

Peak Design BEDB30CH2

Peak Design Everyday Backpack 30L Instruction Manual

Model: BEDB30CH2 | Brand: Peak Design

1. INTRODUCTION

The Peak Design Everyday Backpack 30L is a versatile and durable carrying solution designed to adapt to various needs, from daily commutes to camera gear transport and travel. This manual provides detailed instructions for its setup, operation, maintenance, and specifications to ensure optimal use and longevity.

2. KEY FEATURES

- Intuitive Access:** Features a MagLatch closure for single-handed top access and weatherproof UltraZips for dual side access to the main compartment.
- Customizable Organization:** Equipped with configurable FlexFold dividers to secure and organize photo or everyday gear. Includes dedicated sleeves for up to a 15-inch laptop (or 16-inch MacBook Pro), tablet, and documents, alongside internal and external pockets for smaller items.
- Expandable Design:** The main compartment is expandable, and external carry straps are provided for securing oversized items.
- Weatherproof Protection:** Constructed with a 100% recycled weatherproof shell and durable hardware throughout.
- Comfort & Portability:** Contoured shoulder straps with axial attachments ensure all-day comfort. Features quick grab handles on both sides and an integrated luggage pass-through for easy attachment to rolling luggage.
- Security:** Includes theft-deterrent zip pulls and a quick-access key tether.

3. SETUP & CONFIGURATION

3.1 Adjusting Shoulder Straps and Sternum Strap

For optimal comfort and weight distribution, adjust the shoulder straps to fit snugly against your back. The contoured shoulder straps are designed for ergonomic support. The sternum strap can be adjusted vertically and horizontally for a secure fit across your chest, helping to distribute weight and prevent shoulder fatigue. The sternum strap is also removable if preferred.



Contoured shoulder straps with axial attachments for all-day comfort

Image: Contoured shoulder straps with axial attachments for all-day comfort.



Removable sternum strap

Image: The removable sternum strap provides additional stability.

3.2 Configuring FlexFold Dividers

The FlexFold dividers allow for custom organization of your gear. These origami-inspired dividers can be folded and

positioned using the hook-and-loop fasteners inside the main compartment to create compartments of various sizes. This is ideal for protecting camera bodies, lenses, drones, or other delicate items, preventing them from shifting during transit.

Image: The main compartment with FlexFold dividers configured for camera gear.


3.3 Utilizing External Carry Straps

The external carry straps are located at the bottom of the backpack and can be used to secure larger items such as tripods, yoga mats, or jackets. Thread the straps through the designated loops and tighten them to hold your items securely.

4. OPERATING GUIDELINES

4.1 Top Access (MagLatch)

The MagLatch closure provides quick and secure access to the top compartment. Simply pull up on the latch to open. The magnetic system ensures the flap stays closed when not in use.



MagLatch offers
secure 1-handed
access

Image: The MagLatch mechanism for secure, single-handed top access.



Image: Demonstrating the top access via the MagLatch.

4.2 Dual Side Access (UltraZips)

Both sides of the backpack feature full-length UltraZips, allowing quick access to the main compartment without needing to remove the backpack entirely. This is particularly useful for retrieving camera gear or other items stored in the lower sections of the bag.

4.3 Laptop and Tablet Compartments

The dedicated padded sleeves can accommodate a laptop up to 15 inches (or a 16-inch MacBook Pro) and a tablet. These compartments are accessible from the top zipper, providing secure and protected storage for your electronic devices.



Image: Inserting a laptop into the dedicated padded sleeve.

4.4 Internal and External Pockets

Utilize the various internal and external pockets for organizing smaller essentials such as pens, cables, batteries, and personal items. The external side pockets are suitable for water bottles or compact tripods.

4.5 Integrated Luggage Pass-Through

For convenient travel, slide the backpack's integrated pass-through strap over the handle of your rolling luggage. This secures the backpack to your suitcase, allowing for easier navigation through airports or train stations.



Roller Bag
luggage
passthrough

Image: The integrated luggage pass-through for attaching to rolling bags.

4.6 Theft-Deterrent Zip Pulls and Key Tether

The main compartment zippers feature theft-deterrent pulls that can be secured to prevent accidental opening or unauthorized access. An internal quick-access key tether keeps your keys secure and easily retrievable.



Theft-deterrent zip pulls

Image: Theft-deterrent zip pulls for enhanced security.

Quick-access key tether



Image: Quick-access key tether for convenient and secure key storage.

5. CARE & MAINTENANCE

To maintain the integrity and appearance of your Peak Design Everyday Backpack, follow these care instructions:

- **Cleaning:** For general cleaning, wipe the exterior with a damp cloth and mild soap. Avoid harsh detergents or abrasive cleaners, as these can damage the weatherproof coating.
- **Spot Cleaning:** For stubborn stains, use a soft brush with a small amount of mild soap and water. Rinse thoroughly and allow to air dry completely. Do not machine wash or tumble dry.
- **Drying:** If the backpack becomes wet, open all compartments and allow it to air dry in a well-ventilated area away from direct sunlight or heat sources.
- **Storage:** Store the backpack in a cool, dry place when not in use. Avoid prolonged exposure to extreme temperatures or humidity.



Image: The backpack's weatherproof shell protects contents in various conditions.

6. TROUBLESHOOTING


While the Everyday Backpack is designed for durability and ease of use, here are some common considerations:

- **Difficulty Zipping:** If zippers are stiff, apply a small amount of zipper lubricant or wax. Avoid overpacking, which can strain zippers and seams.
- **Laptop Fit:** The laptop sleeve is designed for up to 15-inch laptops or 16-inch MacBook Pro models. Ensure your device fits within these dimensions to prevent damage or strain on the compartment.
- **Discomfort During Wear:** Re-adjust shoulder straps and sternum strap to ensure even weight distribution. Ensure the backpack is not overloaded beyond its intended capacity.
- **Dividers Not Holding Position:** Ensure the hook-and-loop fasteners on the FlexFold dividers are clean and fully engaged with the interior lining.


7. SPECIFICATIONS

Attribute	Detail
Model Number	BEDB30CH2
Capacity	30 Liters
External Dimensions	7.8 x 14.2 x 20.5 inches (19.8 x 36.1 x 52.1 cm)
Item Weight	Approximately 1.76 kg (3.88 lbs)
Laptop Compatibility	Up to 15-inch laptop or 16-inch MacBook Pro
Material	100% Recycled Weatherproof Shell

EXTERNAL DIMENSIONS



INTERNAL DIMENSIONS



Fits a tablet + laptop
up to 15/16in.

(Average sizes listed, will expand/contract with load.)

Image: Detailed external and internal dimensions of the Everyday Backpack 30L.

8. WARRANTY & SUPPORT

Peak Design products are designed to be lifetime-lasting gear. The Everyday Backpack 30L is backed by Peak Design's comprehensive lifetime warranty, covering defects in materials and workmanship for the life of the product. For warranty claims, product support, or additional inquiries, please visit the official Peak Design website or contact their customer service directly.

For more information, visit the [Peak Design Store on Amazon](#).