

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [KLARSTEIN](#) /
- › [Klarstein Alina Hood Instruction Manual](#)

KLARSTEIN CGCH3-Alina60-BK

Klarstein Alina Hood Instruction Manual

Model: CGCH3-Alina60-BK

1. PRODUCT OVERVIEW

The Klarstein Alina Hood is a modern and efficient wall-mounted extractor hood designed to enhance your kitchen environment. Featuring a sleek glass front, touch controls, and integrated LED lighting with customizable RGB ambient light, it effectively removes cooking odors and steam while adding a stylish touch to your kitchen. This hood operates with a maximum extraction capacity of 600 m³/h and can be used in both extraction and recirculation modes.



Image 1.1: The Klarstein Alina Hood, showcasing its sleek black design and illuminated with blue ambient lighting.

2. SAFETY INSTRUCTIONS

Please read these safety instructions carefully before installation and operation to prevent personal injury or damage to the appliance. Keep this manual for future reference.

- Ensure the power supply voltage matches the rating label on the appliance.
- Installation must be performed by a qualified person in accordance with local regulations.
- Do not operate the hood without filters in place.
- Regularly clean the grease filters to maintain optimal performance and prevent fire hazards.
- Do not flambé under the range hood.
- Ensure adequate ventilation in the room when the range hood is used simultaneously with gas or other fuel-burning appliances.
- Disconnect the appliance from the main power supply before any cleaning or maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and undamaged. If any items are missing or damaged, contact your retailer immediately.

- 1 x Klarstein Alina Extractor Hood
- 2 x Chimney Covers
- 1 x Drain Hose (15 cm diameter x 200 cm length)
- 1 x Check Valve (2 pieces)
- 1 x Mounting Material (wall brackets, dowels, screws)
- 1 x Instruction Manual (German, English language not guaranteed - *Note: This manual is provided in English.*)

4. SETUP AND INSTALLATION

The Klarstein Alina Hood is designed for wall mounting. It can be configured for either extraction (ducting air outside) or recirculation (filtering air and returning it to the kitchen) mode. For recirculation mode, two activated carbon filters (article 10030727, sold separately) are required.

4.1. Wall Mounting

Use the provided mounting material to securely attach the hood to a sturdy wall. Ensure the mounting height above the hob complies with local safety regulations and manufacturer recommendations (typically 65-75 cm for electric hobs and 75-85 cm for gas hobs).




Image 4.1: Dimensional diagram of the Klarstein Alina Hood, illustrating key measurements for installation.

4.2. Ducting (Extraction Mode)

Connect the provided drain hose (15 cm diameter) to the hood's outlet and route it to an external vent. Ensure the check valve is correctly installed to prevent backflow of air.

4.3. Recirculation (Filter Mode)

If using recirculation mode, install two activated carbon filters (not included) into the designated compartments within the hood. These filters will purify the air before it is returned to the kitchen.

5. OPERATING INSTRUCTIONS

The Klarstein Alina Hood features a user-friendly touch control panel for easy operation.



Image 5.1: Detail of the touch control panel, showing the power, speed, and light controls.

5.1. Power and Speed Control

- **Power Button:** Touch to turn the hood on or off.
- **Speed Levels (1, 2, 3):** Select from three different extraction speeds to match your cooking needs. Level 1 is for light cooking, Level 3 for heavy steam and odors.



Image 5.2: The hood in action, demonstrating its powerful extraction capability against cooking steam.

5.2. LED Lighting and Ambient Light

- **LED Lighting:** Touch the light icon to turn the two energy-saving LED lights on or off, illuminating your cooking area.
- **RGB Ambient Light:** The hood features a balanced light concept with nine different ambient colors. Touch the ambient light icon to cycle through available colors: white, red, green, blue, yellow, lilac, orange, turquoise, and yellow-green.



Image 5.3: A detailed view of the hood's side, highlighting the customizable RGB ambient lighting feature.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your Klarstein Alina Hood.

6.1. Cleaning the Exterior

- Wipe the glass and metal surfaces with a soft cloth dampened with mild detergent.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.

6.2. Cleaning Grease Filters

The metal grease filters should be cleaned regularly (approximately every 2-4 weeks, depending on usage) to prevent grease buildup and maintain extraction efficiency. They can be washed by hand with hot soapy water or in a dishwasher.

- To remove, push the filter latch and pull the filter downwards.
- Allow filters to dry completely before re-installing.

6.3. Replacing Activated Carbon Filters (Recirculation Mode)

Activated carbon filters (if used for recirculation) cannot be washed and must be replaced approximately every 3-6 months,

depending on usage. Refer to article 10030727 for replacement filters.

7. TROUBLESHOOTING

If you encounter issues with your Klarstein Alina Hood, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hood not turning on	No power supply; Power cord disconnected; Fuse blown.	Check power connection; Ensure plug is securely inserted; Check household fuse/circuit breaker.
Low extraction power	Grease filters clogged; Activated carbon filters saturated (recirculation); Obstruction in ducting.	Clean grease filters; Replace activated carbon filters; Check ducting for blockages.
Excessive noise	Loose components; Improper installation; Obstruction in fan.	Check all screws and connections; Ensure proper installation; Inspect fan for foreign objects.
Lights not working	LED lights faulty; Electrical connection issue.	Contact customer support for LED replacement; Check electrical connections.

If the problem persists after attempting these solutions, please contact Klarstein customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	KLARSTEIN
Model	CGCH3-Alina60-BK
Dimensions (W x H x D)	Approx. 60 x 37 x 38.5 cm (without chimney finish)
Chimney Cover Dimensions (W x H x D)	Approx. 22.2 x 30-59 x 17.2 cm
Material	Glass
Color	Black
Mounting Type	Wall Mount
Controls Type	Touch
Number of Speeds	3
Max. Extraction Capacity	600 m ³ /h (or 600 CFPH)
Noise Level	59 / 63 dB (lowest / highest performance)
Energy Efficiency Class	A
Lighting Efficiency Class	A
Light Source Type	LED
Ambient Light Colors	White, Red, Green, Blue, Yellow, Lilac, Orange, Turquoise, Yellow-Green
Power Consumption	165 W (when switched on) / 168 watts
Power Supply	220 – 240 V~ 50/60 Hz

Feature	Detail
Item Weight	15 kg / 33 pounds
Drain Hose Diameter	15 cm
Power Cable Length	Approx. 140 cm

9. WARRANTY AND SUPPORT

For warranty information, technical support, or spare parts, please contact your retailer or the official Klarstein customer service. Keep your proof of purchase for any warranty claims.

Visit the official KLARSTEIN Store for more information: [KLARSTEIN Store on Amazon](#)