Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-T08

Joyroom JR-T08 Mini True Wireless Bluetooth Earphones User Manual

Model: JR-T08

Introduction Package Contents Product Overview Setup Operation Charging Maintenance Troubleshooting Specifications Safety Information Warranty & Support

1. Introduction

Thank you for choosing the Joyroom JR-T08 Mini True Wireless Bluetooth Earphones. This manual provides detailed instructions on how to set up, operate, and maintain your earphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

2. Package Contents

Upon opening the package, please verify that all the following items are present:

- Joyroom JR-T08 True Wireless Earphones (Left and Right)
- Portable Charging Case
- USB Charging Cable
- User Manual
- Ear Cushions (various sizes, if included)

3. Product Overview

Familiarize yourself with the components of your Joyroom JR-T08 earphones and charging case.



Figure 3.1: Joyroom JR-T08 earphones securely placed within their open charging case, ready for use or charging.



Figure 3.2: A user demonstrating how to remove an earbud from the charging case, highlighting the compact design.




Figure 3.3: An internal view of the Bluetooth 5.0 chip, indicating advanced wireless connectivity technology.

4. Setup

4.1 Initial Charging

Before first use, fully charge the earphones and the charging case. Connect the provided USB charging cable to the charging port on the case and a compatible USB power source. The charging time is approximately 2 hours.

4.2 Pairing with a Device

1. Ensure the earphones are charged.
2. Open the charging case. The earphones will automatically enter pairing mode, indicated by a flashing LED light on the earbuds (specific light pattern may vary, refer to LED indicator section if available).
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "JR-T08" from the list.
5. Once connected, the LED indicator on the earphones will typically stop flashing or change color.
6. The earphones are now ready for use.

Note: After initial pairing, the earphones will automatically connect to the last paired device when removed from the charging case, provided Bluetooth is enabled on the device.

5. Operating Instructions

The Joyroom JR-T08 earphones feature touch controls for various functions. Specific touch gestures may vary; common functions are listed below:

5.1 Power On/Off

- **Power On:** Remove earphones from the charging case. They will power on automatically.
- **Power Off:** Place earphones back into the charging case and close the lid. They will power off automatically and begin charging.

5.2 Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Control:** The product specifications indicate "Volume Control". This is typically achieved by a long press on one earbud (e.g., left for volume down, right for volume up) or through your connected device. Refer to specific product documentation for exact gestures if available.

5.3 Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud.

5.4 Voice Assistant

- **Activate Voice Assistant:** Triple tap on either earbud (common gesture, may vary).



Figure 5.1: The earphones and charging case positioned near a smartphone, illustrating their use for audio playback.




Figure 5.2: A user wearing a Joyroom JR-T08 earbud, demonstrating its in-ear fit and suitability for active use.

6. Charging

6.1 Charging the Earphones

Place the earphones into the charging case. Ensure they are correctly seated in their respective slots. The earphones will automatically begin charging from the case's internal battery. LED indicators on the earphones or case will show charging status.

6.2 Charging the Case

Connect the USB charging cable to the charging port on the case and a USB power adapter (not included) or a computer's USB

port. The charging time for the case is approximately 2 hours. The case's LED indicator will show charging progress and completion.



Figure 6.1: The charging case and an earbud displayed alongside a smartphone, indicating the portability and charging convenience.

7. Maintenance

7.1 Cleaning

- Regularly clean the earphones and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

- Gently remove any earwax or debris from the ear tips and speaker mesh using a small, soft brush or cotton swab.

7.2 Storage

- When not in use, store the earphones in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures and direct sunlight.

7.3 Water Resistance

The product images suggest some level of water resistance (e.g., water droplets). While the JR-T08 may offer protection against splashes or light rain, it is not designed for submersion. Avoid exposing the earphones to excessive moisture or liquids to prevent damage.



Figure 7.1: The charging case and an earbud with visible water droplets, indicating potential splash resistance.



Figure 7.2: Earbuds resting on a wire with water droplets, further suggesting a degree of water resistance for everyday use.

8. Troubleshooting

If you encounter issues with your Joyroom JR-T08 earphones, refer to the following common problems and solutions:

Problem	Solution
Earphones do not power on.	Ensure the earphones and charging case are fully charged. Place earphones in the case, close the lid, then reopen.

Problem	Solution
Cannot pair with device.	• Ensure Bluetooth is enabled on your device. • Make sure earphones are in pairing mode (LED flashing). • Forget "JR-T08" from your device's Bluetooth list and try pairing again. • Ensure earphones are within range of your device.
Only one earbud is working.	• Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them together. • Ensure both earbuds are charged. • Try resetting the earphones (refer to specific product instructions for reset procedure, if available).
Low volume or poor sound quality.	• Adjust the volume on both your device and the earphones. • Ensure ear tips are clean and properly sealed in your ear canal. • Try different sized ear tips for a better fit. • Ensure there are no obstructions between your device and the earphones.

9. Specifications

Feature	Detail
Brand	Joyroom
Model	JR-T08
Color	Black
Connectivity	Wireless (Bluetooth 5.0)
Headphones Form Factor	In Ear
Compatible Devices	All Bluetooth-enabled devices
Charging Time	Approximately 2 hours
Control Type	Volume Control (and other touch controls)
Material	Plastic, Rubber
Product Dimensions	7 x 4.5 x 3 cm
Item Weight	180.98 g

10. Safety Information

- Do not disassemble, repair, or modify the product. This may cause fire, electronic breakdown, or even complete damage to the product.
- Keep the device away from extreme temperatures, direct sunlight, and high humidity.
- Avoid exposing the earphones to water or other liquids. If they get wet, wipe them dry immediately.

- Do not use the earphones at high volume for extended periods to prevent hearing damage.
- Keep out of reach of children and pets. Small parts may pose a choking hazard.
- Dispose of the product responsibly according to local regulations. Do not dispose of with household waste.

11. Warranty and Support

Joyroom products are designed to provide reliable performance. For warranty information, technical support, or customer service inquiries, please refer to the warranty card included with your purchase or visit the official Joyroom website. Please retain your proof of purchase for warranty claims.

© 2023 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07ZVVDRZY

More documents and user manuals: **https://manuals.plus/**