

[Manuals.plus](#) /

› [PARAMOUNT](#) /

› 3022 DVD User Manual

PARAMOUNT B07ZWBNZSR

3022 DVD

OFFICIAL USER MANUAL

Product Overview

Halfway through a 10-year mission, a group of Astronauts become unstable, overcome by the isolation of deep space. While they prepare to return home, earth is hit by a catastrophic event. The haunting emptiness of space becomes the least of their concerns as they fight to survive against unforeseen threats.

DVD + DIGITAL

OMAR EPPS

KATE WALSH

3022



Image: Front cover of the 3022 DVD, showing the title, main actors, and a visual representation of the space theme.

Setup

- Unpack the DVD:** Carefully remove the DVD disc from its case. Hold the disc by its edges to avoid fingerprints on the playing surface.
- Check Compatibility:** Ensure your DVD player, Blu-ray player, or computer's optical drive is compatible with standard DVD-Video discs.
- Insert the Disc:** Open the disc tray of your player and place the DVD disc with the label side facing up. Close the disc tray.
- Power On:** Turn on your DVD player and television/monitor. Select the correct input source on your television/monitor.

Operating Instructions

- Automatic Playback:** Most DVD players will automatically begin playing the movie or display the main menu upon disc insertion.
- Main Menu Navigation:** Use your remote control's arrow keys to navigate through menu options (e.g., Play Movie, Scene Selection, Special Features, Setup). Press the "Enter" or "OK" button to select an option.
- Language and Subtitle Selection:** Access the "Setup" or "Audio/Subtitles" menu to select your preferred audio language (English) and subtitle options (Subtitled).
- Playback Controls:** Use standard remote control buttons for playback: Play, Pause, Stop, Fast Forward, Rewind, Skip Chapter.

Maintenance

- Disc Handling:** Always hold the DVD by its outer edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- Cleaning:** If the disc becomes dirty or smudged, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or harsh chemicals.
- Storage:** Store the DVD in its original case in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Disc does not play or load.	Disc is dirty or scratched; incorrect disc insertion; player incompatibility.	Clean the disc. Re-insert the disc correctly. Verify player supports DVD-Video format.
No audio during playback.	TV/player volume is low/muted; incorrect audio track selected.	Increase volume. Check mute settings. Select correct audio track from DVD menu.
Poor video quality or freezing.	Disc is damaged; player lens is dirty.	Clean the disc. Try the disc in another player. Consider professional disc repair if severely scratched.

Specifications

- Format:** DVD-Video, NTSC, Subtitled

- **Number of Discs:** 1
- **Language:** English
- **MPAA Rating:** R (Restricted)
- **Product Dimensions:** 0.7 x 7.5 x 5.4 inches; 1.9 ounces
- **ASIN:** B07ZWBNZSR
- **Studio:** PARAMOUNT
- **Director:** John Suits
- **Actors:** Omar Epps, Kate Walsh, Miranda Cosgrove, Angus Macfadyen, Enver Gjokaj
- **Genre:** Science Fiction & Fantasy

Warranty and Support

This product is a standard DVD. Specific warranty information is typically provided by the retailer or the disc's publisher at the time of purchase. For issues related to disc defects or playback, please contact the point of purchase or the publisher, PARAMOUNT, directly.

Please note that physical damage to the disc due to improper handling is not covered by typical product warranties.

© 2024 PARAMOUNT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07ZWBZSR>

More documents and user manuals: <https://manuals.plus/>