

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [XClear](#) /
- > [XClear Wireless Earbuds TT000082 User Manual](#)

XClear TT000082

XClear Wireless Earbuds TT000082 User Manual

Model: TT000082 | Brand: XClear

1. INTRODUCTION

Welcome to your XClear Wireless Earbuds user manual. This guide provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using your device.

What's in the Box

- Wireless Charging Case
- Eartips (various sizes)
- User Manual

2. PRODUCT OVERVIEW

The XClear Wireless Earbuds (Model TT000082) are designed for an immersive audio experience with advanced features for convenience and durability. They feature Bluetooth 5.0 technology for stable connections and clear audio.

Key Features

- **Premium Sound Quality:** Enjoy clear music and calls via Bluetooth 5.0.
- **Fast Pairing:** Quick and easy connection by opening the charging case.
- **Compact Charging Case:** Portable case with a digital LED battery indicator.
- **Comfortable Fit:** Ergonomic design for a secure fit during daily use and sports.
- **IPX5 Sweatproof:** Designed to withstand sweat and light splashes.

Music, Calls, & More

Premium sound quality for music and crystal clear call quality with a Bluetooth 5.0 system.




Image: XClear Wireless Earbuds and Charging Case. The earbuds are shown alongside their compact charging case, highlighting their sleek design.

Secure & Comfortable Fit

A comfortable fit that stays secure inside the majority of ears for unrivaled enjoyment.




Image: A person running while wearing XClear Wireless Earbuds, demonstrating a secure and comfortable fit during physical activity. A close-up inset shows an earbud in an ear.

3. SETUP

Initial Charging

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the charging case to a power source using a compatible USB-C cable. The digital LED battery indicator on the case will show the charging progress. A full charge provides up to 5 hours of playtime for the earbuds and an additional 14 hours with the charging case.



Image: The XClear Wireless Earbuds charging case displaying battery life. Graphics indicate 5 hours of playtime for earbuds and 14 hours with the case.

Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by bright LED lights.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings.
4. Select "XClear Earbuds" from the list of available devices to connect.
5. Once connected, the LED lights on the earbuds will indicate a successful pairing.

Selecting the Right Eartips

For optimal sound quality and comfort, select the eartips that best fit your ear canals. An improper fit may result in reduced sound quality or call performance. Experiment with the different sizes provided to find the most snug and secure fit.

4. OPERATING INSTRUCTIONS

Touch Controls

The XClear Wireless Earbuds feature intuitive touch controls for managing your audio and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.



Image: A diagram illustrating the multi-function touch controls on the XClear Earbuds, showing icons for power, calls, microphone, play/pause, and track skipping.

Dual Mode Listening

You can use the XClear Wireless Earbuds in either Stereo Mode (both earbuds) or Single Ear Mode (one earbud). To properly use Single Ear Mode, ensure the unused earbud is placed in the charging case and the lid is closed.

SINGLE EAR MODE (LEFT EAR)



Dual Mode Listening

Choose between Stereo Mode or Single Ear Mode and switch between them effortlessly.

(NOTE: To properly use Single Ear Mode, place L/R Earbud into Charging Case and close it).

Image: A man wearing a single XClear earbud, demonstrating the dual mode listening feature. The text indicates the ability to switch between stereo and single ear mode.

5. MAINTENANCE

Cleaning and Storage

- Regularly clean the earbuds and charging case with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials.
- Store the earbuds in their charging case when not in use to protect them from dust and damage.

Battery Care

- To prolong battery life, avoid fully discharging the earbuds and charging case frequently.
- Charge the device using only the provided cable or a certified USB-C charger.
- Do not expose the device to extreme temperatures.



Image: A close-up of an XClear earbud with water droplets, illustrating its sweatproof and water-resistant design.

6. TROUBLESHOOTING

Common Issues and Solutions

- **Earbuds not charging:** Ensure the charging cable is securely connected to both the case and the power source. Verify that the earbuds are correctly seated in the charging case. Check the charging case's battery level.
- **Earbuds not pairing:** Make sure Bluetooth is enabled on your device. Place the earbuds back in the case, close the lid, then open it again to re-enter pairing mode. If issues persist, try forgetting the device in your Bluetooth settings and re-pairing.
- **Poor sound quality:** Ensure the eartips provide a snug fit in your ear canals. Clean any debris from the earbud speakers. Check the audio source for quality issues.
- **One earbud not working:** Place both earbuds back into the charging case, close the lid, and then open it again. This often re-syncs them. If the issue continues, try resetting the earbuds (refer to the full manual for specific reset instructions if available).

7. SPECIFICATIONS

Feature	Detail
Brand	XClear
Model Number	TT000082
Model Name	ICANONIC
Connectivity Technology	Bluetooth
Bluetooth Version	5.0
Ear Placement	In Ear
Form Factor	In Ear
Control Type	Touch Control
Water Resistance Level	Water Resistant (IPX5)

Battery Average Life (Earbuds)	5 Hours
Battery Charge Time (with Case)	14 Hours
Item Weight	1.44 Ounces
Microphone	Included
Compatible Devices	Android, Galaxy, Tablet, PC, Notebook, iPad, iPhone

8. WARRANTY AND SUPPORT

Warranty Information

XClear offers a 1-Year Warranty on this product. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the official XClear website or contact customer support.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the XClear official website or contact their customer service department. Contact details can typically be found on the product packaging or the brand's website.