

MuGo OD-E1

MuGo OD-E1 True Wireless Earbuds Instruction Manual

Model: OD-E1 | Brand: MuGo

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your MuGo OD-E1 True Wireless Earbuds. Please read this manual thoroughly before operating the device and retain it for future reference. These earbuds are designed for high-quality audio and convenient wireless connectivity, suitable for various activities including sports and daily use.

PACKAGE CONTENTS

- MuGo OD-E1 True Wireless Earbuds (Left and Right)
- Portable Charging Case
- USB Type-C Charging Cable
- Multiple Sizes of Ear Tips (Small, Medium, Large)
- User Manual

PRODUCT OVERVIEW

The MuGo OD-E1 earbuds feature an ergonomic, lightweight design (approximately 3g per earbud) for comfortable and secure fit. The portable charging case is compact and includes a digital display to indicate battery levels. Each earbud is equipped with touch controls for easy management of audio playback and calls.



Image: MuGo OD-E1 True Wireless Earbuds in their open charging case, showing internal charging contacts and a digital battery display. The case indicates a full charge.

## SETUP

---

### 1. Charging the Case and Earbuds

Before first use, fully charge the charging case and earbuds. Connect the provided USB Type-C cable to the charging port on the back of the case and plug the other end into a USB power source. The digital display on the case will show the current charge level. The earbuds will charge automatically when placed inside the powered case.





Image: A hand holding the MuGo OD-E1 charging case, which displays '100' indicating a full charge. The earbuds are inside the case, ready for use.

## 2. Pairing with a Device

The MuGo OD-E1 earbuds feature one-step pairing. Simply open the charging case, and the earbuds will automatically enter pairing mode. On your device (smartphone, tablet, etc.), enable Bluetooth and select "OD-E1" from the list of available devices to

connect.



# INSTANT PAIRING

Enter pairing mode right after  
out of the charging case

Image: A smartphone screen displaying Bluetooth settings, with the earbuds (likely listed as 'Q12' or similar) appearing as an available device for pairing.

## 1. Wearing the Earbuds

Select the ear tips that provide the most comfortable and secure fit for your ears. Gently insert each earbud into your ear canal and twist slightly to ensure a snug seal. The ergonomic design helps them stay in place during activities.

# STABLE CONNECTION

Stay connect, stay in the zone.



Hi-Fi Sound  
Quality



Bluetooth  
5.0



33-66ft  
Distance



Fully-automatic  
Pairing

Image: A person wearing the MuGo OD-E1 earbuds, demonstrating a secure and comfortable fit in the ear for optimal sound and stability.

## 2. Smart Touch Controls

The earbuds feature intuitive touch controls on their outer surface:

- **Play/Pause Music:** Touch once (L/R earbud)
- **Answer/Hang Up Call:** Touch once (L/R earbud)
- **Previous/Next Track:** Double click (L/R earbud)
- **Activate Voice Assistant (Siri):** Touch and hold for 2 seconds (L/R earbud)
- **Volume Up/Down:** Triple click (L/R earbud)

# PORTABLE CHARGING CASE

## SMALL BUT POWERFUL

Automatic charging on the go!



Music Time  
Talk Time



Standby Time



Charging Time



**5 Times**  
Magnetic  
Charging Case

Image: A diagram illustrating the touch control functions of the MuGo OD-E1 earbuds, detailing actions for music playback, call management, and voice assistant activation.

### 3. Single Earbud Mode

Either earbud can be used independently. Simply take one earbud out of the charging case, and it will automatically connect to

your device. The other earbud can remain in the case or be used by another person.

## **MAINTENANCE**

---

### **1. Cleaning**

Regularly clean your earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials. Ensure the charging contacts on both the earbuds and case are clean and dry.

### **2. Storage**

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from extreme temperatures.

### **3. Water Resistance (IPX7)**

The earbuds are rated IPX7 waterproof, meaning they can withstand temporary immersion in water up to 1 meter for 30 minutes. They are resistant to sweat and rain, making them suitable for workouts. However, they are not designed for swimming or prolonged submersion. Ensure earbuds are completely dry before placing them back in the charging case to prevent damage.

# UPGRADED TOUCH-SCREEN DESIGN



Touch Once(L/R)  
Play/Pause music




Touch Once (L/R)  
Answer/Hang up



Double Click (L/R)  
Previous/Next



Touch 2 Seconds  
(L/R) Activate Siri



Triple Click(L/R)  
Volume Down/Up

Image: A person exercising outdoors, with the IPX7 waterproof logo prominently displayed, indicating the earbuds' resistance to sweat and water during physical activity.

## TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds and the charging case are sufficiently charged. Place earbuds back in the case, close it, then open it again to re-initiate pairing mode. On your device, forget the previous Bluetooth connection and try pairing again.
- **No sound from one or both earbuds:** Check the volume level on your connected device. Ensure the earbuds are properly seated in your ears. Re-pair the earbuds with your device.
- **Charging issues:** Verify that the USB Type-C cable is securely connected to both the charging case and the power source. Try a different USB port or power adapter. Ensure the charging contacts on the earbuds and inside the case are clean.
- **Intermittent connection:** Ensure your device is within the effective Bluetooth range (up to 33-66 feet). Avoid physical obstructions between your device and the earbuds.

## SPECIFICATIONS

|                                   |                                                               |
|-----------------------------------|---------------------------------------------------------------|
| Model Name                        | OD-E1                                                         |
| Brand                             | MuGo                                                          |
| Connectivity Technology           | Bluetooth 5.0                                                 |
| Wireless Communication Technology | Bluetooth                                                     |
| Included Components               | USB Type-C Cable                                              |
| Material                          | Silicone                                                      |
| Specific Uses For Product         | Sports and Exercise                                           |
| Control Type                      | Touch Control (Call Control, Music Playback, Voice Assistant) |
| Item Weight                       | 1 Grams (0.035 ounces) per earbud                             |
| Water Resistance Level            | IPX7 (Waterproof)                                             |
| Product Dimensions                | 1.18 x 0.39 x 0.39 inches                                     |
| Batteries                         | 1 Lithium Ion battery required (included)                     |
| Ear Placement                     | In Ear                                                        |
| Noise Control                     | Sound Isolation                                               |

## SAFETY INFORMATION

- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Do not use the earbuds in situations where inability to hear ambient sounds could be dangerous (e.g., driving, cycling, walking in traffic).
- Keep the earbuds and charging case away from children and pets to prevent accidental ingestion of small parts.
- Do not attempt to disassemble, repair, or modify the product. This may void the warranty and cause injury.
- Dispose of batteries and electronic components responsibly according to local regulations.

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official MuGo website. If you encounter any issues not covered in this manual, please contact customer service for assistance.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B07ZYLZKSN>

More documents and user manuals: <https://manuals.plus/>