ICOOKPOT YSH20(07)B-BLACK-A

ICOOKPOT Electric Kettle User Manual

Model: YSH20(07)B-BLACK-A
Brand: ICOOKPOT

Product Overview

The ICOOKPOT Electric Kettle is a multi-functional appliance designed for precise temperature control and versatile cooking. It features a durable glass body, stainless steel components, and a user-friendly interface. This kettle is ideal for preparing a variety of hot beverages and meals, including tea, coffee, yogurt, and eggs.



Figure 1: ICOOKPOT Electric Kettle with base and accessories.

Setup

Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all parts are present and undamaged. The package should include the main kettle unit, a lid, a tea infuser, an egg cooker, a yogurt box, and the power base.



Figure 2: All components included with the ICOOKPOT Electric Kettle.

Initial Cleaning

Before first use, wash the glass kettle, lid, tea infuser, egg cooker, and yogurt box with warm, soapy water. Rinse thoroughly and dry. Do not immerse the power base in water. Wipe the exterior of the power base with a damp cloth.

Operating Instructions

Control Panel Overview

The kettle features a user-friendly control panel on its base with four touch screen keys and one menu knob. This allows for easy selection of various functions without complex time or temperature settings.



Figure 3: Detailed view of the control panel with menu knob and function buttons.

General Operation

1. Place the kettle securely on the power base. Ensure it locks into place to prevent movement during operation.
2. Fill the kettle with the desired amount of water or ingredients. Observe the minimum and maximum fill lines indicated on the glass.
3. Rotate the MENU knob clockwise or anticlockwise to select your desired function (e.g., Boil, Green Tea, Coffee, Milk, Noodles, Soup, Boiled Egg, Disinfection).
4. The kettle will automatically begin the selected function. The display will show the current temperature or remaining time.
5. To cancel a function at any time, press the 'Cancel' button.

Specific Functions

- **Precise Temperature Control:** Preset smart programs allow for steeping tea or coffee at optimal temperatures (160℉-200℉) for best flavor.
- **Multi-Appliance Use:** This kettle can be used for various tasks beyond boiling water, including making yogurt, oatmeal, pasta, eggs, slow cooking, preparing soup, warming milk, and baby drinks.

- **Tea Infuser:** For brewing loose leaf tea or infusing fruits, attach the stainless steel tea infuser to the lid. The fine mesh prevents particles from entering your drink.



Figure 4: Kettle with tea infuser in use, showing brewed tea.

- **Egg Cooker:** Utilize the included egg holder for perfectly boiled or steamed eggs.
- **Disinfection:** A dedicated disinfection function ensures hygiene for baby bottles or other small items.
- **Delay Time:** Use the 'Delay Time' function to program the kettle to start a function up to 24 hours in advance.
- **Keep Warm:** The kettle can maintain a warm temperature (105℉-185℉) for extended periods after a function is complete.

Maintenance

Cleaning

Always unplug the kettle and allow it to cool completely before cleaning. Hand wash the glass kettle, lid, and accessories. The kettle's wide mouth facilitates easy cleaning. Do not submerge the power base in water. Wipe the exterior with a damp cloth.

Storage

Store the kettle and its accessories in a clean, dry place when not in use.

Troubleshooting

If you experience issues such as E1 errors, flashing temperatures, or continuous boiling, this may indicate a temperature sensor problem. Ensure the kettle is properly seated on the base and that the base is dry. If problems persist, contact customer support. For any concerns regarding glass integrity, discontinue use immediately.

Specifications

Feature	Detail
Brand	ICOOKPOT
Model Name	YSH20(07)B-BLACK-A
Color	Black
Capacity	2 Liters
Material	Glass, Stainless Steel
Special Feature	Programmable
Product Dimensions	6.3"L x 6.3"W x 9.45"H
Item Weight	4.59 pounds
Included Components	Tea Infuser, Egg Cooker, Yogurt Box

Warranty and Support

The ICOOKPOT Electric Kettle comes with a 1-year warranty from the manufacturer. For any product inquiries, technical support, or warranty claims, please contact ICOOKPOT customer service directly. Refer to the contact information provided in your product packaging or visit the official ICOOKPOT website.