

## Linon AMZN1429

# Linon Home Décor Caitlyn Brown Outdoor Chair Instruction Manual

Model: AMZN1429

## INTRODUCTION

---

Thank you for choosing the Linon Home Décor Caitlyn Brown Outdoor Chair. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new outdoor chair. Please read these instructions thoroughly before assembly and retain them for future reference.



Image: Front view of the Linon Caitlyn Brown Outdoor Chair with its light-colored cushion, showcasing the acacia wood frame.

## SAFETY INFORMATION

**WARNING: This product can expose you to chemicals including wood dust, which is known to the State of California to cause cancer. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).**

For external use only. Avoid contact with eyes. Keep away from naked flame or direct heat sources.

- Always assemble the chair on a soft, clean surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight recommendation of 250 pounds.
- Keep small parts away from children during assembly.

## PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or

damaged, do not proceed with assembly and contact customer support.

- Acacia Wood Chair Frame Components
- 1 x 3.15" Thick Seat Cushion (100% Polyester)
- Assembly Hardware (screws, bolts, washers, Allen wrench)

## SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. Follow these general steps for assembly. Refer to the included hardware and diagrams for specific connections.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match all components with the parts list provided in your specific assembly diagram.
3. **Assemble Frame:** Begin by attaching the main frame pieces. Typically, this involves connecting the backrest to the seat frame, and then attaching the legs and armrests. Use the provided hardware and Allen wrench. Do not fully tighten screws until all parts are loosely connected.
4. **Secure All Connections:** Once all parts are in place, gradually tighten all screws and bolts. Ensure the chair is stable and level.
5. **Place Cushion:** Position the 3.15" thick polyester cushion onto the seat.



Image: A diagram illustrating the various dimensions of the Linon Caitlyn Brown Outdoor Chair, including height, width, and depth measurements.

## OPERATING INSTRUCTIONS

The Linon Caitlyn Outdoor Chair is designed for comfortable lounging in outdoor environments.

- **Placement:** This chair is suitable for outdoor use, such as on patios, decks, or in gardens.
- **Weight Capacity:** The maximum recommended weight for this chair is 250 pounds.
- **Usage:** Use the chair for lounging and relaxation. Avoid standing on the chair or using it for purposes other than its intended design.





Image: The Linon Caitlyn Brown Outdoor Chair positioned on a patio, adorned with a blue pillow featuring a white star pattern, next to a small plant.

Your browser does not support the video tag.

Video: A short promotional video from Linon showcasing the Caitlyn Brown Outdoor Chair from various angles, highlighting its design and features.

## MAINTENANCE AND CARE

---

Proper care will extend the life and appearance of your outdoor chair.

- **Cleaning the Frame:** Wipe the acacia wood frame clean with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing and thorough drying.
- **Cushion Care:** The 100% polyester cushion is fade-resistant. Spot clean with a mild detergent and water. Allow to air dry completely.
- **Protection:** While designed for outdoor use, prolonged exposure to harsh weather conditions (heavy rain, direct sunlight, extreme temperatures) can affect the chair's longevity. Consider using a furniture cover or storing the chair in a sheltered area during inclement weather or off-season.
- **Periodic Inspection:** Regularly check all hardware connections and tighten any loose screws or bolts to maintain stability.



Image: A close-up view of the chair's seat, showing the texture of the light-colored polyester cushion and the grain of the brown acacia wood frame.

## TROUBLESHOOTING

---

If you encounter issues with your chair, refer to the following common solutions:

- **Wobbling or Instability:** Ensure all assembly hardware (screws, bolts) are fully tightened. Check that the chair is placed on a level surface.
- **Difficulty Aligning Parts During Assembly:** Loosely connect all parts first before fully tightening any screws. This allows for minor adjustments. If a part seems misaligned, double-check the assembly diagram.

- **Fading or Wear:** While the cushion is fade-resistant, prolonged direct sun exposure can still cause some fading over time. Protect the chair with a cover when not in use.

## SPECIFICATIONS

Feature	Detail
Brand	Linon
Model Name	Caitlyn Acorn Brown Wood Outdoor Chair
Model Number	AMZN1429
Color	Brown
Material	Acacia Wood (Frame), 100% Polyester (Cushion)
Product Dimensions	29.13"D x 35.83"W x 37.8"H
Seat Depth	20.07 inches
Chair Backrest Width	21.65 inches
Item Weight	26.5 pounds
Maximum Weight Recommendation	250 Pounds
Indoor/Outdoor Usage	Outdoor
Assembly Required	Yes
Product Care Instructions	Spot Clean, Wipe Clean

## WARRANTY INFORMATION

This Linon Home Décor Caitlyn Brown Outdoor Chair comes with a**6-month limited warranty**. Please retain your proof of purchase for any warranty claims. For specific details regarding coverage and claims, refer to the warranty documentation included with your product or contact Linon customer support.

## CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact Linon Home Décor customer service. You can also visit the official Linon store for more information and products:

Visit the Linon  
Store

