Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Suptek SPM201

Suptek SPM201 Dual Clamp Bookshelf Speaker Wall Mount Instruction Manual

Model: SPM201

Introduction

This manual provides detailed instructions for the safe and proper installation and operation of your Suptek SPM201 Dual Clamp Bookshelf Speaker Wall Mounts. These mounts are designed to securely hold large surround sound speakers, offering adjustable positioning for an optimized listening experience.



Image: Before and after comparison showing speakers on a desk versus wall-mounted with Suptek mounts, illustrating space-saving and improved aesthetics.

Safety Information

- **Wall Type Verification:** Always verify your wall type (stud, concrete, brick/stone) before installation. Use appropriate mounting hardware for your specific wall construction.
- **Weight Capacity:** Ensure the wall can support the combined weight of the mount and your speaker. Each mount has a maximum load capacity of 25 kg (55 lbs). Do not exceed this limit.
- **Professional Installation:** If you are unsure about the installation process or your wall's capacity, consult a qualified professional.
- **Secure Fastening:** Ensure all screws and bolts are tightened securely to prevent accidental detachment.
- **Cable Management:** Route cables carefully to avoid pinching or damage, which could pose a safety hazard.

Package Contents

Please check that all components are present before beginning installation:

- 2 x Suptek Speaker Wall Mounts
- 1 x Mounting Hardware Kit (various screws, anchors, washers)
- 1 x User Manual



Image: The complete mounting hardware kit, including various screws, anchors, and washers required for installation.

Specifications

Feature	Detail
Model Number	SPM201
Material	Alloy Steel
Color	Black

Feature	Detail
Max Load Capacity (per mount)	25 kg (55 lbs)
Adjustable Speaker Width	135 mm - 280 mm (5.4 - 11 inches)
Tilt Adjustment	Up/Down 7.5 degrees
Swivel Adjustment	Left/Right 45 degrees
Product Dimensions (L x W x H)	16.2 x 9.2 x 27 cm (6.38 x 3.62 x 10.63 inches)




Image: Technical drawing detailing the dimensions and adjustable width range of the SPM201 speaker mount.

Setup and Installation

Tools Required (Not Included)

- Drill

- Drill bits (appropriate for wall type and anchors)
- Pencil
- Level
- Screwdriver
- Stud finder (for stud walls)

Step-by-Step Installation

1. **Prepare the Mounting Location:** Select a suitable wall location. Use a stud finder to locate wall studs if mounting on drywall. Mark the desired height and position for the mounts. Ensure the location can support the weight and allows for optimal speaker placement.
2. **Mark Drilling Points:** Hold the wall plate of the mount against the wall at the marked position. Use a level to ensure it is perfectly straight. Mark the drilling points through the holes on the wall plate.
3. **Drill Pilot Holes:** Drill pilot holes at the marked points. The size of the drill bit will depend on your wall type and the anchors provided. For concrete or brick walls, use appropriate masonry drill bits and wall anchors.
4. **Attach Wall Plate:** Secure the wall plate to the wall using the provided screws and anchors. Ensure it is firmly attached and stable.



Image: Detailed view highlighting the plastic wall cover, cable management, and anti-slip EVA pads on the speaker platform.

5. **Assemble Speaker Clamp:** Attach the speaker clamping mechanism to the main arm of the mount. Ensure all screws are tightened securely. The clamps feature anti-slip EVA pads to protect your speakers.
6. **Mount Speaker:** Place your speaker onto the mount's platform. Adjust the side clamps to securely hold the speaker. The clamps are independently adjustable with fine-thread screws to accommodate speaker widths between 135mm and 280mm.
7. **Cable Management:** Route speaker cables through the integrated cable management opening on the mount arm for a tidy and organized appearance.
8. **Install Plastic Wall Cover:** Place the decorative plastic cover over the wall plate to conceal the mounting hardware for a clean and aesthetic finish.

Operating and Adjustments

The Suptek SPM201 mounts offer flexible positioning to optimize your audio experience.

Tilt Adjustment

The speaker mount allows for vertical tilt adjustment of up to 7.5 degrees. To adjust, locate the adjustment knob/screw on the side

of the mount. Loosen it, adjust the speaker to the desired upward or downward angle, and then firmly tighten the knob/screw to secure the position.

Swivel Adjustment

The mount can swivel horizontally up to 45 degrees left or right. To adjust, loosen the relevant adjustment knob/screw, rotate the speaker to the preferred direction, and then tighten the knob/screw firmly to lock it in place.




Image: Diagram showing the range of tilt (±7.5°) and swivel (±45°) adjustments available for precise speaker positioning.

Maintenance

- **Regular Checks:** Periodically inspect all mounting screws, speaker clamping screws, and adjustment mechanisms to ensure they remain tight and secure.
- **Cleaning:** Clean the mounts with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- **Weight Limit:** Always ensure that no excessive weight is placed on the mounts beyond the specified maximum capacity of

25 kg per mount.

Troubleshooting

Speaker feels unstable after mounting:

- Ensure all wall mounting screws are fully tightened into appropriate wall anchors.
- Verify the speaker clamping screws are securely holding the speaker on the platform.
- Confirm the wall type is appropriate for the installation and the anchors are correctly installed.
- Check that the speaker weight does not exceed the 25 kg (55 lbs) limit per mount.

Difficulty adjusting tilt/swivel:

- Ensure the adjustment knobs/screws are sufficiently loosened before attempting to reposition the speaker.
- Do not force adjustments. If resistance is met, re-check the loosening mechanism and ensure no cables are obstructing movement.

Warranty and Support

For warranty information or technical support regarding your Suptek SPM201 speaker wall mounts, please refer to the contact details provided with your purchase documentation or visit the official Suptek website. Please retain your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08116Q1PS

More documents and user manuals: **https://manuals.plus/**