



Manuals.plus /

- › Coleman /
- › Coleman 30QT Performance Cooler Instruction Manual

**Coleman 2000036083**

# Coleman 30QT Performance Cooler Instruction Manual

## INTRODUCTION

---

This manual provides essential instructions for the proper use and maintenance of your Coleman 30QT Performance Cooler. Designed for durability and efficient cooling, this 28-liter cooler is ideal for various outdoor activities, including picnics, camping, and road trips. Following these guidelines will ensure optimal performance and longevity of your cooler.



Image: The Coleman 30QT Performance Cooler, showcasing its blue body and black lid.

## PRODUCT FEATURES

---

- **Lightweight and Portable Design:** Easy to carry for various outdoor activities.
- **Efficient Insulation:** Features PU foam insulation designed to keep contents cold for up to 2 days.
- **Generous Capacity:** Offers a 28-liter capacity, capable of holding approximately 38 standard 0.33-liter cans.
- **Integrated Bail Handle:** Equipped with a convenient handle for comfortable and secure transport.
- **Food-Safe Interior:** The interior is BPA-free, ensuring it is safe for storing food and beverages, conforming to EU food regulation EN 12456.
- **Durable Construction:** Made from high-density polyethylene (HDPE) for both the exterior and interior lining, providing robust durability.

## SETUP AND FIRST USE

---

### 1. Unpacking

Carefully remove all packaging materials from the cooler. Inspect the cooler for any signs of damage that may have occurred during shipping. If damage is found, contact customer service before use.

### 2. Initial Cleaning

Before its first use, wash the interior and exterior of the cooler with mild soap and warm water. Rinse thoroughly with clean water and allow it to air dry completely. This removes any manufacturing residues.

### 3. Pre-cooling

For optimal cold retention, it is recommended to pre-cool the cooler. Place ice, ice packs, or frozen water bottles inside the empty cooler several hours before loading your items. This lowers the internal temperature of the cooler walls, enhancing its performance.

## OPERATING INSTRUCTIONS

---

### 1. Loading the Cooler

- **Pre-chill Contents:** Always place pre-chilled food and beverages into the cooler. Warm items will melt ice faster.
- **Maximize Ice:** Fill any remaining space with ice, ice packs, or frozen bottles. A full cooler with minimal air space retains coldness more effectively.
- **Layering:** Place items that need to stay coldest at the bottom, covered by ice.

### 2. Maintaining Coldness

- **Keep Lid Closed:** Minimize the frequency and duration of opening the lid to prevent cold air from escaping.
- **Avoid Direct Sunlight:** Position the cooler in a shaded area whenever possible to reduce heat absorption.
- **Drain Water (Optional):** While some prefer to keep melted ice water for additional cooling, draining it can prevent items from getting soggy.

### **3. Transporting the Cooler**

Utilize the integrated bail handle for easy and comfortable carrying. Ensure the lid is securely closed and latched to prevent accidental spills during transport.



Image: The Coleman 30QT Performance Cooler shown with its handle extended, ready for transport.

## MAINTENANCE AND CARE

---

### 1. Cleaning

- **After Each Use:** Empty the cooler of all contents and melted ice. Wash the interior and exterior with mild dish soap and warm water.
- **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
- **Drying:** Allow the cooler to air dry completely with the lid open to prevent mildew and odors.
- **Stubborn Stains/Odors:** For persistent stains or odors, create a paste of baking soda and water. Apply to the affected area, let it sit for a few hours, then scrub and rinse.

### 2. Storage

Store your Coleman cooler in a cool, dry place away from direct sunlight. It is recommended to store the cooler with the lid slightly ajar to allow for air circulation and prevent the buildup of stale odors or mildew.



Image: Front view of the Coleman 30QT Performance Cooler, highlighting the lid design.

## TROUBLESHOOTING

---

Issue	Possible Cause	Solution
Contents not staying cold for expected duration.	Lid not fully closed; insufficient ice; warm contents loaded; frequent opening; direct sunlight exposure.	Ensure lid is securely closed. Pre-chill cooler and contents. Use ample ice/ice packs. Minimize lid openings. Place in shade.
Unpleasant odors inside the cooler.	Improper cleaning; cooler stored with lid closed.	Clean thoroughly with mild soap and water, then rinse with a baking soda solution. Air dry with lid open. Store with lid slightly ajar.
Lid is difficult to open.	Vacuum seal created by cold air; lid stuck due to residue.	Gently pry open from a corner. Apply slight pressure to the lid while lifting the handle. Ensure lid and rim are clean.

## SPECIFICATIONS

Feature	Detail
Model Number	2000036083
Capacity	28 Liters (30QT)
Weight	2.6 kg
Exterior Dimensions (L x W x H)	45 x 34 x 39 cm
Interior Dimensions (L x W x H)	39 x 26 x 31 cm
Insulation Material	Polyurethane foam
Exterior/Interior Material	HDPE, BPA-free
Color	Blue
Ice Retention	Up to 2 days (with ice/ice packs)

## WARRANTY AND SUPPORT

Coleman products are manufactured to high-quality standards. For specific warranty information, product support, or to inquire about replacement parts, please visit the official Coleman website or contact their customer service department directly. It is advisable to retain your purchase receipt as proof of purchase for any warranty claims.