

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ingenuity](#) /

› [Ingenuity Cozy Spot Reversible Duvet Activity Gym & Play Mat User Manual](#)

**Ingenuity 12126**

# Ingenuity Cozy Spot Reversible Duvet Activity Gym & Play Mat User Manual

Model: 12126 | Brand: Ingenuity

## INTRODUCTION

The Ingenuity Cozy Spot Reversible Duvet Activity Gym is designed to provide a comfortable and engaging play space for infants from newborn up to 36 months. This versatile activity gym supports three modes of play: tummy time, lay and play, and seated play, adapting as your child grows.

Key features include an ultra-plush reversible duvet mat, a SlimFold wooden toy bar for easy storage, and five detachable toys made from natural materials. The mat is designed for cloud-like comfort, ensuring a soft surface for your baby's activities.



Figure 1: Assembled Ingenuity Cozy Spot Reversible Duvet Activity Gym.

## SETUP INSTRUCTIONS

---

The Ingenuity Cozy Spot Activity Gym is designed for quick and easy setup. Follow these steps to prepare the play gym for use:

- 1. Unpack Components:** Carefully remove all components from the packaging. Ensure all parts are present: the duvet mat, the SlimFold wooden toy bar, the tummy time pillow, and the five detachable toys (silicone apple toy, plush bear, wooden ring toy, mirror, and bead rattle).
- 2. Unfold the Mat:** Lay the ultra-plush duvet mat flat on a clean, safe surface. The mat is reversible, allowing you to choose between two neutral prints.
- 3. Assemble the Toy Bar:** The SlimFold wooden toy bar is designed to easily unfold. Gently extend the wooden arches until they form a stable arch over the mat. Ensure the connections are secure.
- 4. Attach Toys:** Connect the five detachable toys to the designated loops or holes on the wooden toy bar. These toys are designed to engage your baby during play.
- 5. Position Tummy Time Pillow:** Place the included tummy time pillow on the mat as needed to support your baby during tummy time sessions.

For detailed reassembly instructions, refer to images 1-7 on pages 8-10 of the official PDF instruction

manual, available via the product's Amazon page.



## **SlimFold wooden toy bar easily collapses for storing**

Figure 2: SlimFold wooden toy bar easily collapses for storage.



## 5 detachable toys + tummy time pillow

Figure 3: Detachable toys and tummy time pillow.

### OPERATING INSTRUCTIONS

The Ingenuity Cozy Spot Activity Gym offers multiple ways for your baby to play and develop:

- **Lay and Play:** For newborns and young infants, position your baby on their back under the toy bar. The hanging toys encourage reaching, batting, and visual tracking, promoting early motor skills and hand-eye coordination.
- **Tummy Time:** Place your baby on their stomach on the plush mat, using the tummy time pillow for support if desired. This position helps strengthen neck and upper body muscles. The mat's soft texture and engaging toys provide stimulation during tummy time.
- **Seated Play:** As your baby grows and can sit unassisted, they can continue to interact with the detachable toys while seated on the mat. The toys can be removed from the bar for closer exploration and play.

The reversible duvet mat allows for a quick change in aesthetic, offering two gender-neutral print choices to match your home decor.



## Plush duvet mat for comfort

Figure 4: Baby enjoying the plush duvet mat.

## Reversible duvet cover



Figure 5: Reversible duvet cover options.

## MAINTENANCE

Proper care and maintenance will extend the life of your Ingenuity Cozy Spot Activity Gym:

- **Duvet Mat and Removable Cover:** Before washing, remove the toy bar, all detachable toys, and the plush toy. Machine wash the duvet mat and its removable cover with cold water on a gentle cycle. Do not use bleach. Air dry thoroughly.
- **Toy Bar Assembly and Toys:** Wipe clean the wooden toy bar and all detachable toys with a damp cloth and mild soap. Air dry completely. Do not immerse the toy bar or toys in water.



Figure 6: Duvet mat is machine washable.

## TROUBLESHOOTING

If you encounter any issues with your activity gym, please refer to the following common solutions:

- **Stability Issues:** Ensure the wooden toy bar is fully extended and securely locked into place. Check that the mat is laid flat on an even surface.
- **Toys Not Engaging:** Verify that the detachable toys are securely attached to the toy bar. Try repositioning them or rotating them to offer new perspectives to your baby. Ensure the mirror is clean and free of smudges.
- **Difficulty Folding/Storing:** Make sure all toys are detached from the toy bar. Ensure the toy bar is properly collapsed using the SlimFold mechanism. The mat has built-in handles to assist with folding and carrying.
- **Cleaning Concerns:** Always follow the care instructions provided in the Maintenance section. For stubborn stains, pre-treat with a mild, baby-safe stain remover before machine washing the mat.

If problems persist, contact Ingenuity customer support for further assistance.

## SPECIFICATIONS

<b>Product Dimensions</b>	32.3 x 32.3 x 19.3 inches (L x W x H)
<b>Item Model Number</b>	12126
<b>Target Gender</b>	Unisex
<b>Material Composition</b>	50% Wood, 50% Polyester
<b>Item Weight</b>	3.89 pounds
<b>Power Source</b>	Unpowered
<b>Batteries Required</b>	No

## WARRANTY & SUPPORT

For information regarding product warranty, please refer to the official user manual (PDF) provided with your purchase or available for download from the Ingenuity website or the product's Amazon listing page. This document contains detailed warranty terms and conditions.

Should you require technical assistance, have questions about product functionality, or need to report a defect, please contact Ingenuity customer support. Contact details can typically be found on the product packaging or the official Ingenuity brand website.

### Online Resources:

- [Download User Manual \(PDF\)](#)
- [Visit the Ingenuity Store on Amazon](#)

## Related Documents - 12126

	<p><a href="#">ingenuity Cozy Spot™ Reversible Duvet Activity Gym - Loamy™ User Manual &amp; Assembly Guide</a></p> <p>Official user manual and assembly instructions for the Ingenuity Cozy Spot™ Reversible Duvet Activity Gym - Loamy™. Includes care, cleaning, safety warnings, parts list, and assembly steps.</p>
	<p><a href="#">Ingenuity Cozy Spot™ Reversible Duvet Activity Gym-Calla™: Care, Assembly, and Safety Instructions</a></p> <p>Comprehensive guide for the Ingenuity Cozy Spot™ Reversible Duvet Activity Gym-Calla™ (Model 12421-WW). Includes detailed care and cleaning instructions, critical safety warnings to prevent injury, step-by-step assembly procedures, and a complete parts list with descriptions. Designed for babies, this activity gym provides a safe and engaging play environment.</p>
	<p><a href="#">Ingenuity Cozy Spot™ Reversible Duvet Activity Gym - Loamy™ User Manual and Care Guide</a></p> <p>Learn how to care for and assemble the Ingenuity Cozy Spot™ Reversible Duvet Activity Gym - Loamy™. This user manual provides essential instructions for safe use and maintenance of the baby activity gym.</p>

 <p><b>ingenuity</b> 13122-MEWW</p> <p><b>Sun Valley™</b> Model 13122-MEWW. Mat and arch are made of wood and are not a toy. And d'arche en bois et tapis d'éveil - pas de jouet. Spielzeug aus Holz und Matte sind kein Spielzeug. Arco y alfombra de juguete no son juguetes.</p> <p>ingenuitybaby.com</p>	<p><a href="#"><u>Ingenuity Sun Valley Wooden Toy Arch &amp; Play Mat - Assembly and Safety Guide</u></a></p> <p>Comprehensive guide for the Ingenuity Sun Valley Wooden Toy Arch &amp; Play Mat, including safety warnings, assembly instructions, care, and parts list. Model 13122-MEWW. Suitable for children up to 36 months.</p>
 <p><b>ingenuity</b> 13127</p> <p><b>Prop Spot™ Learn-to-Sit™ - Casi™</b> 3 Peças: Assento - 1 Apoio para os braços - 1 Base 3 Piece(s): Seat - 1 Armrest(s) - 1 Base 3 Piezas: Asiento - 1 Apoyo para los brazos - 1 Base 3 Pezzi: Sedia - 1 Bracciolo - 1 Base</p> <p>ingenuitybaby.com</p>	<p><a href="#"><u>Ingenuity Prop Spot Learn-to-Sit - Casi Floor Seat: User Manual, Safety, and Assembly Guide</u></a></p> <p>This comprehensive guide provides essential information for the Ingenuity Prop Spot Learn-to-Sit - Casi floor seat. It includes detailed safety warnings, assembly instructions, care and cleaning guidelines, and a parts list. Ensure safe use for your child by following these instructions.</p>
 <p><b>ingenuity</b> 13127</p> <p><b>Prop Spot™ Learn-to-Sit™ - Loni™</b> 3 Peças: Assento - 1 Apoio para os braços - 1 Base 3 Piece(s): Seat - 1 Armrest(s) - 1 Base 3 Piezas: Asiento - 1 Apoyo para los brazos - 1 Base 3 Pezzi: Sedia - 1 Bracciolo - 1 Base</p> <p>ingenuitybaby.com</p>	<p><a href="#"><u>Ingenuity Prop Spot Learn-to-Sit - Loni: User Manual, Safety, and Care Guide</u></a></p> <p>Comprehensive user manual for the Ingenuity Prop Spot Learn-to-Sit - Loni baby floor seat. Includes detailed safety warnings, assembly instructions, care and cleaning guidelines, and a parts list. Covers fall hazards, drowning hazards, suffocation risks, and strangulation prevention.</p>