

BaByliss MT728E

BaByliss MT728E Electric Shaver User Manual

Model: MT728E

1. PRODUCT OVERVIEW AND SAFETY INFORMATION

The BaByliss MT728E Electric Shaver is designed for precise grooming of facial hair, including beards and general face areas. This manual provides essential information for the safe and effective use of your device.

Important Safety Warnings

- Use with care to avoid cuts and skin irritation.
- Do not immerse the device in water.
- Avoid using the device near water sources (e.g., bathtubs, showers, sinks).
- Allow the device to dry completely after each use.
- Do not charge the device during use.
- Keep the device and all accessories out of reach of children.

2. PACKAGE CONTENTS

Carefully unpack your BaByliss MT728E Electric Shaver and verify that all components are present and in good condition. The package should contain the following items:

- BaByliss MT728E Electric Shaver unit
- Various trimming guide combs (multiple sizes)
- Nose/ear trimmer attachment
- Precision trimmer attachment
- Cleaning brush
- Lubricating oil
- Charging adapter
- Storage pouch



Figure 2.1: BaByliss MT728E Electric Shaver with all included attachments, including various guide combs, a nose trimmer, and a precision trimmer.



Figure 2.2: Included accessories: charging adapter, cleaning brush, lubricating oil, and a black storage pouch.



Figure 2.3: The retail packaging box for the BaByliss MT728E Electric Shaver.

3. SETUP

3.1 Charging the Device

1. Ensure the shaver is turned off.
2. Connect the charging adapter to the shaver's charging port.
3. Plug the adapter into a suitable electrical outlet.
4. Allow the device to charge fully before first use. Refer to the indicator light for charging status (if applicable).

The BaByliss MT728E is battery-powered and rechargeable, offering cordless convenience once fully charged.

3.2 Attaching and Removing Accessories

To attach a trimming head or guide comb:

1. Ensure the shaver is turned off.
2. Align the desired attachment with the shaver head.
3. Gently push until it clicks securely into place.

To remove an attachment:

1. Ensure the shaver is turned off.
2. Grasp the attachment firmly and pull it away from the shaver head.

4. OPERATING INSTRUCTIONS

The BaByliss MT728E is designed for various grooming needs, including beard trimming, facial hair styling, and general face grooming.

4.1 General Trimming

1. Select the appropriate guide comb for your desired hair length.

2. Turn on the shaver using the power button.
3. Hold the shaver with the blade flat against the skin.
4. Move the shaver slowly against the direction of hair growth for an even trim.
5. For detailing, remove the guide comb and use the bare blade carefully.

4.2 Using the Nose/Ear Trimmer

1. Attach the nose/ear trimmer head to the shaver unit.
2. Gently insert the trimmer tip into the nostril or ear canal.
3. Move the trimmer in a circular motion to remove unwanted hair.
4. Do not insert the trimmer too deeply into the nostril or ear canal.

5. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your BaByliss MT728E Electric Shaver.

5.1 Cleaning the Shaver

1. Ensure the shaver is turned off and disconnected from the charger.
2. Remove any attached guide combs or trimmer heads.
3. Use the provided cleaning brush to remove loose hairs from the blades and inside the shaver head.
4. The blades can be rinsed under running water. Ensure the main body of the shaver does not get wet, as it is not waterproof.
5. Allow all parts to air dry completely before reassembling or storing.



Figure 5.1: Close-up view of the shaver head, highlighting the stainless steel blade for cleaning and maintenance.

5.2 Lubricating the Blades

After cleaning and drying, apply a small drop of the provided lubricating oil to the blades. Turn the shaver on for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.

6. TROUBLESHOOTING

If you encounter issues with your BaByliss MT728E Electric Shaver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on	Battery is depleted	Charge the shaver fully.
Poor trimming performance	Blades are dirty or dull	Clean and lubricate the blades. If dull, consider professional servicing.
Device feels hot during use	Extended continuous use	Turn off the shaver and allow it to cool down before resuming use.
Skin irritation after use	Improper technique or sensitive skin	Ensure proper technique (shaving against hair growth, not pressing too hard). Use pre-shave preparation for sensitive skin.







7. SPECIFICATIONS

- **Brand:** BaByliss
- **Model Name:** MT728E
- **Item Model Number:** 3030050157734
- **Power Source:** Battery Powered (Rechargeable)
- **Blade Material:** Stainless Steel
- **Head Type:** Rotary | Foil
- **Recommended Uses:** Beard, Face, Facial Hair
- **Product Dimensions (L x W x H):** 50 x 50 x 28 cm; 15 grams
- **Manufacturer:** BABYLISS
- **Units:** 1 Total
- **ASIN:** B0813FNPXT
- **Date First Available:** October 21, 2019

8. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please refer to the warranty card included with your purchase or visit the official BaByliss website. You may also contact BaByliss customer service directly for assistance.

For more information about BaByliss products, please visit the [BaByliss Brand Store](#).

	<p><u>BaByliss MT992E Super-X Metal Multitrimmer: User Manual & Comprehensive Grooming Guide</u></p> <p>Get the most out of your BaByliss MT992E Super-X Metal 15-in-1 Multitrimmer with this detailed user manual. Learn about its features, safe operation, charging, attachment usage, cleaning, and maintenance for optimal personal grooming.</p>
	<p><u>BaByliss MT727E Multi-Grooming Kit User Manual</u></p> <p>This manual provides instructions for using the BaByliss MT727E Multi-Grooming Kit, including charging, maintenance, and attachment usage for trimming beards, nose/ear hair, and shaving.</p>
	<p><u>Babylliss MT996E User Manual and Instructions</u></p> <p>Comprehensive user manual and operating instructions for the Babylliss MT996E hair and beard trimmer. Includes details on charging, maintenance, cleaning, and various trimming functions for optimal grooming results.</p>
	<p><u>BaByliss E111E Trimmer: User Manual and Instructions</u></p> <p>Comprehensive user manual and instructions for the BaByliss E111E trimmer, covering safety guidelines, operating procedures, head and battery replacement, and cleaning and maintenance.</p>
	<p><u>Babylliss E652E Nose Trimmer User Guide</u></p> <p>This guide provides instructions for using and maintaining the Babylliss E652E nose, ear, and eyebrow trimmer, ensuring safe and effective operation.</p>
	<p><u>BaByliss OT991E/OT992E/OT996E Cordless Hair and Beard Trimmer User Manual</u></p> <p>This user manual provides comprehensive instructions for the BaByliss OT991E, OT992E, and OT996E cordless hair and beard trimmer. It covers charging, usage, maintenance, safety warnings, and features like waterproofing and travel lock.</p>