

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AILINKE](#) /

› [AILINKE 2.1Gal/8L Ultrasonic Top Fill Humidifier User Manual](#)

AILINKE KC-MH-033

AILINKE 2.1Gal/8L Ultrasonic Top Fill Humidifier User Manual

Model: KC-MH-033

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this humidifier. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the humidifier on a firm, flat, water-resistant surface away from direct sunlight and heat sources.
- Do not block air vents.
- Do not immerse the unit in water or other liquids.
- Unplug the humidifier when not in use or before cleaning.
- Keep out of reach of children and pets.
- Use only clean, cool tap water. Do not use hot water.
- Do not add essential oils directly into the water tank; use the designated essential oil tray.

2. PRODUCT OVERVIEW

The AILINKE 2.1Gal/8L Ultrasonic Top Fill Humidifier is designed to efficiently humidify large rooms up to 500 sq ft, providing continuous operation for up to 48 hours on a single refill. It features customizable humidity levels, multiple mist settings, and a quiet operation suitable for various environments.



Figure 2.1: AILINKE 2.1Gal/8L Ultrasonic Top Fill Humidifier with water splash and lavender.

Healthy Air, Happy Home



500ft² Coverage



8L Large Capacity



48H Runtime



Figure 2.2: The humidifier in a home setting, highlighting its 500 sq ft coverage, 8L capacity, and 48-hour runtime.

3. SETUP AND INITIAL USE

3.1 Unpacking

Carefully remove all packaging materials and ensure all components are present:

- Cool Mist Humidifier x 1
- Remote Control x 1
- User Manual x 1

3.2 Placement

Place the humidifier on a flat, stable surface at least 6 inches (15 cm) away from walls and furniture. Ensure the mist outlet is not directed at walls or furniture to prevent moisture damage.

3.3 Filling the Water Tank

The AILINKE humidifier features a convenient top-fill design:

1. Open the top cover of the humidifier.
2. Pour clean, cool tap water directly into the water tank. Do not exceed the "MAX LEVEL" indicator.
3. Close the top cover securely.



Figure 3.1: Easy top-fill water tank for convenient refilling.

3.4 Essential Oil Tray

To use the aroma diffuser function:

1. Locate the essential oil tray on the side of the humidifier.
2. Add 1-2 drops of your favorite essential oil onto the aroma pad in the tray.
3. Close the tray. The aroma will diffuse with the mist.

Note: Do not add essential oils directly into the water tank, as this may damage the unit.



Figure 3.2: Dedicated essential oil tray for aromatherapy.

4. OPERATING INSTRUCTIONS

The humidifier can be controlled via touch buttons on the unit or the included remote control.

*Breathe in bliss with
aromatic mist*



Figure 4.1: Control panel and remote control for the humidifier.

4.1 Power On/Off

Press the **Power** button on the control panel or remote to turn the unit on or off.

4.2 Mist Level Adjustment

The humidifier offers 3 mist settings: Low, Medium, and High. Press the **Max-Min** button to cycle through the mist levels.



Figure 4.2: Visual representation of Low, Medium, and High mist output settings.

4.3 Constant Humidity Mode (Humidistat)

To set a desired humidity level:

1. Press the **Constant Humidity** button.
2. Use the **Max-Min** button to adjust the target humidity from 40% to 90%.
3. The humidifier will automatically turn on/off to maintain the set humidity level.

4.4 Sleep Mode

Activate Sleep Mode for quiet operation and a dimmed display, ideal for nighttime use.

- Press the **Sleep** button on the control panel or remote.
- The display will turn off, and the unit will operate at a noise level of less than 35dB.

*Embrace Tranquility
Sleep Sweetly*



Sleep Mode



Whisper Quiet



Auto-Off



Figure 4.3: Humidifier operating quietly in sleep mode, suitable for bedrooms and nurseries.

4.5 Timer Function

Set the humidifier to operate for a specific duration:

- Press the **Timer** button.
- Adjust the timer setting from 1 to 12 hours. The unit will automatically shut off after the set time.



Figure 4.4: The humidifier features a timer function for 1 to 12 hours of operation.

4.6 Automatic Shut-Off

The humidifier is equipped with an automatic shut-off feature for safety and convenience:

- The unit will automatically turn off when the desired humidity level is reached in Constant Humidity mode.
- The unit will automatically turn off when the water tank is empty (low water indicator).



Figure 4.5: Waterless auto shut-off protection for safety and extended product life.

5. MAINTENANCE AND CLEANING

Regular cleaning is essential to prevent mineral buildup and ensure optimal performance and hygiene.

5.1 Daily Maintenance

- Empty and rinse the water tank daily.
- Wipe down the mist outlet and exterior surfaces with a clean, damp cloth.

5.2 Weekly Cleaning

1. Unplug the humidifier and empty any remaining water.
2. Separate the top part from the base.
3. Fill the water tank with 1 cup of white vinegar and 1 cup of water. Let it soak for 30 minutes to an hour to loosen mineral buildup.

4. Use a soft brush or cloth to clean the inside of the tank and the ultrasonic transducer (the small disc at the bottom).
5. Rinse all components thoroughly with clean water until the smell of vinegar is gone.
6. Wipe dry and reassemble.

Note: A top review mentions that the wide opening of the tank makes it easy to clean, allowing a hand to reach inside.



Figure 5.1: The wide opening of the water tank facilitates easy cleaning.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Low water level; Mineral buildup on transducer; Unit not properly assembled.	Refill water tank; Clean the ultrasonic transducer; Ensure all parts are correctly assembled.
Unit not turning on	Not plugged in; Power outage; Unit malfunction.	Check power connection; Verify power supply; Contact customer support if issue persists.
Unusual noise	Unit not on a flat surface; Water tank not seated correctly; Foreign object in water.	Place on a stable surface; Re-seat water tank; Check for and remove any foreign objects.
Blinking "88" message (as reported by some users)	Indicates an internal error or sensor issue.	Unplug the unit for 5 minutes, then plug it back in. If the issue persists, contact customer support.

For more detailed troubleshooting or issues not listed here, please refer to the official User Manual PDF or contact AILINKE customer support.

Official User Manual (PDF): [Download PDF](#)

7. SPECIFICATIONS

Feature	Detail
Brand	AILINKE
Model Name	KC-MH-033
Capacity	2.1 Gallons / 8 Liters
Max Mist Output	300mL/h
Coverage Area	Up to 500 Square Feet
Operation Mode	Ultrasonic
Humidity Control	Adjustable (40% to 90%)
Mist Settings	3 (Low, Medium, High)
Noise Level	Less than 35dB
Timer	1-12 Hours
Control Method	Remote, Touch
Special Features	Adjustable Humidity Control, Low Water Indicator, Remote Control, Auto Shut Off, Aroma Diffuser
Product Dimensions	10"D x 10"W x 13"H
Item Weight	3 Pounds
Voltage	120 Volts
Wattage	35 watts
Included Components	Cool Mist Humidifier x 1, Remote Control x 1, User Manual x 1

8. WARRANTY AND SUPPORT

AILINKE stands behind its products with comprehensive support:

- **30-Day Free Replacement:** If you encounter any issues within 30 days of purchase, a free replacement is available.
- **1-Year Warranty:** The humidifier comes with a 1-year warranty for added peace of mind.
- **24-Hour Online Service:** For any assistance, questions, or concerns, AILINKE provides 24-hour online customer service.

For warranty claims or support, please refer to the contact information provided in your user manual or visit the official AILINKE store on Amazon: [AILINKE Store](#)

9. PRODUCT VIDEOS

Watch these official product videos for visual guidance and demonstrations:

No official seller videos are available for embedding at this time.