

[Manuals.plus](#) /

> [PLAYLEARN](#) /

> Playlearn Sensory Bubble Tube: Jumbo Extra Wide 6 Foot Bead Water Tower Instruction Manual

## PLAYLEARN Jumbo Extra Wide 6 Foot Bead Water Tower

# Playlearn Sensory Bubble Tube: Jumbo Extra Wide 6 Foot Bead Water Tower Instruction Manual

Model: Jumbo Extra Wide 6 Foot Bead Water Tower

## 1. INTRODUCTION

The Playlearn Sensory Bubble Tube is a 6-foot tall, extra-wide floor lamp designed to create a calming and stimulating environment. This unit features a clear acrylic tube filled with water and decorative beads that move dynamically with a continuous stream of bubbles. Integrated color-changing LED lights illuminate the column, offering a visually engaging experience. The device is controlled conveniently via a dedicated mobile application, allowing for customization of light colors and effects.

This instruction manual provides essential information for the safe and effective setup, operation, and maintenance of your Playlearn Sensory Bubble Tube.





Image 1.1: The Playlearn Sensory Bubble Tube, showcasing its design and internal bead movement.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

Please read and understand all safety instructions before operating this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Read All Instructions:** Familiarize yourself with the entire manual before assembly and use.
- **Electrical Safety:**
  - Use only the power adapter supplied with the unit.
  - Do not immerse the power adapter or any electrical components in water.
  - Ensure hands are dry when plugging or unplugging the unit.
  - Keep the power cord away from heat sources, sharp edges, and wet areas.
  - If the power cord or adapter is damaged, discontinue use immediately and contact support.
- **Water Safety:**
  - Use distilled water to prevent mineral buildup and maintain clarity.
  - Do not overfill the tube.
  - In case of leakage, unplug the unit immediately and contact support.
- **Placement:**
  - Place the bubble tube on a stable, level, and sturdy surface to prevent tipping.
  - Keep the unit away from direct sunlight, extreme temperatures, and heat sources.
  - Ensure adequate space around the unit for ventilation and to prevent accidental knocking.
- **Children and Pets:**
  - This product is not a toy. Adult supervision is required when children or pets are near the unit.
  - Keep small parts, such as decorative beads, out of reach of young children to prevent choking hazards.
- **Handling:**
  - Do not attempt to move the unit when it is filled with water.
  - Avoid dropping or subjecting the unit to strong impacts.

### 3. PACKAGE CONTENTS

---

Please verify that all components are present and undamaged before proceeding with assembly.

- Playlearn Sensory Bubble Tube Unit (Acrylic tube, base, and top)
- Power Adapter
- Decorative Beads (may be pre-inserted or packaged separately)
- Instruction Manual (this document)

### 4. SETUP INSTRUCTIONS

---

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Select a stable, level, and dry location for the bubble tube, away from direct sunlight, heat sources, and areas where it might be easily knocked over. Ensure the power outlet is within reach of the power adapter cord.
3. **Fill with Water:**
  - Remove the top cap of the bubble tube.
  - Slowly fill the tube with distilled water. Fill up to approximately 1 inch (2.5 cm) below the top edge of the tube.

Do not overfill.

- Using distilled water is highly recommended to prevent mineral deposits and maintain water clarity over time.

4. **Add Beads:** If the decorative beads are not pre-inserted, carefully pour them into the water-filled tube.
5. **Secure Top Cap:** Replace the top cap securely onto the bubble tube.
6. **Connect Power:** Insert the small end of the power adapter into the power input port located on the base of the bubble tube. Plug the other end of the power adapter into a standard electrical outlet.
7. **Download App:** Download the "Playlearn" application from your device's app store (e.g., Apple App Store or Google Play Store).
8. **Initial Power On:** The unit may automatically power on and begin bubbling and illuminating. If not, use the app to turn it on.



Image 4.1: The Playlearn Sensory Bubble Tube in a room, illustrating its presence and scale.

## 5. OPERATION

The Playlearn Sensory Bubble Tube is controlled wirelessly via the dedicated Playlearn mobile application.

1. **Launch App:** Open the Playlearn app on your smartphone or tablet.
2. **Connect:** The app should automatically detect and connect to your bubble tube. If not, follow the in-app instructions to pair your device.
3. **Power On/Off:** Use the designated button within the app to turn the bubble tube on or off.
4. **Adjust Lighting:**
  - **Color Selection:** Choose from a wide spectrum of colors to illuminate the bubble tube.
  - **Lighting Modes:** Select various dynamic lighting modes, such as fading, flashing, or pulsing effects.
  - **Brightness Control:** Adjust the intensity of the LED lights to suit your preference.
  - **Speed Control:** For dynamic modes, adjust the speed at which colors change or effects occur.
5. **Adjust Bubbles:** The app may offer controls to adjust the intensity or frequency of the bubbles. Refer to the app interface for specific options.

**Visual Effect:** Once activated, the internal pump will generate a continuous stream of bubbles, causing the decorative beads to rise and fall within the water column. The LED lights will cycle through selected colors or maintain a static color, creating a mesmerizing and calming visual display.



Image 5.1: The Playlearn Sensory Bubble Tube creating a calming ambiance in a living space.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Playlearn Sensory Bubble Tube.

- **Exterior Cleaning:**

- Unplug the unit before cleaning.
- Wipe the exterior of the tube and base with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the acrylic and finish.

- **Water Replacement:**

- It is recommended to replace the water every 3-6 months, or sooner if the water appears cloudy or discolored.
- To replace water, unplug the unit, carefully remove the top cap, and use a siphon pump or tilt the unit (with assistance, if necessary) to drain the water into a suitable container.

- Refill with fresh distilled water as per setup instructions.
- **Internal Cleaning (Advanced):** If the internal components, such as the pump or air stone, become clogged or show significant buildup, contact customer support for guidance. Do not attempt to disassemble the unit without professional advice.
- **Storage:** If storing the unit for an extended period, drain all water, clean the unit thoroughly, and store it in its original packaging in a cool, dry place.

## 7. TROUBLESHOOTING

If you encounter issues with your Playlearn Sensory Bubble Tube, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on.	Power adapter not connected. Outlet not functioning. App not connected or unit is off in app.	Ensure power adapter is securely plugged into the unit and wall outlet. Test the outlet with another device. Open the Playlearn app and ensure the unit is powered on.
No bubbles or weak bubbles.	Water level too low. Air pump or air stone obstructed. Pump malfunction.	Check water level and refill with distilled water if necessary. Unplug the unit, gently shake it to dislodge any obstructions. If problem persists, contact support. Contact customer support for further assistance.
Lights are not changing color or are stuck on one color.	App connection issue. App settings.	Ensure your device is connected to the bubble tube via the Playlearn app. Check the lighting mode and color settings within the app. Try selecting a different mode or color.
Water leakage.	Loose cap or seal. Damage to the tube.	Unplug the unit immediately. Check if the top cap is securely fastened. Inspect the tube for any visible cracks or damage. Contact customer support.

If the problem persists after attempting these solutions, please contact Playlearn Customer Support.

## 8. PRODUCT SPECIFICATIONS

Feature	Detail
Model	Jumbo Extra Wide 6 Foot Bead Water Tower
Brand	PLAYLEARN

Feature	Detail
Product Dimensions	12 x 12 x 71 inches (Diameter x Diameter x Height)
Height	6 feet (180 cm)
Width (Diameter)	12 inches
Item Weight	33 pounds (empty)
Control Method	APP Controlled
ASIN	B0813Y8GDN
Manufacturer	Playlearn

## 9. WARRANTY INFORMATION

Playlearn offers a **1-year warranty** on all its products from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper maintenance.

To initiate a warranty claim, please contact Playlearn Customer Support with your proof of purchase and a description of the issue.

## 10. CUSTOMER SUPPORT

For any questions, technical assistance, or warranty inquiries, please contact Playlearn Customer Support:

**Email:** [SUPPORT@PLAYLEARN.COM](mailto:SUPPORT@PLAYLEARN.COM)

**Phone:** [1.888.575.0638](tel:1.888.575.0638)

**Online Store:** [Visit the PLAYLEARN Store on Amazon](#)

Our customer service team is available to assist you with any product-related concerns.

