

[Manuals.plus](#) /

› [Genius](#) /

› Genius SW-G2.1 1250 2.1 Channel Speaker System User Manual

Genius SW-G2.1 1250

Genius SW-G2.1 1250 2.1 Channel Speaker System User Manual

Model: SW-G2.1 1250

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Genius SW-G2.1 1250 2.1 channel speaker system. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.



Image: The Genius SW-G2.1 1250 speaker system, featuring a central subwoofer, two satellite speakers, and a separate control unit.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Subwoofer (1 unit)
- Satellite Speakers (2 units)

- Control Unit (1 unit)
- Audio Cables (3.5mm to 3.5mm, 3.5mm to 2RCA)
- User Manual (this document)

SETUP INSTRUCTIONS

Follow these steps to connect your speaker system:

1. **Positioning:** Place the subwoofer on a stable surface, preferably on the floor. Position the satellite speakers on either side of your listening area, facing you.
2. **Connect Satellite Speakers:** Connect the cables from the satellite speakers to the "LEFT" and "RIGHT" speaker output jacks on the back of the subwoofer. Ensure correct polarity if applicable (though typically color-coded or keyed).
3. **Connect Control Unit:** Connect the multi-pin cable from the control unit to the corresponding port on the back of the subwoofer.
4. **Audio Input Connection:**
 - **Option 1 (3.5mm AUX):** Use the 3.5mm audio cable to connect the "AUX" input on the control unit to the headphone jack or audio output of your computer, MP3 player, or other audio device.
 - **Option 2 (2RCA):** Use the 3.5mm to 2RCA cable to connect the "INPUT" RCA jacks (red for right, white for left) on the control unit to the audio output of game consoles, DVD players, or TVs.
5. **Power Connection:** Plug the power cord from the subwoofer into a standard electrical outlet.

SW-G2.1 1250



For audio output, plug in the left and right RCA speaker cables and sub-woofer cable to the back of the control unit.

For audio input:



Option 1:
Use the **3.5mm AUX** audio cable to listen to your PC computer, MAC, iPod/iPad, MP3 player or any electronic device.



Option 2:
Use the **3.5mm jack to RCA** cables to listen to your PC computer, MAC, iPod/iPad, MP3 player or any electronic device.

www.geniusnet.com

Gx Gaming Series By Genius

Image: Connection diagram illustrating how to connect the subwoofer, satellite speakers, control unit, and various audio input sources (3.5mm AUX and RCA) to the Genius SW-G2.1 1250 system.

The control unit provides easy access to essential functions:

- **Power On/Off:** Use the main power knob on the control unit to turn the system on or off.
- **Volume Control:** Rotate the large knob on the control unit to adjust the overall volume.
- **Bass Adjustment:** Use the dedicated bass knob on the control unit to increase or decrease the subwoofer's bass output.
- **Headphone Jack:** Connect headphones to the 3.5mm headphone jack on the control unit for private listening. This will mute the speakers.
- **Microphone Jack:** Connect a microphone to the 3.5mm microphone jack on the control unit for communication, such as during online gaming.



Image: The Genius SW-G2.1 1250 system components, highlighting the control unit's accessible front panel with volume and bass controls, as well as headphone and microphone jacks.

MAINTENANCE

To ensure the longevity and optimal performance of your speaker system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the speakers and control unit. Do not use liquid cleaners or abrasive materials.
- **Placement:** Avoid placing the speakers in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Keep cables organized and free from kinks or excessive bending to prevent damage.
- **Power Off:** Turn off the speaker system when not in use for extended periods.

TROUBLESHOOTING

If you encounter issues with your speaker system, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound	Power not connected	Ensure power cord is securely plugged in and system is turned on.
	Volume too low	Increase volume on the control unit and source device.
	Incorrect audio input	Verify audio cables are correctly connected to the appropriate input.
	Headphones connected	Disconnect headphones from the control unit.
Distorted sound	Volume too high	Reduce volume on the control unit and source device.
	Poor audio source quality	Test with a different audio source or file.
No bass	Bass knob set too low	Increase the bass level using the bass knob on the control unit.
	Subwoofer not connected	Ensure the control unit is properly connected to the subwoofer.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Technical specifications for the Genius SW-G2.1 1250 speaker system:

- **Model Name:** SW-G2.1 1250
- **Speaker Type:** 2.1 Channel (Subwoofer, Satellite)
- **Total Output Power:** 38 Watts (RMS)
- **Subwoofer Driver:** 5.25 inches, MDF wooden cabinet
- **Satellite Speaker Drivers:** 3 inches, magnetically-shielded
- **Connectivity:** Auxiliary (3.5mm), 2RCA
- **Input/Output Jacks:** 3.5mm Audio-in, 3.5mm Headphone, 3.5mm Microphone
- **Controls:** Volume, Bass
- **Power Source:** Corded Electric
- **Material:** Wood (subwoofer)
- **Color:** Black, Red accents
- **Package Dimensions:** 41.91 x 27.94 x 26.92 cm
- **Weight:** 4.56 kg

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Genius website. Keep your proof of purchase for warranty claims.

Online Resources: For additional support and product information, visit www.geniusnet.com.

© 2023 Genius. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question