

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Faber](#) /

› [Faber Hobtop Utopia HT783 CRS BR CI AI 3 Burner Gas Hob Instruction Manual](#)

Faber HT783 CRS BR CI AI

Faber Hobtop Utopia HT783 CRS BR CI AI 3 Burner Gas Hob Instruction Manual

Model: HT783 CRS BR CI AI (106.0593.526)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Faber Hobtop Utopia HT783 CRS BR CI AI 3 Brass Burner Auto Electric Ignition Glass Top. Please read these instructions carefully before installation and operation, and retain them for future reference.

What's in the Box

- Faber Hobtop Utopia HT783 CRS BR CI AI
- Instruction Manual
- Warranty Card

IMPORTANT SAFETY INFORMATION

Always prioritize safety when using any gas appliance. Failure to follow these safety guidelines can result in serious injury or damage.



Image Description: A graphic titled "5 TIPS TO SAFELY USE YOUR GLASS-TOP GAS STOVE". It shows: 1. Don't put hot vessels directly on the glass surface. 2. Don't use abrasive cleaning pads, use a soft cloth. 3. Avoid using oversized pans, use correct pan support trivet. 4. Don't put water or wet cloth on hot glass surface, wait for it to cool. 5. Don't use Tandoor Cooker/Baati if it covers the burner trivet entirely and touches the glass.

- Ensure proper ventilation in the kitchen.
- Do not leave cooking unattended.
- Keep flammable materials away from the hob.
- In case of a gas leak, turn off the gas supply immediately, open windows, and do not operate electrical switches.
- Always use appropriate cookware sizes for the burners.

PRODUCT OVERVIEW

The Faber Hobtop Utopia HT783 is designed for efficient and safe cooking. It features a toughened glass top and brass burners with auto electric ignition.



Image Description: An overhead view of the Faber Hobtop Utopia HT783 gas hob, highlighting its features: Flame Failure Device, 4 KW Triple Ring Burner, Auto Ignition, Cast Iron Pan Support, and Premium Metal Knobs.

Key Features

- **Burners:** 3 brass burners with black enamel coating, including 1 x 4 kW triple ring dual flame burner, 1 x 3 kW mini triple ring, and 1 x 1.7 kW double ring burner.
- **Ignition:** In-built auto electric ignition, AC 230V power operated.
- **Safety:** Equipped with a Flame Failure Device (FFD) for superior safety, automatically cutting off gas supply if the flame extinguishes.
- **Pan Support:** Heavy cast iron pan supports designed for maximum stability for Indian cookware.
- **Surface:** 8 mm thick toughened glass top for durability and easy cleaning.
- **Knobs:** Heat-resistant premium metal knobs, suitable for longer cooking durations.
- **Versatility:** Can be used as a hobtop or built-in as per installation requirements.



Image Description: Left: Close-up of the three golden-colored premium metal control knobs. Right: Close-up of a single brass burner with its cast iron pan support.

INSTALLATION

The Faber Hobtop Utopia HT783 can be used as a freestanding hob or integrated into your kitchen countertop. Professional installation is highly recommended to ensure safety and proper functioning.

Pre-Installation Checks

- Verify that the gas supply type (LPG/PNG) matches the hob's configuration.
- Ensure adequate ventilation in the installation area.
- Check the electrical supply for the auto-ignition (AC 230V).
- Confirm countertop cutout dimensions if built-in installation is planned. Granite Cut (W*D) - 75 x 475 mm.

Installation Steps (Summary)

1. Position the hob: Place the hob on a stable, level surface or insert it into the countertop cutout.
2. Connect gas supply: Securely connect the gas inlet to the household gas supply using appropriate fittings. Check for leaks.
3. Connect electrical supply: Plug the hob into a grounded AC 230V power outlet for the auto-ignition.
4. Place pan supports and burners: Ensure all burner components and pan supports are correctly seated.
5. Test operation: Turn on the gas supply and test each burner for proper ignition and flame.

For detailed installation instructions, refer to the dedicated installation section in the full manual provided with the product or consult a qualified technician.

OPERATING INSTRUCTIONS

Igniting a Burner

1. Ensure the gas supply is open.
2. Push down the desired burner knob and turn it counter-clockwise to the ignition position (usually marked with a flame symbol).
3. Hold the knob down for a few seconds until the flame ignites. The auto-electric ignition will spark automatically.
4. Once ignited, release the knob. If the flame extinguishes, repeat the process.
5. Adjust the flame intensity by turning the knob between the high and low flame settings.

Turning Off a Burner

To turn off a burner, turn the knob clockwise to the "OFF" position. Ensure the flame is completely extinguished.

Flame Failure Device (FFD)

Your hob is equipped with an FFD. If the flame accidentally goes out (e.g., due to a draft or spillage), the FFD will automatically cut off the gas supply to that burner, preventing gas leakage. When igniting, you must hold the knob down for a few seconds to allow the FFD sensor to heat up and register the flame.

MAINTENANCE & CLEANING

Regular cleaning and maintenance will prolong the life of your hob and ensure safe operation.

General Cleaning

- Always ensure the hob is cool before cleaning.
- Disconnect from the electrical supply and turn off the gas supply.
- Use a soft cloth and mild detergent for general cleaning.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals that can damage the glass or metal surfaces.

Glass Top Care

- Do not place hot vessels directly on the glass surface after cooking; allow the hob to cool.
- Avoid spilling cold water or placing wet cloths on the hot glass surface, as this can cause thermal shock.
- Clean spills immediately once the hob has cooled to prevent staining.

Burners and Pan Supports

- Remove pan supports and burner caps/crowns for cleaning.
- Wash them with warm soapy water. For stubborn stains, a non-abrasive scrubber can be used.
- Ensure all parts are completely dry before reassembling them. Moisture can affect ignition.
- Periodically check burner holes for blockages and clean them with a fine wire or needle if necessary.

TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply; Power outage (for auto-ignition); Burner components wet or clogged; Ignition pin dirty.	Check gas cylinder/pipeline; Check power supply; Dry and clean burner parts; Clean ignition pin.
Flame is weak or uneven	Burner holes clogged; Low gas pressure.	Clean burner holes; Contact gas provider to check pressure.

Problem	Possible Cause	Solution
Flame extinguishes after releasing knob	FFD sensor not heated sufficiently; FFD malfunction.	Hold knob down longer (5-10 seconds); Contact service if issue persists.
Knobs become hot during cooking	Normal during prolonged cooking; Oversized vessels.	Use appropriate sized vessels; Exercise caution when touching knobs.

If the problem persists after attempting these solutions, please contact Faber customer support.

SPECIFICATIONS

Feature	Detail
Brand	Faber
Model Number	HT783 CRS BR CI AI (106.0593.526)
Burners	3 Brass Burners (1x 4kW Triple Ring, 1x 3kW Mini Triple Ring, 1x 1.7kW Double Ring)
Ignition Type	Auto Electric Ignition (AC 230V)
Top Material	8 mm Toughened Glass
Pan Support	Heavy Cast Iron
Safety Feature	Flame Failure Device (FFD)
Product Dimensions (L x D x H)	78 x 52.5 x 14.5 cm
Granite Cut Dimensions (W x D)	75 x 47.5 cm
Item Weight	19.9 kg
Color	Black
Power Source	Electric (for ignition)
Fuel Type	Gas

WARRANTY & CUSTOMER SUPPORT

Your Faber Hobtop Utopia HT783 comes with a **1-year manufacturer warranty** from the date of purchase. Please retain your purchase receipt and warranty card for any claims.

For technical assistance, service requests, or warranty claims, please contact Faber customer support. Contact details can be found on your warranty card or the official Faber website.

PRODUCT VIDEO OVERVIEW

Your browser does not support the video tag.

Video Description: An official product video providing a visual overview of the Faber Hobtop Utopia HT783 gas hob, showcasing its design, features, and functionality.



© 2024 Faber. All rights reserved. This manual is for informational purposes only.