

Tuanzi Moyan X12 Pro

Tuanzi Moyan X12 Pro True Wireless Earbuds User Manual

Model: Moyan X12 Pro

1. INTRODUCTION

Thank you for choosing the Tuanzi Moyan X12 Pro True Wireless Earbuds. These earbuds feature advanced Bluetooth 5.0 technology, delivering clear 3D sound and a comfortable fit. Designed for extended use, they offer a week's endurance with the included charging case, making them ideal for iPhone, Samsung, iPad, and Android devices. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Moyan X12 Pro Wireless Earbuds
- Magnetic Charging Case
- Smooth Carrying Bag
- USB Charging Cable
- Silicone Ear Caps
- User Manual (this document)

3. PRODUCT OVERVIEW

The Moyan X12 Pro earbuds are designed for superior audio experience and ease of use. Below are key components and features:

Earbuds and Charging Case



This image shows the Tuanzi Moyan X12 Pro True Wireless Earbuds in their compact white magnetic charging case. One earbud is shown outside the case, highlighting its design. The earbuds feature a unique blue and white pattern.


Key Features

SPORT WIRELESS HEADSET

HD high-definition sound quality



**Ergonomic
design**



**Intelligence
chip**



**Noise
reduction**



**IPX 5 Level
waterproof**



Customizable

This graphic illustrates the main features of the earbuds, including ergonomic design for comfortable fit, an intelligence chip for enhanced performance, noise reduction technology for clear audio, IPX5 level waterproofing for sweat and splash resistance, and customizable options.

Function Buttons and Indicators



This diagram points out the function button on the earbud for various controls, the indicator light for charging status and connection, and the built-in microphone. It also shows the power indicator light on the charging case.

Bluetooth 5.0 and Smart Boot

**Dreamy Color
More Choices Of Color**

Starry Sky(Black) 01

blue

02

gemstone

03



Moonlight (White) 04



Here with you (Pink) 05




Blooming (Green) 06



Fantasy 07



Flame 08



Ice Soul 09



Dancer 10



Here with you 11



Blooming 12

This image emphasizes the Bluetooth 5.0 chip for stable and low-power connection, and the "Smart Boot" feature, which allows the earbuds to automatically turn on and connect to your device when removed from the charging case.

4. SETUP AND PAIRING

4.1 Initial Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically turn on.

3. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
4. Search for "Moyan X12 Pro" or similar in the list of available devices.
5. Select the earbuds to pair. Once paired, you will hear a confirmation sound.


4.2 Automatic Connection

After the first successful pairing, the earbuds will automatically turn on and connect to your last paired device when taken out of the charging case. Each earbud can also pair separately if needed.

4.3 Charging the Earbuds and Case

The earbuds charge automatically when placed inside the magnetic charging case. The case itself is charged via a USB cable.

Sport Wireless Headset



more than 6 hours
listening and calling



40-60min fast
charging



4 time full
charge



stand-by time
150 hours

This image shows the earbuds being charged within the magnetic charging case, highlighting the charging process and indicating that the case provides multiple full charges for extended listening time.


5. OPERATING INSTRUCTIONS

The Moyan X12 Pro earbuds feature intuitive touch controls for various functions:

Action	Function
L/R short press (single-click)	Play/Pause, Answer/Hang up call
L/R long press 2 seconds	Turn on earbuds, Activate Siri/Android Voice Assistant
L/R long press 4 seconds	Turn off earbuds
L press 2 times (double-click)	Volume down
R press 2 times (double-click)	Volume up
L press 3 times (triple-click)	Next song
R press 3 times (triple-click)	Last song

For a visual guide on controls, please refer to the diagram below:





This image provides a detailed diagram of the touch controls on the earbuds, illustrating how single, double, and triple clicks, as well as long presses, correspond to different functions like play/pause, volume adjustment, track skipping, and activating voice assistants.

5.1 Official Product Video

Your browser does not support the video tag.

This video demonstrates the features and usage of the Sabbath X12 PRO 3D Clear Sound True Wireless Earbuds, including their design and how they function. The video duration is 29 seconds.

6. MAINTENANCE AND CARE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX5 level waterproof, meaning they are resistant to sweat and splashes. Do not submerge them in water or expose them to heavy rain.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Silicone Ear Caps:** Ensure the silicone ear caps are properly fitted for optimal sound quality and comfort. Clean them periodically with water and mild soap, then dry thoroughly before reattaching.

7. TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget the device in Bluetooth settings and re-pair.

Problem	Possible Solution
Only one earbud working	Place both earbuds back in the case, close the lid, wait a few seconds, then open again. Ensure both are charged.
Low volume or poor sound quality	Adjust volume on both earbuds and connected device. Ensure ear caps are clean and properly fitted. Check for debris in earbud nozzles.
Charging case not charging	Ensure USB cable is securely connected to both the case and power source. Try a different USB cable or power adapter.
Earbuds frequently disconnect	Ensure you are within the Bluetooth range of your device. Avoid strong electromagnetic interference. Try re-pairing.

8. SPECIFICATIONS

Feature	Detail
Model	Moyan X12 Pro
Bluetooth Version	5.0
Impedance	32Ω
Input	DC 5V
Sensitivity	120±5dB
Earbud Battery Capacity	3.7V/60mAh
Charge Case Capacity	3.7V/750mAh
Charging Time	1 hour
Calling / Playback Time	6 hours (earbuds), 30+ hours (with charging case)
Frequency Response	20-20000Hz
Profile Support	HSP/HFP/A2DP/AVRCP
Water Resistance Level	IPX5
Manufacturer	Sabbat

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Tuanzi store online. You can find more information at the [Tuanzi Store](#).
For further assistance, please contact Tuanzi customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question