

Ingenico Move3500

Ingenico Move3500 Base Charger User Manual

Model: Move3500 Base Charger

1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Ingenico Move3500 Base Charger. Please read this manual thoroughly before using the device to ensure safe and efficient operation.

2. SAFETY INFORMATION

- Ensure the charger is connected to a power source that matches the voltage requirements specified on the power adapter.
- Do not expose the charger to water, excessive moisture, or extreme temperatures.
- Avoid dropping or subjecting the charger to severe impacts.
- Do not attempt to disassemble or modify the charger. Refer all servicing to qualified personnel.
- Keep the charger away from flammable materials.

3. PACKAGE CONTENTS

Verify that the following item is included in your package:

- Ingenico Move3500 Base Charger (Main Unit)

Note: The power adapter for the base charger is typically sold separately or included with the Move3500 terminal. Ensure you have the correct power adapter for operation.

4. SETUP

1. **Unpack the Charger:** Carefully remove the Ingenico Move3500 Base Charger from its packaging.
2. **Connect Power:** Locate the 2-pin power input port on the base charger. Connect the appropriate power adapter (not included) to this port, then plug the power adapter into a standard electrical outlet.
3. **Place the Terminal:** Gently place your Ingenico Move3500 payment terminal onto the base charger. Ensure the terminal's charging contacts align correctly with the magsafe connector on the base. The

terminal should sit securely in the base.



Image: The Ingenico Move3500 Base Charger, a black, compact unit designed to hold and charge the Move3500 payment terminal. It features a recessed area for the terminal and a magsafe-style charging connector.

Once the terminal is correctly seated, it should begin charging. Refer to your Move3500 terminal's manual for specific charging indicators.

5. OPERATING INSTRUCTIONS

The Ingenico Move3500 Base Charger is designed for simple operation:

- **Charging:** To charge your Move3500 terminal, simply place it onto the base charger, ensuring a firm connection. The terminal's display or indicator lights will confirm that charging has commenced.
- **Removal:** To remove the terminal, lift it gently from the base.
- **Continuous Power:** The base can provide continuous power to the terminal when docked, allowing for extended use without battery drain.

6. MAINTENANCE

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry, lint-free cloth to wipe the exterior of the base. Do not use liquid cleaners, aerosols, or solvents.
- **Storage:** When not in use for extended periods, store the charger in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspect Connections:** Periodically check the power cable and charging contacts for any signs of damage or wear.

7. TROUBLESHOOTING

- **Terminal Not Charging:**
 - Ensure the power adapter is securely plugged into both the base charger and the electrical outlet.
 - Verify that the electrical outlet is functional.
 - Check that the Move3500 terminal is correctly seated on the base, with charging contacts aligned.
 - Inspect the charging contacts on both the terminal and the base for any debris or damage.
- **Intermittent Charging:**
 - Ensure the base is on a stable, flat surface to prevent the terminal from shifting.
 - Clean the charging contacts on both devices.

If problems persist, contact Ingenico customer support or your service provider.



8. SPECIFICATIONS

Brand	Ingenico
Model	Move3500 Base Charger
Connector Type (to terminal)	Magsafe
Total USB Ports	1
Main Power Connector Type	2 Pin
UPC	746175940702
ASIN	B08174BVTX
Manufacturer	Ingenico

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your Ingenico Move3500 payment terminal or visit the official Ingenico website. You may also contact your product reseller for assistance.

Related Documents - Move3500

	Ingenico AXIUM DX8000-BASE-C User Guide User guide for the Ingenico AXIUM DX8000-BASE-C payment terminal base, detailing product introduction, specifications, installation procedures, and operating information.
	Ingenico AXIUM DX8000-BASE-W2 User Guide User guide for the Ingenico AXIUM DX8000-BASE-W2 base station, covering setup, management, operating modes, and troubleshooting.




[\[pdf\]](#) User Manual Quick Start Guide Guide

Microsoft Word DIV434787A docx apurves move3500 quick start guide gems cdn ingenico binaries content assets uk website |||

Quick Start Guide **Move3500** GETTING STARTED Set up your charging base unit in a convenient location close to a power source. Your terminal will automatically pick-up the best available mobile network. However, if required, you may manually select a network in order for the terminal to always connect...

lang:en **score:42** filesize: 849.21 K page_count: 4 document date: 2017-05-25



[\[pdf\]](#) Guide

Microsoft Word DIV434807B x053 Move3500 User Guide docx SChristensen cdn ingenico 3djh Oryh 8vhu *xlgh rs uljkw qjhlqr qwurgxfwlqr 7kdqn rx iru fkrvqlj dq sd phqw whuplqdo h uhfrpphqg wkdw fduhixoo uhdg wklv xvhu xjlgh w jlyhv wkh div434807b move3500 user guide tms matsu binaries content assets uk website guides |||

Terminal User Guide Move/3500 Table of contents Introduction to provide you with appropriate advice. External connection All external circuits connected to the **Move3500** must be SELV Safety Extra Low Voltage and LPS limited power source within the meaning o...

lang:tl **score:37** filesize: 3.07 M page_count: 102 document date: 2019-02-19



[\[pdf\]](#) User Manual Guide

Nets Quick Guide Payment Terminal Viking 07 19 2724 indd Bohemian viking quick guide assets ctfassets net t9oyr33fsyh2 5rflkqAF3MzKul9utwC8YF c758bbf5e1cc415ca237116d2fb5e821 ||| Quick Guide Payment Terminals Hurtigguide Betalingsterminaler Hurtigveiledning Betalingsterminaler S ... e. Read Chip reader more about offline transactions at nets.eu/payments/contact-us CLEAR yellow **Move3500** Power supply cable Charging unit/base station Battery Network cable BT Receipt roll ...

lang:en **score:37** filesize: 783.44 K page_count: 17 document date: 2020-04-07



[Ingenico Move 3500 User Guide](#)

Comprehensive user guide for the Ingenico Move 3500 payment terminal, covering setup, operation, safety, and troubleshooting procedures.

lang:en score:36 filesize: 5.46 M page_count: 32 document date: 2022-09-29



[\[pdf\] Guide](#)

Microsoft Word DIV434765A.docx apurves Move 3500 User Guide Ingenico Terminal will print the merchant receipt Cardholder to enter PIN code and press Press if printout is readable else move3500

user guide gems ingenico co uk binaries content assets website guides Telium TETRA cdn |||

Move/3500 Telium TETRA Table of contents Table of contents

..... 2 Introduction

..... 6 Contents of box

...


lang:en score:36 filesize: 8.43 M page_count: 80 document date: 2017-05-24



[Ingenico Desk/5000 Payment Terminal User Guide](#)

Comprehensive user guide for the Ingenico Desk/5000 payment terminal, covering setup, transaction processing, system management, and troubleshooting.

lang:en score:35 filesize: 3.91 M page_count: 88 document date: 2019-02-19



[pdf] Confidentiality Request Letter

Donald PYPER Worldline X059 Move3500 User Guide V13 cdn bfldr WO4S5JJO at vxnfrt6w9zj6fm4shv6zkqp |||

Page 1 of 79 Move/3500 User Guide Status Author: Document date: Classification: Version: Draft Dav ... g points Serial connection ports Telephone Power socket socket The base for Wi-Fi only or GPRS **Move3500s** terminals is charging only so does not have the ports detailed in Picture 1 above. 3.7 Co...

lang:en score:35 filesize: 4.35 M page_count: 79 document date: 2024-04-10



[pdf] Guide

Microsoft Word DIV434765A docx apurves Telium TE TRA move3500 user guide evopayments co uk ||| Move/3500 Telium TETRA Table of contents Table of contents

..... 2 Introduction
..... 6 Contents of box
...

lang:en score:32 filesize: 1.19 M page_count: 77 document date: 2019-04-26




[pdf]

Move3500 1 giorno fa — Connect via Bluetooth WiFi or 3G L Optimise revenue opportunities with 24 7 wireless connectivity Reinvent mobile payment using a compact sized device 23 hours ago Ingenico Terminal approvedbusiness co uk Files CompanyPdfFiles 114792 |||

Move3500 Accept any payment while on-the-go L Leverage Telium applications on the next-generation payment terminal. L Make NFC payment a seamless consumer experience. L Bring mobile payment to your POS with the most connected terminal. Connect via Bluetooth, WiFi or 3G. L Optimise revenue opportunit...


lang:en score:31 filesize: 273.51 K page_count: 2 document date: 2020-05-19



[Ingenico Move/5000 Payment Terminal User Guide](#)

A comprehensive guide for the Ingenico Move/5000 payment terminal, covering setup, operation, transaction processing, reporting, and security. Learn about contactless payments, card handling, and terminal management.

lang:en score:30 filesize: 3.98 M page_count: 91 document date: 2019-02-19




[\[pdf\] Quick Start Guide Guide Diagram](#)

Donald PYPHER Microsoft X059 Move Series Quick Start Guide V10 cdn bflr WO4S5JJO at pvj3rhg4jk3kqv2z3kqgpm54 |||

Quick Start Guide Move Series GETTING STARTED Set up your base unit in a convenient location close t ... ur terminal it may come with one of the two following keypad layouts. Arrow Keys: These keys on the **Move3500** are used to navigate up and down menu options on the screen. Function Keys: For the...

lang:en score:29 filesize: 999.99 K page_count: 11 document date: 2024-08-21



[\[pdf\] Instructions Troubleshooting Guide Guide Declaration of Conformity](#)

Carla Sandbakken Maksupäätteet Nets PA DSS Implementation Guide v5 4 for Viking 8 2 0 assets ctfassets net uxru22fwd1p 7BfE9qjleOiSV0TiQW0TOU e0faa6f84deef794021c8eda0c80f38e |||

Nets Denmark A/S: PA-DSS Implementation Guide for Viking terminal V8.2.0 Version 5.4 PA-DSS Implemen ... mobile ECR to PTS Host Comm Type Ethernet BT Android via ECR GPRS Wifi ECR Comm Type= BT Android **Move3500**, iWL250B **Move3500**, Link2500, Link2500i, iWL250B **Move3500**, Link2500, Link2500i, iWL250B, iSM...

lang:en score:29 filesize: 419.38 K page_count: 24 document date: 2022-04-06



[\[pdf\]](#) Guide

Microsoft Word DIV434765A docx craig jones Move3500 user guide Terminal support ingenico move3500
 userguide a storyblok f 274328 x 5cae634f33 |||

123456788 9 99 # # * 2,-

47.74////////////////////////////////////5

77////////////////////////////////////1

747.,72////////////////////////////////...

lang:i-klingson **score:28** filesize: 9.52 M page_count: 80 document date: 2017-11-30



[Ingenico Move 3500 User Guide: Setup, Operation, and Maintenance](#)

A comprehensive user guide for the Ingenico Move 3500 payment terminal, detailing its features, setup procedures, card reading capabilities, battery management, paper roll installation, safety recommendations, and troubleshooting tips.

lang:en **score:28** filesize: 5.76 M page_count: 20 document date: 2023-01-02



[\[pdf\]](#) User Manual Guide

900019007 R11 000 09 MOVE 3500 indd User Manual MOVE3500 part 1 INGENICO M5000CL4GWI
 XKB XKBM5000CL4GWI m5000cl4gwi

Move 3500 User Guide Optional www.ingenico.com 28-32, boulevard de Grenelle,
 75015 Paris - France / T 33 0 1 58 01 80 00 / F 33 0 1 58 01 91 35 Ingenico - SA au
 capital de 47 656 332 / 317 218 758 RCS Nanterre Contents 1_Introduction 4
 2_Presentation 5 2_1 Content of the box 5 2_1_1...

lang:en **score:28** filesize: 5.76 M page_count: 20 document date: 2022-12-14




[\[pdf\]](#) User Manual Catalog

900019007 R11 000 09 MOVE 3500 indd User manual Move3500 Part 2 INGENICO M5000CLWI XKB XKB M5000CLWI m5000clwi

4_6_2 Installing paper roll Open the paper compartment by lifting the catch located at the rear of the terminal and pull the cover to the rear of the terminal. Insert the paper roll in the compartment following the directions shown on the below picture Pull the paper up to the top of the terminal Ma...

lang:en score:28 filesize: 1.46 M page_count: 12 document date: 2023-01-02



[PCI-Secure Software Standard Vendor Implementation Guide for Viking Terminal 2.00](#)

This guide from Nets provides detailed information on the PCI-Secure Software Standard for the Viking terminal, covering secure implementation, application software, remote updates, data protection, authentication, logging, and network configurations for vendors and merchants.

lang:en score:28 filesize: 627.2 K page_count: 26 document date: 2023-11-24



[\[pdf\]](#) Documentation Guide

900019007 R11 000 09 MOVE 3500 indd Move Ingenico 1 Introduction We hope that you will be fully satisfied with your new terminal This is available in different models Please select by yourself this documentation items related to 2019 10 — Turn and unclip the battery trapdoor pushing on button as shown picture Disengage move3500 r11 cdn ingenico binaries content assets corporate en user guides ||| Move 3500 User Guide Optional www.ingenico.com 28-32, boulevard de Grenelle, 75015 Paris - France / T 33 0 1 58 01 80 00 / F 33 0 1 58 01 91 35 Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre Contents 1_Introduction 4 2_Presentation 5 2_1 Content of the box 5 2_1_1...


lang:en score:27 filesize: 6.53 M page_count: 32 document date: 2018-12-12



[Ingenico Move/3500 User Manual and Safety Guide](#)

Comprehensive guide for the Ingenico Move/3500 payment terminal, covering installation, safety, troubleshooting, and compliance.

lang:en score:27 filesize: 1.46 M page_count: 12 document date: 2022-12-14



[\[pdf\] Guide](#)

Aruna Panicker Maksupäätteet Nets PCI Secure Software Standard Vendor Implementation Guide v1 1

Viking 01 0 assets ctfassets net uxrhu22fwd1p 51ZufD7Styl80AE5HVpplt


d71390e34bc543dd6330dd97661d3942 |||

Nets Denmark A/S: PCI-Secure Software Standard Software Vendor Implementation Guide for Viking termi ... tsdocs/4-20321ICO-OPE-04972-

ENV12_PCI_PTS_Security_Policy_Desk_3200_Desk_3500-1650663092.33407.pdf

Move3500 https://listings.pcisecuritystandards.org/ptsdocs/4-20320ICO-OPE-04848-ENV11_PCI_PTS_Secur...

lang:en score:25 filesize: 437.79 K page_count: 33 document date: 2023-01-05



[\[pdf\] Guide](#)

Aruna Panicker Maksupäätteet Nets PCI Secure Software Standard Vendor Implementation Guide v1 0

for Viking 1 00 assets ctfassets net uxrhu22fwd1p 6b6rNKYCWWmseFKChHyx9J

fc55d30c431030a2a12f585518a87112 |||


Nets Denmark A/S: PCI-Secure Software Standard Software Vendor Implementation Guide for Viking termi ... tsdocs/4-20321ICO-OPE-04972-

ENV12_PCI_PTS_Security_Policy_Desk_3200_Desk_3500-1650663092.33407.pdf

Move3500 https://listings.pcisecuritystandards.org/ptsdocs/4-20320ICO-OPE-04848-ENV11_PCI_PTS_Secur...

lang:en score:25 filesize: 432.61 K page_count: 33 document date: 2022-09-20

Detailed guide for implementing and securing Nets Viking payment terminals according to the PCI Secure Software Standard. Covers configuration, updates, and compliance for vendors and merchants.




Letterhead with logo Volkmar BLOCH Ingenico Download Support 20210820 faxbestellung zubehor
telium cdn ingenico binaries content assets germany smart terminals ersatz und zuberhorteile |||

lang:de score:24 filesize: 166.28 K page_count: 1 document date: 2021-08-20

Erdal Dastan Approved terminal list Dankort 20240129 assets ctfassets net gxv815mh8y8i

Tk1IQ4gImPryKFk727lvQ ebde88e9d166ac0fd123284a18d1d796 |||

lang:it score:23 filesize: 293.91 K page count: 5 document date: 2024-02-05



[\[pdf\]](#) Datasheet

move3500 cdn ingenico binaries content assets corporate en library datasheets |||

Move/3500 Accept any payment while on-the-go Leverage Telium applications on the next-generation payment terminal Make NFC payment a seamless consumer experience Bring mobile payment to your POS with the most connected terminal 5 The Move/3500 offers a seamless payment experience while on-the-g...

lang:en **score:22** filesize: 993.77 K page_count: 2 document date: 2019-10-02




[\[pdf\]](#)

Move3500 07 21 indd 202107 move3500 datenblatt cdn ingenico binaries content assets germany smart terminals 1 x produkte tetra |||

Move/3500 Flexible mobile Akzeptanz aller Zahlungsarten Erfüllt strengste Sicherheitsanforderungen entsprechend PCI PTS 5.x Anbindung in mobile und lokale Kommunikationsnetze Modular erweiterbares Softwarekonzept auf zukunftsweisender Plattform Kontaktloses Bezahlen mit allen gängigen Verfahren, auch ...

lang:de **score:22** filesize: 1020.92 K page_count: 2 document date: 2021-07-07




[\[pdf\]](#) Datasheet

Fiche technique Move 3500 Ingenico MOVE3500 datasheet JUNE22 cms test ingenico sites default files resource document 2022 07 |||

Move/3500 Accept any type of payment, while doing business on-the-go Leverage Telium applications on the next-generation payment terminal Make NFC payment a seamless consumer experience Bring mobile payment to your POS with the most connected terminal The Move/3500 offers a seamless payment experi...

lang:en **score:22** filesize: 2.61 M page_count: 2 document date: 2022-06-15



[\[pdf\]](#) Installation Guide Guide

Report Lionel JAMES Ingenico Driver Installer User Guide This document is the installation guide of USB driver for Telium 1 3 Scope aimed at every administrator or user who wants to ingenico sites default files resource 2024 06 |||

Ingenico Driver Installer User Guide Installer v3.36 ICO-OPE-4329-V6 Public INGENICO Smart Terminals ... ck document validity before using ICO-OPE-4329-V6 Ingenico Driver Installer User Guide Ingenico **Move3500** Ingenico Desk3xxx Ingenico Move2500 Ingenico Lane7000 Ingenico iST1xx/iUC1xx/iUC2xx/iUI120/... lang:tl **score:22** filesize: 1.34 M page_count: 27 document date: 2023-09-11



[\[pdf\]](#)

Move3500 07 21 indd Download Ingenico Datenblätter 202107 Datenblatt ingenico sites default files resource document 2023 01 |||

Move/3500 Flexible mobile Akzeptanz aller Zahlungsarten Erfüllt strengste Sicherheitsanforderungen entsprechend PCI PTS 5.x Anbindung in mobile und lokale Kommunikationsnetze Modular erweiterbares Softwarekonzept auf zukunftsweisender Plattform Kontaktloses Bezahlen mit allen gngigen Verfahren, auch ... lang:de **score:21** filesize: 1.17 M page_count: 2 document date: 2023-01-31



[\[pdf\]](#) Dimension Guide Borchure Catalog

ING FICHE Move3500 FR 2 PAO IMAC move3500 fr cdn ingenico binaries content assets website brochures terminaux portables |||

Move/3500 Acceptez tous les paiements en mobilit Ayez accs au catalogue applicatif TELIUM sur un terminal de nouvelle gnrntion Effectuez des transactions sans contact par carte et par mobile Ajoutez du paiement mobile votre point-de-vente grce un terminal la connectivit multiple BR-Produit-M... lang:fr **score:21** filesize: 570.12 K page_count: 2 document date: 2016-09-06



[pdf] Declaration of Conformity

DECLARATION OF SIMILARITY MOVE5000 MOVE3500 2 njacquemont Ingenico Group Cover letter 1
INGENICO XTRAWIC KKB KKBXTRAWIC xtrawic

Date: 2022-09-15 DECLARATION LETTER To Whom It May Concern: We, Ingenico, as manufacturer of XTRA Module models, hereby declare that these modules under: FCC ID: XKB-XTRAWIC and IC: 2586D-XTRAWIC, will only be used with Lane/7000 and Lane/8000 hosts, that the module will only be used by Ingenico ...

lang:fr score:21 filesize: 158.07 K page_count: 1 document date: 2022-09-16



[pdf] Test Report SAR Rating

SAR test report Thomas Vogler Report INGENICO M5000CL4GWIBT Mobile Payment terminal KKB
XKB M5000CL4GWIBT m5000cl4gwibt

TEST REPORT BNetZ-A-CAB-02/21-102 Test Report No.: 1-5566/17-01-02-A D-PL-12076-01-03 Testing Lab ... 10 0.012 0.14 22.7 0 23060 704.0 12 rear 23.0 22.2 0.019 0.022 0.16 22.7 0 10MHz BW/1RB/QPSK - **Move3500** 23060 704.0 25 left 24.0 23.3 0.247 0.290 0.03 22.7 0 23095 707.5 25 left 24.0 23.2...

lang:en score:21 filesize: 2.33 M page_count: 78 document date: 2018-04-03



[pdf]

Erdal Dastan Unattended Semi attended Terminal Approved UPT Semiattended list Integrated Dankort
20241001 assets ctfassets net gxv815mh8y8i 7wEXZXyLWTMuLFbb95dO1u

b75c75096bcb47305c42eca5fc168623 |||

Unattended/Semi-attended Terminal Integrations: This list only contains Unattended and Semi-attended ... 1 N Y Y Y y ID-3097 Semi- Nets Viking FO.PS Integrations Nets 1.3 Y attended Lane3000/**Move3500**/Desk3500/Li nk2500 ID-3109 UPT Nets Viking IUC150b IUR250 Future Ordering Kiosk 22...

lang:it score:21 filesize: 214.28 K page_count: 3 document date: 2024-10-01

DECLARATION LETTER

Date: 2019-11-27

To Whom It May Concern:

We, Ingenico, as manufacturer of XTRA Module models, hereby declare that these modules under

FCC ID: XKB-XTRAWIBTC and IC: 2586D-XTRAWIBTC,

will only be used with Lane/7000 and Lane/8000 hosts, that the module will only be used by Ingenico and will not be sold to customers as a standalone product.

Thanks for your attention on this matter.

Yours faithfully

Name	Nicolas Jacquemont - HW Certification Manager
Company	INGENICO Terminals SAS

Signature _____

Unattended/Semi-attended Terminal Integrations:

This list only contains Unattended and Semi-attended solutions that have been tested and verified by NETS (IT-verification since 01.01.2018). For any questions related to the solution validity, function, acceptance etc., please contact the Suseller/owner.

Application	Architecture	System (model)	Application	API Version	Notes
Google 1	ARM	Google 1	Google 1	Google 1	
Google 2	ARM	Google 2	Google 2	Google 2	
Google 3	ARM	Google 3	Google 3	Google 3	
Google 4	ARM	Google 4	Google 4	Google 4	
Google 5	ARM	Google 5	Google 5	Google 5	
Google 6	ARM	Google 6	Google 6	Google 6	
Google 7	ARM	Google 7	Google 7	Google 7	
Google 8	ARM	Google 8	Google 8	Google 8	
Google 9	ARM	Google 9	Google 9	Google 9	
Google 10	ARM	Google 10	Google 10	Google 10	
Google 11	ARM	Google 11	Google 11	Google 11	
Google 12	ARM	Google 12	Google 12	Google 12	
Google 13	ARM	Google 13	Google 13	Google 13	
Google 14	ARM	Google 14	Google 14	Google 14	
Google 15	ARM	Google 15	Google 15	Google 15	
Google 16	ARM	Google 16	Google 16	Google 16	
Google 17	ARM	Google 17	Google 17	Google 17	
Google 18	ARM	Google 18	Google 18	Google 18	
Google 19	ARM	Google 19	Google 19	Google 19	
Google 20	ARM	Google 20	Google 20	Google 20	
Google 21	ARM	Google 21	Google 21	Google 21	
Google 22	ARM	Google 22	Google 22	Google 22	
Google 23	ARM	Google 23	Google 23	Google 23	
Google 24	ARM	Google 24	Google 24	Google 24	
Google 25	ARM	Google 25	Google 25	Google 25	
Google 26	ARM	Google 26	Google 26	Google 26	
Google 27	ARM	Google 27	Google 27	Google 27	
Google 28	ARM	Google 28	Google 28	Google 28	
Google 29	ARM	Google 29	Google 29	Google 29	
Google 30	ARM	Google 30	Google 30	Google 30	
Google 31	ARM	Google 31	Google 31	Google 31	
Google 32	ARM	Google 32	Google 32	Google 32	
Google 33	ARM	Google 33	Google 33	Google 33	
Google 34	ARM	Google 34	Google 34	Google 34	
Google 35	ARM	Google 35	Google 35	Google 35	
Google 36	ARM	Google 36	Google 36	Google 36	
Google 37	ARM	Google 37	Google 37	Google 37	
Google 38	ARM	Google 38	Google 38	Google 38	
Google 39	ARM	Google 39	Google 39	Google 39	
Google 40	ARM	Google 40	Google 40	Google 40	
Google 41	ARM	Google 41	Google 41	Google 41	
Google 42	ARM	Google 42	Google 42	Google 42	
Google 43	ARM	Google 43	Google 43	Google 43	
Google 44	ARM	Google 44	Google 44	Google 44	
Google 45	ARM	Google 45	Google 45	Google 45	
Google 46	ARM	Google 46	Google 46	Google 46	
Google 47	ARM	Google 47	Google 47	Google 47	
Google 48	ARM	Google 48	Google 48	Google 48	
Google 49	ARM	Google 49	Google 49	Google 49	
Google 50	ARM	Google 50	Google 50	Google 50	
Google 51	ARM	Google 51	Google 51	Google 51	
Google 52	ARM	Google 52	Google 52	Google 52	
Google 53	ARM	Google 53	Google 53	Google 53	
Google 54	ARM	Google 54	Google 54	Google 54	
Google 55	ARM	Google 55	Google 55	Google 55	
Google 56	ARM	Google 56	Google 56	Google 56	
Google 57	ARM	Google 57	Google 57	Google 57	
Google 58	ARM	Google 58	Google 58	Google 58	
Google 59	ARM	Google 59	Google 59	Google 59	
Google 60	ARM	Google 60	Google 60	Google 60	
Google 61	ARM	Google 61	Google 61	Google 61	
Google 62	ARM	Google 62	Google 62	Google 62	
Google 63	ARM	Google 63	Google 63	Google 63	
Google 64	ARM	Google 64	Google 64	Google 64	
Google 65	ARM	Google 65	Google 65	Google 65	
Google 66	ARM	Google 66	Google 66	Google 66	
Google 67	ARM	Google 67	Google 67	Google 67	
Google 68	ARM	Google 68	Google 68	Google 68	
Google 69	ARM	Google 69	Google 69	Google 69	
Google 70	ARM	Google 70	Google 70	Google 70	
Google 71	ARM	Google 71	Google 71	Google 71	
Google 72	ARM	Google 72	Google 72	Google 72	
Google 73	ARM	Google 73	Google 73	Google 73	
Google 74	ARM	Google 74	Google 74	Google 74	
Google 75	ARM	Google 75	Google 75	Google 75	
Google 76	ARM	Google 76	Google 76	Google 76	
Google 77	ARM	Google 77	Google 77	Google 77	
Google 78	ARM	Google 78	Google 78	Google 78	
Google 79	ARM	Google 79	Google 79	Google 79	
Google 80	ARM	Google 80	Google 80	Google 80	
Google 81	ARM	Google 81	Google 81	Google 81	
Google 82	ARM	Google 82	Google 82	Google 82	
Google 83	ARM	Google 83	Google 83	Google 83	
Google 84	ARM	Google 84	Google 84	Google 84	
Google 85	ARM	Google 85	Google 85	Google 85	
Google 86	ARM	Google 86	Google 86	Google 86	
Google 87	ARM	Google 87	Google 87	Google 87	
Google 88	ARM	Google 88	Google 88	Google 88	
Google 89	ARM	Google 89	Google 89	Google 89	
Google 90	ARM	Google 90	Google 90	Google 90	
Google 91	ARM	Google 91	Google 91	Google 91	
Google 92	ARM	Google 92	Google 92	Google 92	
Google 93	ARM	Google 93	Google 93	Google 93	
Google 94	ARM	Google 94	Google 94	Google 94	
Google 95	ARM	Google 95	Google 95	Google 95	
Google 96	ARM	Google 96	Google 96	Google 96	
Google 97	ARM	Google 97	Google 97	Google 97	
Google 98	ARM	Google 98	Google 98	Google 98	
Google 99	ARM	Google 99	Google 99	Google 99	
Google 100	ARM	Google 100	Google 100	Google 100	

[\[pdf\]](#) Decleration of Conformity

DECLARATION OF SIMILARITY MOVE5000 MOVE3500 2 njacquemont Ingenico Group Cover Letter

Usage of the module INGENICO XTRAWIBTC Add on RF XKB XKBXTRAWIBTC xtrawibtc

Date: 2019-11-27 DECLARATION LETTER To Whom It May Concern: We, Ingenico, as manufacturer of XTRA Module m o d e l s , hereby declare that these modules under FCC ID: XKB-XTRAWIBTC and IC: 2586D-XTRAWIBTC, will only be used with Lane/7000 and Lane/8000 hosts. that the module will only be used by ...

lang:de score:20 filesize: 137.95 K page count: 1 document date: 2019-12-04

[pdf]

Erdal Dastan Approved UPT Semiattended list integrated Dankort 20230601 assets ctfassets net

gxv815mh8y8i 7wEXZXyLWTMuLFbb95dO1u c888c15e0023ba24f5925d0de5c0b53d |||

Unattended/Semi-attended Terminal Integrations: This list only contains Unattended and Semi-attended ... ommonACI1.3 Galaxy Kiosk 1.0 Harbakiosk 1.2 WCM Payment

10.6 WestPay xUPT-303 Nets Viking Lane3000/**Move3500**/Desk3500/Li nk2500

Kiosk Payment Service1.2 FO.PS Integrations Nets 1.3 PIN Yes/No Y Y Y ...

lang:it score:20 filesize: 169.88 K page count: 3 document date: 2023-06-06

[\[pdf\]](#) Guide


BF 20180911 ki move3500 div3311 cdn ingenico binaries content assets germany smart terminals 3 x

```
userguide t tetra |||
```

Kurzinfo Move/3500 Tastatur F1 und F4 dienen der Bestätigung einer im Display angezeigten Auswahl. F ... n einem Abstand kleiner 4 cm ber den Druckerdeckel gehalten. Copyright 2018 Ingenico 20180911 KI **Move3500** DIV3311.doc 1/4

Menführung / Funktionsaufruf Das Terminal verfügt ber verschiedene Modi, ...

lang:de score:20 filesize: 443.42 K page count: 4 document date: 2018-09-11



[\[pdf\]](#) User Manual Guide

Allgemeine Sicherheitshinweise Jan Rassbach 20180911 ia move3500 div3312 cdn ingenico binaries content assets germany smart terminals 3 x userguide t tetra |||

Installationsanleitung Move/3500 Allgemeine Sicherheitshinweise Packen Sie das Gert vorsichtig aus ... eit der menschlichen Gesundheit und der Umwelt gewhrleistet. Copyright 2018 Ingenico 20180911_IA_ **Move3500_DIV3312.docx** 1 / 4 Lieferumfang Lieferkonfigurationen: Move/3500 3G/WLAN mit Ladebasis ... lang:de **score:20** filesize: 485.14 K page_count: 4 document date: 2018-09-11




[\[pdf\]](#) Guide

900019007 R11 000 06 MOVE 3500 indd userguide move3500 INGENICO M5000CLWIBT Mobile Payment terminal KXB XKBM5000CLWIBT m5000clwibt Move 3500 User Guide Optional www.ingenico.com 28-32, boulevard de Grenelle, 75015 Paris - France / T 33 0 1 58 01 80 00 / F 33 0 1 58 01 91 35 Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre Contents 1_Introduction 4 2_Presentation 5 2_1 Content of the box 5 2_1_1... lang:en **score:20** filesize: 1.87 M page_count: 32 document date: 2017-04-18



[\[pdf\]](#) Guide

900019007 R11 000 06 MOVE 3500 indd userguide move3500 INGENICO M5000CL3GWIBT Mobile Payment terminal KXB XKBM5000CL3GWIBT m5000cl3gwibt Move 3500 User Guide Optional www.ingenico.com 28-32, boulevard de Grenelle, 75015 Paris - France / T 33 0 1 58 01 80 00 / F 33 0 1 58 01 91 35 Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre Contents 1_Introduction 4 2_Presentation 5 2_1 Content of the box 5 2_1_1... lang:en **score:20** filesize: 1.88 M page_count: 32 document date: 2017-04-04




[\[pdf\]](#) Guide

900019007 R11 000 06 MOVE 3500 indd userguide move3500 INGENICO M5000CL4GWIBT Mobile Payment terminal XKB XKBM5000CL4GWIBT m5000cl4gwibt

Move 3500 User Guide Optional www.ingenico.com 28-32, boulevard de Grenelle, 75015 Paris - France / T 33 0 1 58 01 80 00 / F 33 0 1 58 01 91 35 Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre Contents 1_Introduction 4 2_Presentation 5 2_1 Content of the box 5 2_1_1...

lang:en score:20 filesize: 3.89 M page_count: 32 document date: 2018-03-20




[\[pdf\]](#) User Manual

Allgemeine Sicherheitshinweise Jan Rassbach Ingenico 31 2023 — Das zugehörige Symbol bedeutet dass WEEE und Altbatterien nicht weggeworfen sondern getrennt gesammelt recycelt werden dürfen 20180911 IA Move3500 DIV3312 ingenico sites default files resource document 01 |||

Installationsanleitung Move/3500 Allgemeine Sicherheitshinweise Packen Sie das Gert vorsichtig aus ... eit der menschlichen Gesundheit und der Umwelt gewhrleistet. Copyright 2018 Ingenico 20180911_IA_ **Move3500**_DIV3312.docx 1 / 4 Lieferumfang Lieferkonfigurationen: Move/3500 3G/WLAN mit Ladebasis ...

lang:de score:20 filesize: 584.71 K page_count: 4 document date: 2023-01-27



[\[pdf\]](#) Specifications Datasheet

Téléchargement Ingenico Move 3500 MOVE datasheet EN OCT22 ingenico sites default files resource document 2022 10 Ficha técnica del MOVE3500 JUNE22 07 |||

Move/3500 Managing all payment types, in every location Process easily payment on the spot through a compact portable terminal Make NFC payment a seamless consumer experience Bring mobile payments to your POS via a hyperconnected terminal A smooth payment experience while on-the-go 3.2 color to...

lang:en score:20 filesize: 1 M page_count: 2 document date: 2022-09-16

 TEST REPORT Test Report No.: 1-2648/16-01-07-A	
Testing Laboratory CTCadvanced GmbH Unterwasserstr. 8a, D-48117 Bielefeld-Gremmighausen Phone: +49 521 150 100 Fax: +49 521 150 101 E-mail: info@ctcadvanced.com Accredited Test Laboratory The testing laboratory (area of testing) is accredited according to DIN EN ISO/IEC 17025:2005 by the Deutsche Akkreditierungsstelle GmbH (DAKGS). The accreditation is valid for the scope of testing procedures as indicated in the accreditation certificate with the registration number: D-PL-15015-2015	Applicant Agencie Group 8 Avenue de la Gare Roubaix 59100 Roubaix Cedex FRANCE Phone: +33 3 20 33 10 00 Contact: Jean-Raphaël Paillet Email: jean-raphael.paillet@agenciegroup.com Fax: +33 3 20 33 10 01 Manufacturer Ingenico Group 8 Avenue de la Gare Roubaix 59100 Roubaix Cedex FRANCE
Test Standards Recommended Practice for Determining the Peak Spatial Average Specific Absorption Rate (SAR) for Human-Head-Torso Wireless Communications Devices Measurement Techniques (All Frequency Bands) ETSI EN 301 893 ETSI EN 301 893-1 ETSI EN 301 893-2 ETSI EN 301 893-3 ETSI EN 301 893-4 ETSI EN 301 893-5 ETSI EN 301 893-6 ETSI EN 301 893-7 ETSI EN 301 893-8 ETSI EN 301 893-9 ETSI EN 301 893-10 ETSI EN 301 893-11 ETSI EN 301 893-12 ETSI EN 301 893-13 ETSI EN 301 893-14 ETSI EN 301 893-15 ETSI EN 301 893-16 ETSI EN 301 893-17 ETSI EN 301 893-18 ETSI EN 301 893-19 ETSI EN 301 893-20 ETSI EN 301 893-21 ETSI EN 301 893-22 ETSI EN 301 893-23 ETSI EN 301 893-24 ETSI EN 301 893-25 ETSI EN 301 893-26 ETSI EN 301 893-27 ETSI EN 301 893-28 ETSI EN 301 893-29 ETSI EN 301 893-30 ETSI EN 301 893-31 ETSI EN 301 893-32 ETSI EN 301 893-33 ETSI EN 301 893-34 ETSI EN 301 893-35 ETSI EN 301 893-36 ETSI EN 301 893-37 ETSI EN 301 893-38 ETSI EN 301 893-39 ETSI EN 301 893-40 ETSI EN 301 893-41 ETSI EN 301 893-42 ETSI EN 301 893-43 ETSI EN 301 893-44 ETSI EN 301 893-45 ETSI EN 301 893-46 ETSI EN 301 893-47 ETSI EN 301 893-48 ETSI EN 301 893-49 ETSI EN 301 893-50 ETSI EN 301 893-51 ETSI EN 301 893-52 ETSI EN 301 893-53 ETSI EN 301 893-54 ETSI EN 301 893-55 ETSI EN 301 893-56 ETSI EN 301 893-57 ETSI EN 301 893-58 ETSI EN 301 893-59 ETSI EN 301 893-60 ETSI EN 301 893-61 ETSI EN 301 893-62 ETSI EN 301 893-63 ETSI EN 301 893-64 ETSI EN 301 893-65 ETSI EN 301 893-66 ETSI EN 301 893-67 ETSI EN 301 893-68 ETSI EN 301 893-69 ETSI EN 301 893-70 ETSI EN 301 893-71 ETSI EN 301 893-72 ETSI EN 301 893-73 ETSI EN 301 893-74 ETSI EN 301 893-75 ETSI EN 301 893-76 ETSI EN 301 893-77 ETSI EN 301 893-78 ETSI EN 301 893-79 ETSI EN 301 893-80 ETSI EN 301 893-81 ETSI EN 301 893-82 ETSI EN 301 893-83 ETSI EN 301 893-84 ETSI EN 301 893-85 ETSI EN 301 893-86 ETSI EN 301 893-87 ETSI EN 301 893-88 ETSI EN 301 893-89 ETSI EN 301 893-90 ETSI EN 301 893-91 ETSI EN 301 893-92 ETSI EN 301 893-93 ETSI EN 301 893-94 ETSI EN 301 893-95 ETSI EN 301 893-96 ETSI EN 301 893-97 ETSI EN 301 893-98 ETSI EN 301 893-99 ETSI EN 301 893-100	
Test Item Payment Terminal Model name: M5000CL3GWIBT Serial number: 161677313191018601103817 ETSI EN 301 893-1 ETSI EN 301 893-2 ETSI EN 301 893-3 ETSI EN 301 893-4 ETSI EN 301 893-5 ETSI EN 301 893-6 ETSI EN 301 893-7 ETSI EN 301 893-8 ETSI EN 301 893-9 ETSI EN 301 893-10 ETSI EN 301 893-11 ETSI EN 301 893-12 ETSI EN 301 893-13 ETSI EN 301 893-14 ETSI EN 301 893-15 ETSI EN 301 893-16 ETSI EN 301 893-17 ETSI EN 301 893-18 ETSI EN 301 893-19 ETSI EN 301 893-20 ETSI EN 301 893-21 ETSI EN 301 893-22 ETSI EN 301 893-23 ETSI EN 301 893-24 ETSI EN 301 893-25 ETSI EN 301 893-26 ETSI EN 301 893-27 ETSI EN 301 893-28 ETSI EN 301 893-29 ETSI EN 301 893-30 ETSI EN 301 893-31 ETSI EN 301 893-32 ETSI EN 301 893-33 ETSI EN 301 893-34 ETSI EN 301 893-35 ETSI EN 301 893-36 ETSI EN 301 893-37 ETSI EN 301 893-38 ETSI EN 301 893-39 ETSI EN 301 893-40 ETSI EN 301 893-41 ETSI EN 301 893-42 ETSI EN 301 893-43 ETSI EN 301 893-44 ETSI EN 301 893-45 ETSI EN 301 893-46 ETSI EN 301 893-47 ETSI EN 301 893-48 ETSI EN 301 893-49 ETSI EN 301 893-50 ETSI EN 301 893-51 ETSI EN 301 893-52 ETSI EN 301 893-53 ETSI EN 301 893-54 ETSI EN 301 893-55 ETSI EN 301 893-56 ETSI EN 301 893-57 ETSI EN 301 893-58 ETSI EN 301 893-59 ETSI EN 301 893-60 ETSI EN 301 893-61 ETSI EN 301 893-62 ETSI EN 301 893-63 ETSI EN 301 893-64 ETSI EN 301 893-65 ETSI EN 301 893-66 ETSI EN 301 893-67 ETSI EN 301 893-68 ETSI EN 301 893-69 ETSI EN 301 893-70 ETSI EN 301 893-71 ETSI EN 301 893-72 ETSI EN 301 893-73 ETSI EN 301 893-74 ETSI EN 301 893-75 ETSI EN 301 893-76 ETSI EN 301 893-77 ETSI EN 301 893-78 ETSI EN 301 893-79 ETSI EN 301 893-80 ETSI EN 301 893-81 ETSI EN 301 893-82 ETSI EN 301 893-83 ETSI EN 301 893-84 ETSI EN 301 893-85 ETSI EN 301 893-86 ETSI EN 301 893-87 ETSI EN 301 893-88 ETSI EN 301 893-89 ETSI EN 301 893-90 ETSI EN 301 893-91 ETSI EN 301 893-92 ETSI EN 301 893-93 ETSI EN 301 893-94 ETSI EN 301 893-95 ETSI EN 301 893-96 ETSI EN 301 893-97 ETSI EN 301 893-98 ETSI EN 301 893-99 ETSI EN 301 893-100	
Test Report authorized: Alexander Heubner Test Manager Public Communications & EMC	
Test performed: Matthias Schlegel Testing Manager Public Communications & EMC	

[pdf] Test Report SAR Rating

TEST REPORT CTC advanced GmbH SAR Report INGENICO M5000CL3GWIBT Mobile Payment

terminal KXB XKBM5000CL3GWIBT m5000cl3gwbtt

CETECOM ICT Services is now TEST REPORT Test Report No.: 1-2648/16-01-07-A


Testing Laboratory CTC ... o.: 1-2648/16-01-07-A CETECOM ICT Services is now

Date/Time: 08.02.2017 15:02:44 FCC-GSM850 - MSL-**Move3500** DUT: Ingenico;

Type: Move/3500; Serial: 161677313191018601103817 Communication System: UID

...

lang:en score:19 filesize: 2.18 M page_count: 66 document date: 2017-04-10



[pdf]

BF Tastatur Karten einlesen Ingenico Jan 31 2023 — Das Terminal verfügt über verschiedene Modi den

Grundzustand und Eingabemodus Im werden Informationen Verbindungsstatus sowie 20180911 KI

Move3500 DIV3311 ingenico sites default files resource document 01 |||

Kurzinfo Move/3500 Tastatur F1 und F4 dienen der Bestätigung einer im Display

angezeigten Auswahl. F ... n einem Abstand kleiner 4 cm ber den Druckerdeckel

gehalten. Copyright 2018 Ingenico 20180911 KI_ **Move3500**_DIV3311.doc 1/4

Menführung / Funktionsaufruf Das Terminal verfügt ber verschiedene Modi, ...

lang:de score:19 filesize: 521.73 K page_count: 4 document date: 2023-01-27