

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Playmobil](#) /

› [Playmobil 70253 Heidi's Grandfather's Chalet Playset Instruction Manual](#)

## Playmobil 70253

# Playmobil 70253 Heidi's Grandfather's Chalet Playset Instruction Manual

## INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of the Playmobil 70253 Heidi's Grandfather's Chalet playset. Please read all instructions carefully before beginning assembly or play to ensure a safe and enjoyable experience.

The playset includes Heidi, her grandfather, and their dog Hercules, along with a detailed chalet featuring a spacious living area, a storage space for hay under the roof, and a pantry. This set is designed to encourage imaginative play.

## SAFETY INFORMATION

- **Warning:** Not suitable for children under 3 years due to small parts which may present a choking hazard.
- Always use this product under adult supervision.
- Inspect all components regularly for damage. Discontinue use if any parts are broken or damaged.

## SETUP AND ASSEMBLY

The Playmobil 70253 playset requires assembly. The set contains 107 individual pieces. Parental assistance is recommended for assembly.

### Assembly Steps:

1. Unpack all components from the box and verify that all 107 pieces are present using the included parts list.
2. Refer to the visual guide below for component identification and placement.
3. Begin by assembling the main structure of the chalet, connecting the wall panels and floor pieces as indicated in the visual instructions.
4. Attach the roof sections, ensuring they are securely fastened.

5. Assemble the interior furniture, such as the table, chairs, and shelves, and place them inside the chalet.
6. Position the smaller accessory pieces, including the figures of Heidi, her grandfather, and the dog Hercules, around the chalet to complete the scene.



**Figure 1:** Overview of all components included in the Playmobil 70253 set, illustrating their layout for assembly. This image helps identify each piece before construction begins.



**Figure 2:** The fully assembled Playmobil 70253 Heidi's Grandfather's Chalet playset, showcasing the complete structure and figures in an outdoor setting.

## OPERATING THE PLAYSET

The Playmobil 70253 playset is designed for imaginative role-play. Children can create various scenarios with Heidi, her grandfather, and their dog Hercules in and around the chalet.

- Position the figures to act out daily life in the Alps, such as the grandfather chopping wood or Heidi playing with the dog.
- Utilize the chalet's interior, including the living area and pantry, for indoor play scenarios.
- Encourage storytelling and creative interaction with all included accessories.



**Figure 3:** Heidi and her grandfather enjoying a meal inside the chalet, demonstrating an example of interactive play within the playset's interior.

## MAINTENANCE

---

To ensure the longevity of your Playmobil playset, follow these simple maintenance guidelines:

- **Cleaning:** Pieces without stickers can be cleaned simply under running water. Avoid using chemical cleaning agents, as these may damage the plastic or printed details.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight to prevent discoloration and material degradation.
- **Inspection:** Periodically check all connections and parts for wear and tear.

## TROUBLESHOOTING

---

Most issues with Playmobil playsets can be resolved by carefully reviewing the assembly instructions or checking for missing pieces.

- **Missing Pieces:** If you find any pieces are missing upon opening the box, please contact Playmobil customer support.
- **Difficulty Assembling:** Ensure you are following the visual instructions provided. Some connections require firm pressure. If a piece does not fit, double-check its orientation.
- **Damaged Parts:** If any part is damaged, do not attempt to force it. Contact customer support for replacement parts.

## SPECIFICATIONS

---

Feature	Detail
Model Number	70253
Brand	Playmobil
Sub-brand	Heidi
Number of Pieces	107
Material	Plastic
Product Dimensions (L x W x H)	51.5 x 9 x 38.5 cm
Item Weight	1.4 kilograms (1396 Grams)
Recommended Age (Manufacturer)	4 - 99 years
Assembly Required	Yes
Educational Value	Agility, Creativity, Sociability
Batteries Required	No
Batteries Included	No

## WARRANTY AND SUPPORT

---

For information regarding warranty, replacement parts, or customer support, please refer to the official Playmobil website or contact their customer service directly. Details are typically provided on the product packaging or the manufacturer's official channels.