

[Manuals.plus](#) /

- › [Backyard Discovery](#) /
- › Backyard Discovery Lakewood Cedar Wood Swing Set Instruction Manual

## Backyard Discovery 2001022

# Backyard Discovery Lakewood Cedar Wood Swing Set

INSTRUCTION MANUAL - MODEL 2001022

## Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Backyard Discovery Lakewood Cedar Wood Swing Set. Designed for residential use, this playset features an elevated clubhouse, a lower playhouse with a snack bar, two belt swings, and a trapeze bar, all crafted from durable cedar wood.



Image: The complete Lakewood Cedar Wood Swing Set installed in a backyard, showing children enjoying the swings,

slide, and playhouse.

## Safety Information

---

For residential use only. Always supervise children during play. Ensure the playset is installed on a level surface and anchored securely. Regularly inspect all components for wear or damage. Refer to the full safety guidelines provided in the packaging for detailed instructions.


**Important Safety Note:** This product is designed and tested to meet and exceed ASTM standards for children up to 12 years old. Maximum weight recommendation for individual components is 40 kilograms.

## Components

---

The Backyard Discovery Lakewood Cedar Wood Swing Set includes the following main components:

- Elevated Clubhouse with canopy roof
- Lower Playhouse with full front door, windows, and built-in bench seating
- 8-foot Wave Slide
- Two Belt Swings
- One Trapeze Bar
- Flat Step Ladder
- All necessary hardware and wood pieces



## LAKEWOOD SWING SET




Image: An exploded view diagram illustrating the various parts included in the Lakewood Swing Set package.

## Setup and Assembly

Assembly of the Lakewood Swing Set requires careful attention to detail. It is recommended to have at least two adults for assembly.

1. **Site Preparation:** Choose a level area in your backyard for installation. Ensure adequate clear space around the playset for safe use.
2. **Delivery and Inventory:** Upon delivery, verify all boxes and parts are present against the packing list.
3. **Apply Sealant:** If your product is made of wood, apply a sealant for protection and durability before assembly.
4. **Assembly Process:** Follow the step-by-step instructions provided. The interactive BILT app offers 3D instructions for a guided assembly experience. Scan the QR code or visit the app store to download.

Scan for easy 3D instructions



**Tap. Zoom. Rotate** with official interactive instructions on the BILT app. Download now for faster setup.



**BILT.**<sup>®</sup>

Image: The BILT app interface showing interactive 3D assembly instructions for the playset.

Your browser does not support the video tag.

Video: An official assembly guide for the Lakewood Swing Set, demonstrating key steps and features.

## Operation and Usage

The Lakewood Swing Set offers various play activities:

- **Clubhouse and Playhouse:** Children can access the elevated clubhouse via the step ladder and enjoy the lower playhouse with its snack bar window and bench.
- **Swings and Trapeze:** The two belt swings and trapeze bar provide opportunities for swinging and acrobatic play.
- **Wave Slide:** The 8-foot wave slide offers a quick and fun descent from the upper deck.



Children enjoying various activities on the playset.



The lower playhouse features a snack bar window.



Access the clubhouse via the sturdy step ladder.



Enjoy a fun ride down the wave slide.



The swing beam includes two belt swings and a trapeze.

## Maintenance

Regular maintenance ensures the longevity and safety of your swing set.

- **Wood Treatment:** Cedar wood is naturally durable, but applying a wood sealant annually is recommended to protect against weathering and extend the product's life.
- **Hardware Inspection:** Periodically check all bolts, nuts, and screws for tightness. Tighten as necessary.
- **Component Check:** Inspect swings, ropes, and the slide for signs of wear, cracks, or damage. Replace any worn or damaged parts immediately.
- **Cleaning:** Clean the playset with mild soap and water as needed. Avoid harsh chemicals.

## Troubleshooting

If you encounter issues during assembly or use:

- **Missing or Damaged Parts:** Contact Backyard Discovery customer service immediately if any parts are missing or damaged upon arrival.
- **Assembly Difficulties:** Double-check the instruction manual and the BILT app for clarification.

Ensure all pieces are correctly oriented and hardware is properly installed.

- **Structural Stability:** Confirm the playset is on level ground and all anchors are secure. Uneven ground can affect stability.

## Specifications

### Product Specifications

Feature	Detail
Brand	Backyard Discovery
Model Number	2001022
Material	Cedar Wood
Product Dimensions (D x W x H)	135"D x 168.5"W x 103"H
Item Weight	21.16 Kilograms
Included Components	2 belt swings, 8 ft slide, all accessories, all hardware, all wood, canvas roof, snack bar, trapeze bar, windows, working door
Minimum Age Recommendation	36 Months
Maximum Age Recommendation	120 Months
Maximum Weight Recommendation	40 Kilograms
Required Assembly	Yes



Image: Dimensional diagrams showing the top and front views of the Lakewood Swing Set, including the recommended safe play zone.

## Warranty and Support

**Warranty Information:** This product comes with a 5-year limited warranty. For specific details regarding coverage and claims, please refer to the warranty documentation included with your purchase.

**Customer Support:** For assistance with parts, assembly, or any other inquiries, please visit the official Backyard Discovery store or contact their customer service directly.

[Visit the Backyard Discovery Store](#)