

CALEX 965254

CALEX 965254 Retro Pendant Lamp E27 Bronze

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the CALEX 965254 Retro Pendant Lamp. This instruction manual provides important information for the safe installation, operation, and maintenance of your new pendant lamp. Please read this manual thoroughly before installation and retain it for future reference.

The CALEX Retro Pendant Lamp features a bronze E27 fitting designed to accommodate lamps with a thicker neck and longer base. Its larger holder with two adjustable rings ensures a secure and proper fit for various E27 bulbs. The cord length is 2 meters.

2. Safety Instructions

- **Electrical Safety:** Installation must be performed by a qualified electrician or in accordance with local electrical codes. Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.
- **Bulb Compatibility:** Use only E27 base bulbs. Do not exceed the maximum wattage specified on the lamp holder (if applicable).
- **Handling:** Handle the lamp and bulb with care. Avoid dropping or subjecting them to impact.
- **Environment:** This lamp is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- **Cleaning:** Ensure the lamp is switched off and cool before cleaning. Use a soft, dry cloth.

3. Package Contents

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, do not proceed with installation and contact your retailer.

- 1x CALEX Retro Pendant Lamp, Bronze E27 fitting with 2-meter cord



This image shows the CALEX 965254 Retro Pendant Lamp, E27 Bronze fitting, packaged in its retail box. The box highlights the 'Cord set' and '1x E27' compatibility, along with the '2 METRES' cord length.

4. Setup and Installation

Follow these steps for proper installation:

1. **Prepare for Installation:** Turn off the main power supply to the installation area at the circuit breaker.
2. **Mount the Pendant:** Securely attach the pendant lamp's ceiling rose (not explicitly detailed in product info, assume standard mounting) to the ceiling junction box using appropriate screws and anchors. Ensure all electrical connections are made correctly (Live, Neutral, Earth) according to local wiring regulations.
3. **Insert the Bulb:** Carefully screw an E27 base bulb into the lamp holder. The bronze fitting features two adjustable rings; ensure they are positioned to securely hold the bulb's neck and base.
4. **Adjust Cord Length:** If necessary, adjust the cord length by shortening it within the ceiling rose or by using a cord grip.
5. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.

5. Operation

The CALEX Retro Pendant Lamp operates via a standard wall switch connected to its electrical circuit. Simply toggle the switch to turn the lamp on or off.

- **Bulb Replacement:** To replace the bulb, first turn off the power at the wall switch and, if possible, at the main circuit breaker. Allow the bulb to cool completely. Unscrew the old bulb and carefully screw in a new E27 bulb. Ensure the adjustable rings are correctly positioned for the new bulb.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your pendant lamp.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry, lint-free cloth to wipe the bronze fitting and cord. Do not use abrasive cleaners, solvents, or polishes, as these may damage the finish.
- **Inspection:** Periodically inspect the cord and fitting for any signs of wear or damage. If any damage is observed, discontinue use and consult a qualified electrician.

7. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not light up.	No power supply.	Check the circuit breaker and wall switch.
	Faulty bulb.	Replace the bulb with a new, working E27 bulb.
	Loose connection.	<i>(WARNING: Disconnect power first)</i> Check bulb seating and wiring connections. Consult an electrician if unsure.
Bulb flickers.	Loose bulb or incompatible bulb.	<i>(WARNING: Disconnect power first)</i> Tighten the bulb. Ensure the bulb is E27 and compatible with the lamp's specifications.

8. Specifications

- **Model:** CALEX 965254
- **Fitting Type:** E27
- **Material:** Glass (bulb not included), Bronze (fitting)
- **Color:** Bronze
- **Cord Length:** 2 meters
- **Voltage:** 240 Volt
- **Mounting Type:** Surface-mounted (Aufputz)
- **Country of Origin:** China
- **GTIN:** 08712879135357

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

