

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BoomPods](#) /

› [BoomPods Bassline True Wireless Earbuds User Manual](#)

BoomPods BASSLINE

BoomPods Bassline True Wireless Earbuds User Manual

Model: BASSLINE

Brand: BoomPods

INTRODUCTION

Thank you for choosing the BoomPods Bassline True Wireless Earbuds. These earbuds are designed to provide a seamless audio experience with advanced features for your daily listening needs. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

Key features include Bluetooth 5.0 connectivity, intuitive touch controls, a compact charging case for extended playtime, an ergonomic design for a secure fit, and IPX5 splash resistance, making them suitable for various activities.

SETUP

Package Contents

Before you begin, please ensure all items are present in the package:

- BoomPods Bassline True Wireless Earbuds (Left and Right)
- Portable Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Tips (Small, Medium, Large)
- User Manual



Image: The retail packaging of the BoomPods Bassline True Wireless Earbuds, showing the earbuds and charging case.

Initial Charging

For optimal performance, fully charge your earbuds and charging case before first use.

1. Place both earbuds into the charging case. Ensure they are correctly seated and the charging indicators light up.

2. Connect the USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).
3. The charging case indicators will show charging status. A full charge typically takes approximately 2 hours.



UP TO 20 HOURS WIRELESS PLAY
WITH CHARGING CASE

Image: The BoomPods Bassline earbuds resting inside their open charging case, illustrating the compact design and charging contacts. The image also highlights the "Up to 20 hours wireless play with charging case" feature.

Pairing with Your Device

The Bassline earbuds feature instant connection and Bluetooth 5.0 for stable pairing.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "BoomPods Bassline" from the list.
4. Once connected, you will hear an audible confirmation, and the earbud indicator lights will change.

Note: The earbuds support single earbud use. You can use either the left or right earbud independently after initial pairing.

auto pairing



Image: A graphic illustrating the "auto pairing" feature of the BoomPods Bassline earbuds, showing two earbuds with radiating Bluetooth signals and a Bluetooth 5.0 logo, emphasizing "pick up & play".

OPERATING INSTRUCTIONS

Wearing the Earbuds

The Bassline earbuds are designed for an in-ear secure fit. Choose the ear tips that provide the best seal and comfort for your ears. A proper fit enhances sound quality and noise isolation.



Image: A man wearing the BoomPods Bassline earbuds, demonstrating their discreet and ergonomic fit in the ears.

Touch Controls

The earbuds feature intuitive EasyTouch™ sensitive controls. The following actions can be performed by tapping the touch area on either earbud:

Action	Control
Play/Pause Audio	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud
Answer/End Call	Single tap on either earbud during a call
Reject Call	Press and hold on either earbud during an incoming call
Activate Voice Assistant	Press and hold on either earbud (when not on a call)



Image: A diagram illustrating the touch control points on the BoomPods Bassline earbuds, showing "in-ear secure fit", "EASYTOUCH™ finger touch control", "volume control", and "CLOSE MIC™".



EASYTOUCH™
touch control



CLOSEMIC™
clearer calls



VOLUME PLAY™
onboard control

Image: An overhead view of the BoomPods Bassline earbuds in their open charging case, highlighting key features such as "EASYTOUCH™ touch control", "CLOSEMIC™ clearer calls", and "VOLUME PLAY™ onboard control".

Water and Sweat Resistance (IPX5)

The Bassline earbuds are rated IPX5 for splash resistance, meaning they can withstand sweat and light splashes of water. They are suitable for workouts and outdoor activities. However, they are not designed for submersion in water.




Image: A man with sweat on his face, wearing the BoomPods Bassline earbuds, with "IPX4 SWEAT-PROOF" text and water droplet icons, demonstrating their resistance to sweat.

MAINTENANCE

Cleaning Your Earbuds

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- For ear tips, remove them from the earbuds and clean with a mild soap solution if necessary, then rinse and dry thoroughly before reattaching.
- Do not use abrasive cleaners or submerge the earbuds or case in water.

Battery Care and Charging Case

To maximize battery life and ensure consistent performance:

- Always store the earbuds in their charging case when not in use. This protects them and keeps them charged.

- Recharge the charging case regularly, especially if it will not be used for an extended period.
- Avoid exposing the earbuds and case to extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your BoomPods Bassline earbuds, please refer to the following common solutions:

Earbuds Not Pairing or Connecting

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device and then turn it back on.
- Forget "BoomPods Bassline" from your device's Bluetooth list and attempt to pair again.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to re-initiate pairing mode.

No Sound or Low Volume

- Check the volume level on both your device and the earbuds (using touch controls).
- Ensure the earbuds are properly seated in your ears and the ear tips provide a good seal.
- Clean any debris from the earbud speaker mesh.

Charging Issues

- Verify the charging cable is securely connected to both the case and the power source.
- Try a different USB port or charging adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

SPECIFICATIONS

Feature	Detail
Model Name	BASSLINE
Connectivity Technology	Wireless, Bluetooth 5.0
Water Resistance Level	IPX5 (Splash Resistant)
Control Type	Touch Control
Battery Life (Earbuds)	Up to 4.5 Hours
Total Playtime with Case	Up to 20 Hours

Feature	Detail
Charging Time	Approximately 2 Hours
Bluetooth Range	10 Meters
Frequency Range	20Hz-20kHz
Material	Silicone, Plastic
Item Weight	4.2 ounces
Product Dimensions	2.76 x 1.38 x 0.98 inches

WARRANTY AND SUPPORT

BoomPods products are manufactured to the highest standards and undergo rigorous testing. For information regarding warranty coverage and customer support, please refer to the warranty card included in your product packaging or visit the official BoomPods website.

For further assistance or technical support, please contact BoomPods customer service through their official channels. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: www.boompods.com