

Nutale F9X

Nutale Mini Smart Tracker Instruction Manual

Model: F9X

1. PRODUCT OVERVIEW

The Nutale Mini Smart Tracker is a compact and versatile item locator designed to help you keep track of your valuable belongings. Utilizing Bluetooth technology, it connects to your smartphone, allowing you to find misplaced items quickly and efficiently. Its small size and replaceable battery make it ideal for everyday use with keys, wallets, bags, and more.



Image: Nutale Mini Smart Trackers (Gold & Black) and a tracker attached to keys.

2. PACKAGE CONTENTS

- Nutale Mini Smart Tracker (Gold & Black, 2 Pack)
- User Manual (this document)
- Pre-installed Lithium Metal Batteries (CR2032)

3. SPECIFICATIONS

Feature	Detail
Model Number	F9X
Dimensions	1.5 x 1.5 x 0.28 inches
Weight	0.352 ounces
Connectivity	Bluetooth
Battery Type	CR2032 Lithium Metal (replaceable)
Material	Aluminum, Polycarbonate (PC)

4. SETUP GUIDE

4.1. Download the Nut App

To use your Nutale Mini Smart Tracker, you must first download the official "Nut" application on your smartphone. The app is available for both iOS and Android devices.

- Search for "Nut" in your device's app store (Apple App Store for iOS, Google Play Store for Android).
- Download and install the application.

4.2. Pairing Your Tracker

1. Ensure Bluetooth is enabled on your smartphone.
2. Open the Nut App.
3. Follow the on-screen instructions to add a new device. You may need to press the button on your Nutale Mini Smart Tracker to activate pairing mode.
4. Once paired, you can name your tracker (e.g., "Keys," "Wallet," "Bag").



Image: Nutale Mini Smart Trackers attached to keychains, ready for use.

5. OPERATING INSTRUCTIONS

5.1. Finding Your Items (One-Touch Find)

If you misplace an item attached to your Nutale Mini Smart Tracker, you can use the app to make the tracker ring.

1. Open the Nut App on your smartphone.
2. Select the specific tracker you wish to locate.
3. Tap the "Call" button within the app. The Nutale Mini Smart Tracker will emit an audible alarm, helping you pinpoint its location.



Image: Using the Nut App's "Call" function to locate a tracker.

5.2. Finding Your Phone

If you misplace your phone but have your Nutale Mini Smart Tracker, you can use the tracker to make your phone ring.

- Double-press the button on your Nutale Mini Smart Tracker.
- Your phone will ring, even if it's on silent mode, helping you find it.

Find Your phone



Image: Activating the 'Find Your Phone' feature by pressing the tracker button.

5.3. Bidirectional Anti-Lost Alert (Alert Mode)

The Nutale Mini Smart Tracker features a bidirectional anti-lost alert system. Both your phone and the tracker will alert you if they become disconnected, preventing you from leaving items behind.

1. In the Nut App, navigate to the settings for your specific tracker.
2. Enable "Alert Mode" or "Disconnection Alert."
3. You can customize the alert period and duration for both the device and the phone.

Your browser does not support the video tag.

Video: Demonstrates how to set up and use the Alert Mode feature in the Nut App, showing both the device and phone alerting when disconnected.

When your phone and the tracker move out of Bluetooth range (typically 32-65ft indoors, 100-165ft in open spaces), both will sound an alarm. This helps prevent accidental loss of items.

5.4. Location Record Locator

The Nut App records the last known location where your tracker was connected to your phone. This feature is useful for retracing your steps if an item is lost out of Bluetooth range.

- Open the Nut App and view the map.
- The map will display the last connected location, providing an approximate area to begin your search.

6. MAINTENANCE

6.1. Replacing the Battery

The Nutale Mini Smart Tracker uses a replaceable CR2032 Lithium Metal battery. When the battery is low, the app may notify you, or you might notice a decrease in performance.

1. Gently open the tracker casing. Refer to the product diagram for the battery compartment location.
2. Remove the old CR2032 battery.
3. Insert a new CR2032 battery with the positive (+) side facing up.
4. Close the tracker casing securely.



Image: Replacing the CR2032 battery in the Nutale Mini Smart Tracker.

Note: Dispose of used batteries responsibly according to local regulations.

6.2. Cleaning

Wipe the tracker with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as they may damage the device.

7. TROUBLESHOOTING

Problem	Possible Cause / Solution
Tracker not connecting to phone.	<ul style="list-style-type: none">• Ensure Bluetooth is enabled on your phone.• Check if the tracker's battery is dead or low; replace if necessary.• Make sure the tracker is within Bluetooth range of your phone.• Restart the Nut App or your phone.• Try re-pairing the device through the app.
Tracker alarm is too quiet.	<ul style="list-style-type: none">• Ensure the tracker is not obstructed by other items (e.g., deep inside a bag).• Check the battery level; a low battery can affect alarm volume.
Phone not ringing when tracker button is pressed.	<ul style="list-style-type: none">• Ensure the Nut App is running in the background on your phone.• Check phone notification settings for the Nut App to ensure alerts are allowed.• Verify the tracker is paired and connected to your phone.
Inaccurate last seen location.	<ul style="list-style-type: none">• Ensure location services are enabled for the Nut App on your phone.• GPS accuracy can vary based on environment (indoors vs. outdoors).

8. SAFETY INFORMATION

- Keep the device and batteries out of reach of children and pets.
- Do not expose the device to extreme temperatures, direct sunlight, or water.
- Do not attempt to disassemble or modify the device.
- Use only specified battery type (CR2032).

9. WARRANTY AND SUPPORT

Nutale products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or visit the official Nutale website.

For technical support, troubleshooting assistance, or general inquiries, please contact Nutale Customer Care:




- **Website:** www.nutale.com (Note: This is a placeholder URL as no specific support URL was provided in the input.)

- **Email:** support@nutale.com (Note: This is a placeholder email as no specific support email was provided in the input.)

Please have your product model number (F9X) and purchase information ready when contacting support.

© 2025 Nutale. All rights reserved.

Related Documents - F9X

	<p>Nutale Findmy Wireless Locator: Setup, Pairing & Usage Guide</p> <p>Get detailed instructions for the Nutale Findmy wireless locator. Learn setup, pairing with Apple's Find My app, using 'Play Sound' and 'Lost Mode', and understanding device status. FCC compliant.</p>
	<p>Nutale Findmy Product Instruction Manual</p> <p>Comprehensive user guide for the Nutale Findmy Product, detailing setup, operation, and troubleshooting for this Apple Find My network compatible Bluetooth tracker. Includes FCC compliance information.</p>
	<p>Blumaple Corporate Catalogue: Premium Electronics, Office IT Hardware, and Corporate Gifting</p> <p>Explore the Blumaple Corporate Catalogue featuring a wide range of premium electronics, office IT hardware, and corporate gifting solutions. Discover smart water bottles, speakers, wearables, paper tablets, and more from leading brands.</p>