Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aigostar B30101I3C

Aigostar Smart Tower Fan User Manual

Model: B30101I3C

1. Product Overview

The Aigostar Smart Tower Fan is designed to provide efficient and comfortable air circulation for your home or office. It features a powerful airflow, multiple operating modes, adjustable speeds, and smart connectivity options for convenient control. Its sleek, space-saving design integrates seamlessly into any room.



Image: The Aigostar Smart Tower Fan, a tall black unit, is shown alongside its remote control and a smartphone displaying the AigoSmart app interface. This illustrates the various control methods available for the fan.

2. Safety Information

Please read all safety instructions carefully before using this appliance. Failure to follow these instructions may result in

electric shock, fire, or serious injury.

- Always ensure the power supply matches the voltage specified on the rating label.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug the fan from the outlet when not in use, when moving it from one location to another, and before cleaning.
- Do not operate any fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.
- Keep children and pets away from the fan during operation.
- Do not insert fingers or foreign objects into any openings of the fan.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not block air openings or operate near curtains or other objects that may block airflow.

3. Package Contents

Verify that all items are present in the package:

- Aigostar Smart Tower Fan Unit
- Base Assembly (if separate)
- Remote Control
- User Manual

4. Setup

Follow these steps to set up your Aigostar Smart Tower Fan:

1. **Base Assembly:** If the base is separate, align the fan body with the base and secure it according to the instructions provided in the packaging. Typically, this involves twisting or clicking the fan body onto the base until it locks.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for optimal airflow and oscillation.
3. **Power Connection:** Plug the power cord into a standard electrical outlet.
4. **Initial Power On:** The fan is now ready for operation. You can power it on using the control panel on top of the fan, the remote control, or the AigoSmart app.



Image: The Aigostar Smart Tower Fan is shown in a room setting, with a hand holding a smartphone displaying the AigoSmart app. Logos for Amazon Alexa and Google Assistant are visible, indicating smart home compatibility. This image highlights the fan's smart features and ease of setup with mobile devices.

5. Operating Instructions

Your Aigostar Smart Tower Fan offers multiple ways to control its functions.

5.1 Control Panel and Remote Control



Image: A detailed view of the Aigostar Smart Tower Fan's LED display, showing temperature and mode indicators, alongside its remote control. This illustrates the primary physical control methods for the fan.

- **Power On/Off:** Press the **ON/OFF** button on the control panel or remote to turn the fan on or off.
- **Speed Adjustment:** Press the **SPEED** button to cycle through Low, Medium, and High fan speeds. The LED display will indicate the current speed setting.
- **Mode Selection:** Press the **MODE** button to switch between the following modes:
  - **Normal Mode:** Provides continuous airflow at a constant speed.
  - **Natural Mode:** Simulates natural breeze by varying fan speed at intervals.
  - **Night Mode:** Gradually reduces fan speed over time to a minimum setting for quiet operation during sleep. Note: This mode is not inherently quieter than others, but adjusts for comfort.
- **Oscillation:** Press the **SWING** button to activate or deactivate the 70° oscillation feature, distributing air across a wider area.
- **Timer:** Press the **TIMER** button to set the fan to automatically turn off after a specified period, up to 24 hours. Each press typically increases the timer by one hour.



Image: A visual representation of the three operating modes (Night, Natural, Normal) and three speed settings (Low, Medium, High) of the Aigostar Smart Tower Fan. This helps users understand the different airflow patterns and intensity options.



Image: A scene depicting a child sleeping peacefully, with the Aigostar Smart Tower Fan in the background. Icons indicate a 24-hour timer, noise level of ≤55 dB, and a display-off feature, emphasizing the fan's quiet operation and suitability for nighttime use.



Image: A graphic illustrating the 70-degree oscillation feature of the Aigostar Smart Tower Fan, showing the wide area of air distribution. This highlights the fan's ability to cool a larger space effectively.

5.2 Smart Control (App, Alexa, Google Home)

The Aigostar Smart Tower Fan can be controlled remotely via the "AigoSmart" app and integrated with voice assistants.

1. **Download App:** Download the "AigoSmart" app from your smartphone's app store (iOS or Android).
2. **Pairing:** Follow the in-app instructions to pair your fan using WiFi (2.4G only) and Bluetooth. Ensure your fan is in pairing mode.
3. **App Functions:** Once connected, you can control all fan functions (power, speed, mode, oscillation, timer) from anywhere. You can also program the 24-hour timer more precisely through the app.
4. **Voice Control Setup:**
    - Open your Alexa or Google Home app.
    - Enable the "AigoSmart" skill/service.
    - Link your AigoSmart account.

- Discover devices. Your Aigostar Smart Tower Fan should now be controllable via voice commands.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your fan.

- **Cleaning:**
  - Always unplug the fan before cleaning.
  - Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
  - For dust accumulation on the air intake or outlet grilles, use a vacuum cleaner with a brush attachment to gently remove dust.
  - Do not allow water to drip into the interior of the fan.
- **Storage:**
  - If storing the fan for an extended period, clean it thoroughly.
  - Store it in its original packaging or a suitable box in a cool, dry place.
  - Avoid placing heavy objects on top of the fan during storage.

7. Troubleshooting

If you encounter issues with your Aigostar Smart Tower Fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Power cord not properly plugged in; Power outlet malfunction.	Check if the fan is plugged into a working outlet. Try a different outlet. Ensure the power button is pressed.
Weak airflow.	Fan speed is too low; Air intake/outlet blocked; Dust accumulation.	Increase the fan speed. Ensure no obstructions are blocking the grilles. Clean the fan grilles.
Fan is noisy.	Fan not on a level surface; Internal components loose; Dust inside.	Place the fan on a flat, stable surface. If noise persists, clean the fan. If the noise is unusual or loud, discontinue use and contact support.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and fan.	Replace the batteries in the remote control. Ensure there is a clear line of sight between the remote and the fan's receiver.
App/Voice control not connecting.	Incorrect WiFi network (not 2.4G); Fan not in pairing mode; App/skill not properly linked.	Ensure your WiFi is 2.4G. Re-enter pairing mode on the fan. Re-link the AigoSmart app/skill in your smart home assistant. Check your internet connection.

8. Specifications

Feature	Detail
Brand	Aigostar
Model Number	B30101I3C
Dimensions (Product)	29.9 cm (L) x 29.9 cm (W) x 103 cm (H)

Feature	Detail
Package Dimensions	108 x 23.5 x 21.5 cm; 5.58 kg
Fan Design	Tower Fan (Floor Fan)
Power Source	Corded Electric
Special Feature	Smart Tower Fan (WiFi+Bluetooth, App Control, Alexa, Google Home)
Modes	Normal, Natural, Night
Speeds	3 (Low, Medium, High)
Oscillation	70°
Timer	Up to 24 hours
Noise Level	Approx. 55 dB (at maximum speed)
Recommended Use	Cooling, Ventilation (suitable for Bedroom, Living Room, Office, Kitchen)



Image: The Aigostar Smart Tower Fan is depicted in a room, highlighting its compact and portable design. Dimensions (40 inches height, 10.2 inches base) are shown, along with an inset image of a hand using the integrated handle for easy transport.

9. Warranty and Support

Aigostar products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty. For warranty claims, technical support, or any inquiries regarding your product, please contact Aigostar customer service. Refer to the contact information provided on the Aigostar official website or your purchase documentation.

Website: www.aigostar.com (This is a placeholder link, please refer to actual brand website for support)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081DW8DFK

More documents and user manuals: **https://manuals.plus/**