Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Altec Lansing ASH-100-WAL

Altec Lansing Voice Activated Smart Security System

Instruction Manual

Model: ASH-100-WAL

1. Overview

The Altec Lansing Voice Activated Smart Security System is a comprehensive home monitoring solution. This bundle includes a Google portable speaker and a panoramic full HD camera, designed to provide security and smart home integration.
Key features of the system include:

- Voice-activated speaker with Wi-Fi and Bluetooth connectivity.
- Integrated Google Assistant for interactive voice commands.
- Panoramic full HD camera with 360-degree view.
- Digital pan-tilt-zoom functionality for camera control.
- Two-way intercom for communication.
- Motion detection with alerts.
- Compatibility with Chromecast for video streaming.

2. Product Components



Front view of the Altec Lansing Smart Security System, showcasing the Google Live speaker and the panoramic HD camera.



Rear view of the speaker and camera, highlighting the power input and control buttons on the speaker, and the mounting bracket on the camera.



Top panel of the speaker showing volume and playback controls, and the bottom of the camera revealing its power port.



The panoramic HD camera positioned on a bedside table, demonstrating its compact size and discreet design within a home environment.



Front of the product packaging, illustrating key features such as Google Assistant integration,

easy setup, and the full HD camera.



Back of the product packaging, detailing the camera's extra-wide panoramic view, remote video monitoring, home security features, 2-way video/audio, and Chromecast streaming capabilities.

3. Setup

Follow these steps to set up your Altec Lansing Smart Security System:

1. **Download the App:** Download the Google Home app and the Smart Security System app from your device's app store.
2. **Power On:** Connect both the speaker and the camera to their respective power sources using the provided adapters.
3. **Initial Pairing:** Open the Google Home app and follow the on-screen instructions to set up the Google Live speaker. Ensure your mobile device is connected to your home Wi-Fi network.
4. **Camera Setup:** Open the Smart Security System app. Follow the in-app instructions to add and configure your panoramic HD camera. This typically involves scanning a QR code on the camera or entering a device ID.
5. **Wi-Fi Connection:** Ensure both devices are connected to a stable 2.4GHz Wi-Fi network for optimal performance.

4. Operating Instructions

Once set up, you can utilize the full range of features:

- **Voice Control (Speaker):** Use voice commands with Google Assistant. Say "Hey Google" followed by your command to play music, get information, control smart home devices, and more.
- **Live Camera View:** Access the live feed from your camera through the Smart Security System app.
- **Pan-Tilt-Zoom:** Within the app, use the digital controls to pan, tilt, and zoom the camera's view to monitor different areas.
- **Two-Way Intercom:** Use the microphone and speaker functions in the app to communicate with individuals near the camera.
- **Motion Detection:** Configure motion detection alerts in the Smart Security System app to receive notifications when movement is detected.
- **Chromecast Streaming:** Stream the camera's live video feed to a Chromecast-enabled display by using voice commands or the Google Home app.

5. Maintenance

To ensure the longevity and optimal performance of your security system, consider the following maintenance tips:

- **Cleaning:** Gently wipe the exterior of the speaker and camera with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Software Updates:** Regularly check for and install firmware updates for both the speaker (via Google Home app) and the camera (via Smart Security System app) to ensure you have the latest features and security patches.
- **Network Stability:** Ensure your Wi-Fi network is stable and strong where the devices are placed to prevent connectivity issues.
- **Placement:** Position the camera and speaker in areas where they are protected from extreme temperatures, direct sunlight, and moisture.

6. Troubleshooting

If you encounter issues with your Altec Lansing Smart Security System, try the following solutions:

Problem	Possible Solution
Device not connecting to Wi-Fi	Ensure your Wi-Fi password is correct. Check if the device is within range of your router. Restart your router and the device. Confirm you are connecting to a 2.4GHz network.
Google Assistant not responding	Ensure the speaker is powered on and connected to Wi-Fi. Check the microphone mute button on the speaker. Speak clearly and directly to the speaker.
Camera live view is blurry or black	Check the camera lens for dirt or obstructions. Ensure adequate lighting in the room. Verify the camera has a stable internet connection. Restart the camera.
Motion detection alerts not received	Check app notification settings on your phone and within the Smart Security System app. Ensure motion detection is enabled in the camera settings.
Two-way intercom audio issues	Ensure your phone's microphone and speaker are working. Check the volume levels on both your phone and the app. Verify the camera's microphone and speaker are not obstructed.

If problems persist, refer to the support section or contact customer service.

7. Specifications

Feature	Detail
Brand	Altec Lansing
Model Name	ASH-100-WAL
Connectivity Technology	Wireless (Bluetooth, Wi-Fi)
Power Source	Corded Electric

Feature	Detail
Controller Type	Google Assistant
Video Capture Resolution	1080p Full HD
Field Of View	360 Degrees
Zoom Type	Digital Zoom
Alert Type	Motion Only
Item Dimensions (L x W x H)	10 x 4 x 8 inches
Item Weight	2 Pounds
Batteries Required	Yes (1 Lithium Ion battery included)
Wattage	10 watts
International Protection Rating	IP54

8. Warranty Information

The Altec Lansing Voice Activated Smart Security System comes with a**1-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
For detailed warranty terms and conditions, please refer to the documentation included with your product or visit the official Altec Lansing website.

9. Support

For further assistance, technical support, or customer service inquiries regarding your Altec Lansing Voice Activated Smart Security System, please:

- Visit the official Altec Lansing website for FAQs, support articles, and contact information.
- Refer to the help sections within the Google Home app or the Smart Security System app.
- Contact Altec Lansing customer support directly through their provided channels.

© 2024 Altec Lansing. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081G7H52N

More documents and user manuals: **https://manuals.plus/**