Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SANODESK EZ1B-EU

SANODESK EZ1 Electric Height Adjustable Desk User Manual

Model: EZ1B-EU

Introduction

Welcome to the user manual for your SANODESK EZ1 Electric Height Adjustable Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read it thoroughly before use.

Safety Information

Adhering to these safety guidelines will ensure safe operation and prolong the life of your desk.

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during height adjustment.
- Do not overload the desk beyond its specified weight capacity (80 kg).
- The desk features an anti-collision function. Do not intentionally obstruct the desk's movement.
- Disconnect power before cleaning or maintenance.
- Avoid placing liquids directly on the control panel or motor components.

Package Contents

Please verify that all components are present before beginning assembly.

- Desk Frame (Legs, Crossbar, Feet)
- Control Panel
- Motor
- Power Adapter and Cable
- Assembly Hardware (Screws, Allen Keys, etc.)
- User Manual (this document)

Note: Tabletop is sold separately and is not included with the frame package.

Setup and Assembly

The SANODESK EZ1 is designed for quick and easy assembly. Follow these steps for a smooth setup.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Legs and Crossbar:** Attach the desk legs to the central crossbar using the provided hardware. Ensure all connections are firm.
3. **Attach Feet:** Secure the foot supports to the bottom of each leg.
4. **Install Motor and Control Panel:** Mount the motor and control panel according to the detailed instructions in the included assembly guide. Connect all necessary cables.
5. **Attach Tabletop (Sold Separately):** Place your chosen tabletop onto the assembled frame. Align it properly and secure it using appropriate screws (not included with frame).
6. **Cable Management:** Organize cables to prevent tangling and ensure free movement of the desk.



Image: The SANODESK EZ1 electric height adjustable desk frame, showing the legs, crossbar, and motor assembly.



Image: An exploded view demonstrating the simple assembly process of the SANODESK EZ1 desk, with the tabletop separated from the frame.

Tabletop Compatibility: The desk frame is designed to accommodate tabletops ranging from 100 cm to 160 cm in width and 50 cm to 80 cm in depth.



Image: Diagram illustrating the compatible tabletop dimensions for the SANODESK EZ1 desk frame, showing minimum and maximum widths and depths.

Operating Instructions

Your SANODESK EZ1 desk features an intuitive control panel for easy height adjustment and personalized settings.

Basic Operation

- **Adjusting Height:** Use the **Up** and **Down** buttons on the control panel to smoothly raise or lower the desk to your desired height. The desk adjusts from 71 cm to 116 cm.
- **Smooth Start/Stop:** The desk features a soft start and stop function for stable and quiet movement.



Image: Two SANODESK EZ1 desks, one at its minimum height of 710mm and another at its maximum height of 1160mm, illustrating the adjustable range.

Advanced Features

- **Memory Presets:** The control panel allows you to save up to three preferred height settings. To set a memory position:
    a. Adjust the desk to your desired height.
    b. Press the "M" button, then press one of the numbered preset buttons (1, 2, or 3) to save the current height.
    c. To recall a saved height, simply press the corresponding numbered preset button.
- **Anti-Collision Function:** The desk is equipped with an anti-collision system. If the desk encounters an obstacle during adjustment, it will automatically stop and reverse slightly to prevent damage.
- **Child Safety Lock:** The control panel includes a child safety lock feature to prevent accidental adjustments. Refer to the detailed assembly guide for instructions on activating and deactivating this function.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your SANODESK EZ1 desk.

- **Cleaning:** Wipe the desk surfaces and frame with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Cable Inspection:** Periodically check all cables for wear or damage. Ensure they are not pinched or tangled.
- **Fastener Check:** Occasionally inspect all screws and fasteners to ensure they remain tight. Tighten if necessary.
- **Motor Care:** The motor is designed for maintenance-free operation. Do not attempt to open or lubricate the motor housing.

Troubleshooting

If you encounter issues with your SANODESK EZ1 desk, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Child safety lock active; Overload.	Check power connection; Deactivate child safety lock; Reduce weight on desk.
Desk moves unevenly or makes unusual noise.	Loose fasteners; Obstruction; Uneven weight distribution.	Check and tighten all fasteners; Remove any obstructions; Distribute weight evenly.
Anti-collision function triggers frequently.	Obstruction in path; Sensitivity setting too high (if adjustable).	Ensure clear path for desk movement; Refer to assembly guide for collision sensitivity adjustment.

If the problem persists, please contact SANODESK customer support.

Specifications

Model: EZ1B-EU

Brand: SANODESK

Height Adjustment Range: 71 cm to 116 cm (without tabletop)

Compatible Tabletop Width: 100 cm to 160 cm

Compatible Tabletop Depth: 50 cm to 80 cm

Static Load Capacity: 80 kg

Material: Alloy Steel (Frame)

Features: Electric height adjustment, Anti-collision, Memory presets, Child safety lock, Smooth start/stop.

Weight: Approximately 16 kg (frame only)



Image: A SANODESK EZ1 desk with a 80kg weight placed on its tabletop, demonstrating its robust load capacity.

Warranty and Support

SANODESK is committed to providing high-quality ergonomic products.

- **Motor and Controller Warranty:** 3 years
- **Desk Frame Warranty:** 5 years

For technical assistance, warranty claims, or any questions regarding your SANODESK EZ1 desk, please contact SANODESK customer support through their official channels. Refer to your purchase documentation for specific contact details.
SANODESK products undergo rigorous testing, including over 20,000 fatigue tests, and hold European certifications such as CE and TUV.

Important Notes

- This manual covers the SANODESK EZ1 electric height adjustable desk frame. Tabletop is not included and must be purchased separately.
- Always refer to the detailed assembly instructions provided in the product packaging for specific step-by-step guidance.



Image: A SANODESK EZ1 electric height adjustable desk with a black tabletop, set up in a modern office environment with a monitor and laptop.




Image: The SANODESK brand logo alongside an overview of their standing desk products in a minimalist setting.

© 2023 SANODESK. All rights reserved.
For the latest information and support, please visit the official SANODESK website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081GGZ1VK

More documents and user manuals: **https://manuals.plus/**