Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DROP DT 177X GO

DROP + Beyerdynamic DT 177X GO Over-Ear Closed-Back Headphones User Manual

Model: DT 177X GO

Introduction

The DROP + Beyerdynamic DT 177X GO headphones are designed for high-fidelity audio reproduction. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your headphones to ensure optimal performance and longevity.



Image: Front view of the DROP + Beyerdynamic DT 177X GO headphones.

Setup

1. **Attach the Audio Cable:** Locate the mini-XLR connector on the headphone's left earcup. Align the cable's connector with the port and push firmly until it clicks into place. Ensure a secure connection.



Image: The detachable audio cable connected to the left earcup.

2. **Select Earpads:** The DT 177X GO comes with two types of premium ear pads: sheepskin and velour. To change them, gently twist and pull off the installed earpad. Align the new earpad with the earcup and press it around the rim until it is securely seated.



Image: The headphones with both sheepskin and velour earpads, and the audio cable.

3. **Connect to Audio Source:** Plug the 3.5mm end of the audio cable into your desired audio device (smartphone,

tablet, laptop, audio interface, etc.). An included 1/8–1/4 inch (3.5–6.35 mm) adapter is provided for devices with a larger jack.

Operating Instructions

- **Wearing the Headphones:** Adjust the headband so the earcups sit comfortably over your ears. The closed-back design provides passive noise isolation. The headphones are designed for extended wear comfort.



Image: A person wearing the headphones while listening to music on a smartphone.

- **Volume Control:** Control the audio volume directly from your connected audio source. Start with a low volume and gradually increase it to a comfortable listening level.
- **Sound Characteristics:** These headphones feature 45-millimeter Tesla drivers, offering a wide frequency range and controlled bass response. With a 32-ohm impedance, they are easily driven by portable devices without requiring a dedicated amplifier.

Maintenance

- **Cleaning Ear Pads:** Regularly clean the ear pads with a soft, dry cloth. For deeper cleaning, refer to the specific care instructions for sheepskin and velour materials. Avoid harsh chemicals.
- **Headband Cleaning:** Wipe the headband with a soft, slightly damp cloth. Ensure no moisture enters the internal components.
- **Cable Care:** The detachable cable should be handled with care. Avoid sharp bends or excessive pulling. If the cable retains its coiled shape, gently try to straighten it over time, but avoid aggressive force.
- **Storage:** Store the headphones in a clean, dry place away from extreme temperatures and direct sunlight. If a carrying case is available, use it to protect the headphones during transport.

Troubleshooting

Problem	Possible Cause / Solution
No sound or low volume	Ensure the audio cable is securely connected to both the headphones and the audio source. Check the volume level on your audio source. Test with a different audio source or cable to rule out component failure.
Sound is muddy or lacks clarity	Ensure the ear pads are correctly installed and sealed around your ears. Consider using the sheepskin ear pads for a potentially different bass response. If using an equalizer, try adjusting settings or resetting to default. Poorly recorded or mastered audio may also sound less clear.
Physical damage to components (e.g., headband mechanism)	Discontinue use to prevent further damage. Contact customer support or refer to the warranty section for repair or replacement options.
Cable kinks or does not straighten	Store the cable loosely coiled. Over time, the cable may relax. Avoid forcing it straight.

Specifications

- **Model:** DT 177X GO
- **Brand:** DROP
- **Ear Placement:** Over Ear
- **Form Factor:** Over Ear
- **Impedance:** 32 ohm
- **Connectivity Technology:** Wired
- **Headphone Jack:** 3.5 mm Jack (mini-XLR to 3.5mm detachable cable)
- **Audio Driver Type:** Dynamic Driver
- **Audio Driver Size:** 45 millimeters
- **Frequency Range:** 5 Hz – 40 kHz
- **Noise Control:** Sound Isolation (Passive)
- **Enclosure Material:** Aluminum, Sheepskin, Velour
- **Item Weight:** 414 g
- **Product Dimensions:** 23.4 x 22.2 x 11.5 cm
- **Country of Origin:** Germany
- **Included Accessories:** Pair of sheepskin ear pads, Pair of velour ear pads, 1/8–1/4 inch (3.5–6.35 mm) adapter

Warranty Information

The DROP + Beyerdynamic DT 177X GO headphones are covered by a**Massdrop 2-year Warranty**. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the official DROP website or contact customer support.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact DROP customer support through their official website. Provide your product model number (DT 177X GO) and a detailed description of the issue for efficient service.

For additional resources and community discussions, you may visit the official DROP website: drop.com

© 2026 DROP. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081GJWSPQ

More documents and user manuals: **https://manuals.plus/**