

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Ibergrif](#) /

> [Ibergrif M22117 Kitchen Tap User Manual: Installation, Operation, and Maintenance Guide](#)

Ibergrif M22117

Ibergrif M22117 Kitchen Tap User Manual

Brushed Bronze Double Handle Mixer with High Spout

1. PRODUCT OVERVIEW

The Ibergrif M22117 is a high-quality kitchen tap featuring a high spout and a double-handle mixer design. It is finished in brushed bronze, offering both durability and a distinctive aesthetic. This tap is designed for single-hole, deck-mounted installation and includes a durable ceramic cartridge for extended lifespan.



Image 1.1: The Ibergrif M22117 kitchen tap, showcasing its high spout and double handle design in a brushed bronze finish.

2. PACKAGE CONTENTS

Before beginning installation, please verify that all components are present and undamaged.

- 1 x Ibergrif M22117 Kitchen Faucet
- 1 x Installation Kit (includes mounting hardware)
- 2 x 40 cm G3/8 Inch Hose Pipes
- Instruction Manual



Image 2.1: All components included in the package, including the faucet, hoses, and mounting hardware.

3. SETUP AND INSTALLATION

This faucet is designed for single-hole, deck-mounted installation. Ensure you have the necessary tools before starting (e.g., adjustable wrench, screwdriver, plumber's tape).

1. **Preparation:** Turn off the main water supply to your kitchen. Clear the area under the sink and remove any existing faucet. Clean the mounting surface.
2. **Mounting the Faucet:** Insert the faucet body into the single mounting hole on your sink or countertop. Ensure the base gasket is correctly positioned between the faucet and the mounting surface to prevent leaks.
3. **Securing the Faucet:** From underneath the sink, slide the rubber washer, metal washer, and mounting nut onto the threaded shank of the faucet. Tighten the mounting nut securely using the provided installation kit.
4. **Connecting Water Hoses:** Attach the two G3/8 inch hose pipes to the corresponding hot and cold water inlets on the faucet's threaded shank. Hand-tighten first, then use a wrench to tighten an additional quarter turn. Connect the other ends of the hoses to your hot and cold water supply lines. Ensure connections are secure to prevent leaks.

5. **Testing:** Slowly turn on the main water supply. Check all connections for leaks. Operate both handles to ensure proper water flow and temperature control.



Image 3.1: Detailed view of the faucet's underside, showing the threaded shank and mounting hardware for secure installation.

4. OPERATING INSTRUCTIONS

The Ibergrif M221 17 features a double-handle design for precise control over water temperature and flow.

- **Cold Water:** Turn the right handle counter-clockwise to open the cold water supply.
- **Hot Water:** Turn the left handle counter-clockwise to open the hot water supply.
- **Temperature Control:** Adjust both handles simultaneously to achieve the desired water temperature.
- **Flow Control:** The further the handles are turned, the greater the water flow.



Image 4.1: The kitchen tap in operation, demonstrating water flow from the high spout.

5. MAINTENANCE AND CARE

Proper maintenance will ensure the longevity and appearance of your Ibergrif kitchen tap.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the brushed bronze finish.
- **Aerator Maintenance:** If water flow decreases or becomes irregular, the aerator at the end of the spout may be clogged. Unscrew the aerator, clean any debris, and rinse it before reattaching.
- **Ceramic Cartridge:** The faucet is equipped with a durable ceramic cartridge. In case of persistent drips or leaks from the handles, the cartridge may need to be replaced. Consult a professional plumber if you are unsure.



Image 5.1: A close-up view of the aerator at the end of the high spout, which can be removed for cleaning.

6. TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves; kinked supply lines.	Clean the aerator; ensure shut-off valves are fully open; check supply lines for kinks.
Leaking from Spout	Worn ceramic cartridge.	Replace the ceramic cartridge.
Leaking at Base	Loose mounting nut; improperly seated gasket.	Tighten mounting nut; re-seat gasket.

Problem	Possible Cause	Solution
No Hot/Cold Water	Supply valve closed; issue with water heater (for hot water).	Check corresponding supply valve; verify water heater operation.

7. SPECIFICATIONS

Brand	Ibergrif
Model Number	M22117
Product Type	Kitchen Tap with High Spout, Double Handle Mixer
Finish	Brushed Bronze
Material	Bronze (faucet body), Ceramic (handle material)
Installation Method	Single Hole, Deck Mount
Number of Handles	2
Product Dimensions	36 x 23 x 6 cm
Item Weight	2.25 kg
Hose Pipe Connection	G3/8 Inch (2 x 40 cm hoses included)
Special Features	Durable ceramic cartridge

UNIT:MM




Image 7.1: Technical drawing illustrating the dimensions of the Ibergrif M22117 kitchen tap in millimeters.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.