



Manuals.plus /

› **Beyblade** /

› Beyblade Burst Rise Hypersphere Harmony Pegasus P5 Starter Pack Instruction Manual

Beyblade E7719

Beyblade Burst Rise Hypersphere Harmony Pegasus P5 Starter Pack Instruction Manual

Model: E7719

[Product Overview](#)

[Safety Information](#)
[Troubleshooting](#)

[Setup & Assembly](#)
[Specifications](#)

[Operating Instructions](#)
[Warranty & Support](#)

[Maintenance](#)

1. PRODUCT OVERVIEW

The Beyblade Burst Rise Hypersphere Harmony Pegasus P5 Starter Pack provides a complete battling top experience. This set includes one right-spin Beyblade Burst Hypersphere top, Harmony Pegasus P5, and one Hypersphere left/right-spin launcher. The top is designed with Hypersphere technology, featuring a specialized Performance Tip that allows it to climb the vertical wall of a Hypersphere Beystadium (sold separately) and drop in on opponents for dynamic battles.

Included Components:

- 1x Beyblade Burst Hypersphere Harmony Pegasus P5 Battling Top (consisting of Energy Layer, Forge Disc, and Performance Tip)
- 1x Beyblade Burst Hypersphere Left/Right-Spin Launcher



Image 1.1: The Beyblade Burst Rise Hypersphere Harmony Pegasus P5 Starter Pack, showing the Harmony Pegasus P5 battling top and the Hypersphere launcher in their packaging.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.

- Always use Beyblade Burst tops and launchers with an official Beyblade Burst Beystadium (sold separately).
- Do not lean over the Beystadium when tops are in battle.
- Do not launch tops at people or animals.
- Ensure all components are securely assembled before launching.
- Keep small parts away from young children to prevent choking.

3. SETUP & ASSEMBLY

Follow these steps to assemble your Beyblade Burst Hypersphere Harmony Pegasus P5 battling top and prepare the launcher.

1. **Unpack Components:** Carefully remove the Beyblade top components (Energy Layer, Forge Disc,

Performance Tip) and the launcher from the packaging.

2. Assemble the Battling Top:

- Attach the *Performance Tip (TH13)* to the *Forge Disc (D57)*.
- Align the assembled Forge Disc and Performance Tip with the *Energy Layer (Harmony Pegasus P5)*.
- Twist the components together until they lock securely, forming the complete battling top. Ensure the GT Chip is properly seated within the Energy Layer.

- 3. Prepare the Launcher:** The Hypersphere launcher is designed for both left and right-spin tops. Ensure the launcher is set to the correct spin direction for Harmony Pegasus P5, which is a right-spin top. Adjust the switch on the launcher if necessary.



Image 3.1: The Beyblade Burst Hypersphere Harmony Pegasus P5 battling top components and launcher, ready for assembly.

4. OPERATING INSTRUCTIONS

To engage in Beyblade Burst battles, a Beyblade Burst Hypersphere Beystadium is required (sold separately).

1. **Load the Top:** Insert the assembled Harmony Pegasus P5 battling top into the Hypersphere launcher. Ensure it clicks into place securely.
2. **Position for Launch:** Hold the launcher over the Beyblade Burst Hypersphere Beystadium. For optimal Hypersphere performance, aim for the vertical wall or the brink of the Beystadium.
3. **Launch the Top:** Pull the ripcord firmly and swiftly to launch the top into the Beystadium. The Hypersphere Performance Tip is designed to allow the top to climb the vertical wall and speed along the brink, then drop into the center for high-intensity battles.
4. **Battle:** Compete against other Beyblade Burst tops. The goal is to be the last top spinning, or to burst your opponent's top into pieces. Burst rates may vary.
5. **Digital Battles (Optional):** Scan the code located on the Energy Layer of your Harmony Pegasus P5 top using the Beyblade Burst app on a compatible mobile device. This unlocks the top for digital battles and allows for mixing and matching with other components within the app.

5. MAINTENANCE

Proper care will extend the life of your Beyblade Burst components.

- **Cleaning:** Wipe components with a dry, soft cloth to remove dust and debris. Do not use water or cleaning solutions, as this may damage the plastic or internal mechanisms.
- **Storage:** Store tops and launchers in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect the top and launcher for any signs of wear or damage. Discontinue use if any part is broken or cracked.
- **Avoid Force:** Do not apply excessive force when assembling or disassembling components, as this can cause breakage.

6. TROUBLESHOOTING

If you encounter issues with your Beyblade Burst Harmony Pegasus P5 Starter Pack, refer to the following common solutions:

Problem	Possible Cause	Solution
Top does not spin or spins weakly.	Top not assembled correctly. Launcher not loaded properly. Ripcord pulled too slowly or weakly.	Ensure all top components are securely locked. Verify the top is fully inserted into the launcher until it clicks. Pull the ripcord firmly and quickly.
Top bursts too easily.	Impact with other tops or Beystadium walls. Components not fully secured.	Bursting is a normal part of Beyblade Burst battles; rates vary. Re-check assembly to ensure all parts are locked.
Launcher jams or does not release top.	Top not inserted correctly. Ripcord not aligned. Launcher mechanism damaged.	Ensure the top is fully seated and clicked into the launcher. Check that the ripcord is inserted straight and not twisted. If damaged, discontinue use and consider replacement.

7. SPECIFICATIONS

- **Model Number:** E7719
- **Product Dimensions:** 1.5 x 5 x 7.99 inches
- **Item Weight:** 0.8 ounces
- **Manufacturer Recommended Age:** 8 years and up
- **Top Type:** Stamina (Right-Spin)
- **Components:**
 - Energy Layer: Harmony Pegasus P5
 - Forge Disc: D57
 - Performance Tip: TH13

Top Performance Stats (Harmony Pegasus P5):

- **Attack:** 3
- **Defense:** 5
- **Endurance:** 5
- **Weight:** 6
- **Agility:** 2
- **Burst:** 1

Hypersphere Performance Stats:

- **Run Time:** 5
- **Drop-In Frequency:** 1

Note: Performance may vary depending on battle conditions and Beystadium used.

8. WARRANTY & SUPPORT

Specific warranty information for the Beyblade Burst Rise Hypersphere Harmony Pegasus P5 Starter Pack is not provided in this manual. For details regarding product warranty, returns, or to contact customer support, please visit the official Hasbro or Beyblade website.

Manufacturer: Hasbro

For further assistance, please refer to the manufacturer's official support channels.