Babymoov YOO Care

Babymoov YOO Care Video Baby Monitor Instruction Manual

Model: YOO Care (A014422)

1. Introduction

The Babymoov YOO Care Video Baby Monitor is designed to provide parents with a simple and reliable way to monitor their baby. This manual provides essential information on how to set up, operate, and maintain your YOO Care monitor to ensure optimal performance and safety.

2. Safety Information

- Keep the monitor units and cables out of reach of children (at least 1 meter away from the crib).
- Do not place the camera or parent unit in or near water.
- Use only the provided power adapters. Using unauthorized adapters may damage the device and void the warranty.
- Ensure proper ventilation for both units. Do not cover them with cloths or other materials.
- This product is not a substitute for responsible adult supervision.

3. Package Contents

Please check the package contents to ensure all items are present:

- 1 x Camera Unit (Baby Unit)
- 1 x Parent Unit (Receiver with 2.4" screen)
- 2 x Power Adapters (for camera and parent unit)
- Instruction Manual



Image: The Babymoov YOO Care baby monitor package contents, including the camera unit, parent unit, and two power adapters.

4. Product Overview

4.1 Camera Unit (Baby Unit)

- **Camera Lens:** Captures video of your baby.
- **Infrared LEDs:** For night vision.
- **Night Light:** Provides a soft glow in the baby's room.
- **Temperature Sensor:** Monitors the room temperature.
- **Power Button:** To turn the camera unit on/off.
- **Manual Pan/Tilt:** Allows you to manually adjust the camera's angle (360° rotation).
- **Power Input:** For connecting the power adapter or inserting AAA batteries.



Image: The Babymoov YOO Care camera unit, highlighting its night light and 360-degree manual rotation capability.

4.2 Parent Unit (Receiver)

- **2.4" Digital Screen:** Displays live video feed from the camera.
- **Tactile Control Buttons:** For navigating menus and controlling functions.
- **Microphone:** For the Talk Back function.
- **Speaker:** To hear your baby and for Talk Back audio.
- **Power/Menu Button:** To turn the unit on/off and access settings.
- **Charging Port:** For connecting the power adapter to recharge the internal lithium battery.
- **Belt Clip:** For convenient portability.



Image: The Babymoov YOO Care parent unit, showing its 2.4-inch screen and tactile control buttons.

5. Setup

5.1 Powering the Camera Unit

1. Connect one of the provided power adapters to the camera unit's power input.
2. Plug the adapter into a wall outlet.
3. Alternatively, the camera can be powered by 3 AAA batteries (not included) for portable use. Insert the batteries into the designated compartment.
4. Press the Power button on the front of the camera unit to turn it on.

5.2 Powering and Charging the Parent Unit

1. Connect the second power adapter to the parent unit's charging port.
2. Plug the adapter into a wall outlet. The parent unit has a built-in rechargeable lithium battery.
3. Charge the parent unit fully before first use.

4. Press and hold the Power/Menu button on the parent unit to turn it on.



Image: The two power adapters included with the Babymoov YOO Care monitor, used for powering the camera and charging the parent unit.

5.3 Placement and Pairing

1. Place the camera unit in your baby's room, ensuring a clear view of the crib. Keep it at least 1 meter away from the baby.
2. Manually adjust the camera's angle to achieve the desired viewing area. The camera can be rotated 360 degrees.
3. Once both units are powered on, they should automatically pair. If pairing fails, refer to the troubleshooting section.

6. Operation

6.1 Basic Monitoring

- The parent unit's 2.4" screen will display the live video feed from the camera.
- Use the volume buttons on the parent unit to adjust the sound level.

6.2 VOX Mode (Voice Activated)

The VOX mode puts the parent unit into standby when no sound is detected from the baby's room. It automatically reactivates when your baby makes a sound or cries. This feature helps conserve battery life and reduces wave emissions.

- Activate VOX mode through the parent unit's menu settings.
- Adjust the VOX sensitivity level if needed (e.g., to prevent activation from minor background noises).

6.3 Talk Back Function

The Talk Back function allows you to speak to your baby through the parent unit, providing comfort and reassurance from a distance.

- Press and hold the Talk Back button on the parent unit to speak.
- Release the button to listen.

6.4 Night Light

The camera unit features a built-in night light to create a soothing environment for your baby.

- Activate the night light via the parent unit's menu.

6.5 Temperature Monitoring

The camera unit includes a temperature sensor to display the room temperature on the parent unit's screen.

- The current temperature is continuously displayed on the parent unit.

6.6 Digital Zoom

The parent unit allows you to digitally zoom in on the video feed for a closer look at your baby.

- Use the zoom controls on the parent unit to activate the 2x digital zoom.

7. Maintenance

- **Cleaning:** Wipe both units with a dry, soft cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** For optimal battery life, fully charge the parent unit regularly. If storing the unit for an extended period, charge it periodically.
- **Storage:** Store the monitor in a cool, dry place away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
No image/sound on parent unit	Units not powered on, out of range, or not paired.	Ensure both units are powered on and charged. Move units closer together. Re-pair units via menu if necessary.

Problem	Possible Cause	Solution
Poor image quality	Low light, camera lens obstructed, or out of range.	Ensure adequate lighting or night vision is active. Clean camera lens. Move units closer.
Short battery life on parent unit	VOX mode not active, frequent use, or aging battery.	Activate VOX mode. Reduce screen brightness. Ensure full charge before use.
Interference/Static	Other wireless devices nearby.	Move the monitor away from other electronic devices (Wi-Fi routers, microwaves, cordless phones). The monitor uses automatic channel selection to minimize interference.

9. Specifications

- **Model Name:** YOO Care
- **Model Number:** A014422
- **Screen Size:** 2.4 inches (6 cm)
- **Screen Resolution:** 720p
- **Connectivity:** Wireless
- **Range:** Up to 300 meters (open field)
- **Camera View Angle:** 360 degrees (manual orientation)
- **Zoom:** 2x Digital
- **Special Features:** VOX Mode, Talk Back Function, Night Light, Room Temperature Sensor
- **Power Source (Camera):** Mains adapter (included) or 3x AAA batteries (not included)
- **Power Source (Parent Unit):** Rechargeable Lithium Battery (included) via Mains adapter (included)
- **Voltage:** 5 Volts
- **Wattage:** 2 Watts
- **Dimensions (approx.):** 24 x 8.5 x 21 cm (overall product)
- **Material:** Plastic



Image: Detailed dimensions of the Babymoov YOO Care camera and parent units.

10. Warranty and Support

Babymoov offers a lifetime warranty on this product. To benefit from the lifetime warranty, you must register your product within 2 months of purchase. Please refer to the official Babymoov website for full terms, conditions, and registration details.

For further assistance or technical support, please visit the official Babymoov website or contact their customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question