

Yaheetech B081KXBJRK

Yaheetech TV Stand Instruction Manual

Model: B081KXBJRK

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Yaheetech TV Stand. Please read this manual thoroughly before beginning assembly or use to ensure safe and proper functionality. Keep this manual for future reference.



Figure 1: Yaheetech TV Stand with a television on top, showcasing its primary function as a media console.

2. SAFETY INFORMATION

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Contact customer support if any parts are missing or defective.

- Do not overtighten screws, as this may damage the material.
- Keep small parts and packaging materials away from children and pets.
- For safety, it is recommended that two people assemble this unit.
- Do not exceed the maximum weight capacity: 55 lb on the top, 28.7 lb on each of the two shelves, and 6.2 lb in the drawer.
- Secure the unit to the wall using the provided anti-tip kit to prevent accidental tipping, especially in households with children.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- All wooden panels (labeled with numbers)
- Hardware pack (screws, dowels, cam locks, drawer slides, handles)
- Assembly Guide (this document)
- Installation Tool (Allen wrench/screwdriver)




Figure 2: Exploded view of the TV stand components and their dimensions, including the top panel (39.5"W x 12"D),

drawer, and two lower shelves.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. Refer to the included video for visual guidance.

Your browser does not support the video tag.

Video 1: Official Yaheetech 3-Tier Console Table with Drawers Assembly Guide. This video provides a step-by-step visual walkthrough of the entire assembly process.

Step-by-Step Assembly:

1. **Prepare Side Panels:** Attach the necessary hardware (dowels and cam bolts) to the X-shaped side panels. Ensure they are securely fastened.
2. **Assemble Drawer Components:** Attach the drawer slides to the drawer side panels. Ensure the slides are correctly oriented for smooth operation.
3. **Construct Drawer Box:** Assemble the drawer box using the provided panels and hardware. Secure the bottom panel of the drawer.
4. **Attach Drawer Handles:** Fasten the metal handles to the front of the drawer.
5. **Connect Side Panels to Base:** Attach the side panels to the bottom shelf using cam locks and dowels.
6. **Insert Middle Shelf:** Slide the middle shelf into the designated slots on the side panels and secure with cam locks.
7. **Attach Top Panel:** Place the top panel onto the assembled frame and secure it with cam locks.
8. **Install Drawer into Frame:** Carefully align the drawer slides on the drawer with the corresponding slides on the main frame and push the drawer in until it clicks into place.
9. **Secure Anti-Tip Kit:** Attach the anti-tip hardware to the back of the unit and to a wall stud, following the instructions provided with the kit. This is crucial for stability and safety.



Figure 3: Detailed view of key components, including the smooth, protective corners, elegant metal drawer pulls, and the robust X-shaped side panels, highlighting the quality of construction.

5. OPERATING INSTRUCTIONS

The Yaheetech TV Stand is designed for versatile use in various rooms. Its 3-layer structure provides ample storage and display space.

- **Media Console:** Place your television on the sturdy top surface. The large drawer (86.3 cm L × 22 cm Depth × 7.3 cm H) can store remote controls, cables, or small accessories. The two lower shelves (90.6 cm L × 28 cm W) are ideal for electronic equipment such as a record player, soundbar, gaming consoles, or media collections.
- **Entryway Table:** Use the console in your entryway to hold keys, mail, and decorative items. The shelves can store baskets for shoes or other essentials.
- **Sofa Table/Sideboard:** Position behind a sofa or against a wall in the living room or dining room to display decor, books, or serve as an additional surface for entertaining.



Figure 4: The TV stand functioning as a versatile console table, demonstrating its adaptability in different home environments.

6. MAINTENANCE

To maintain the appearance and longevity of your TV stand, follow these simple care instructions:

- **Cleaning:** Wipe with a dry cloth for regular dusting. For spills or stains, wipe with a damp cloth immediately. Avoid abrasive cleaners or harsh chemicals that could damage the veneer finish.
- **Protection:** Avoid placing hot items directly on the surface. Use coasters or protective pads under drinks and decorative objects.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight may cause fading or discoloration.
- **Hardware Check:** Periodically check and tighten all screws and fasteners to ensure the unit remains stable.




Figure 5: Illustration of cleaning the TV stand surface with a damp cloth, emphasizing easy maintenance.

7. TROUBLESHOOTING

If you encounter any issues with your Yaheetech TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit is wobbly or unstable.	Loose fasteners or uneven floor.	Tighten all screws and bolts. Ensure the unit is on a level surface. Use shims if necessary.
Drawer does not slide smoothly.	Drawer slides are misaligned or dirty.	Check that the drawer slides are correctly installed and aligned. Clean any debris from the tracks.
Missing parts during assembly.	Packaging error.	Review the package contents list. Contact Yaheetech customer support for replacement parts.
Scratches or damage to the surface.	Improper handling or sharp objects.	Use a furniture repair kit for minor scratches. For deeper damage, consider professional repair or replacement.

8. SPECIFICATIONS

- **Brand:** Yaheetech
- **Model Name:** TV Stand
- **Product Dimensions:** 39.5"W x 12"D x 31.5"H
- **Color:** White
- **Material Type:** Engineered Wood (CARB P2 MDF panels) and Solid Pine Wood (legs)
- **Item Weight:** 40.3 Pounds
- **Maximum Weight Recommendation:** 55 Pounds (top), 28.7 Pounds (each shelf), 6.2 Pounds (drawer)
- **Number of Drawers:** 1
- **Number of Shelves:** 2
- **Included Components:** Assembly Guide, Installation Tool
- **Product Care Instructions:** Wipe with Dry Cloth, Wipe with Damp Cloth

Ours

Sturdy Solid Pine Wood Legs



Others

MDF Legs



VS

100%

Solid Pine Wood

Robust solid wood legs for better weight capacity



Figure 6: Visual comparison emphasizing the use of 100% solid pine wood for robust legs, contributing to better weight capacity and durability.

9. WARRANTY AND SUPPORT

Yaheetech stands behind the quality of its products. For warranty information, product support, or to order

replacement parts, please contact Yaheetech customer service through the retailer's platform or visit the official Yaheetech store online.

For additional resources, you may refer to the [Installation Manual \(PDF\)](#).