

soundcore Ace A1

Soundcore Ace A1 Portable Bluetooth Speaker User Manual

Model: Ace A1 (A3151)

1. INTRODUCTION

Thank you for choosing the Soundcore Ace A1 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before use and retain it for future reference.



Image 1.1: Front view of the Soundcore Ace A1 Portable Bluetooth Speaker, showcasing its compact design and control buttons.

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- Soundcore Ace A1 Portable Bluetooth Speaker
- USB Charging Cable
- Detachable Lanyard/Strap
- User Manual (this document)

3. CONTROLS AND INDICATORS

Familiarize yourself with the speaker's buttons and LED indicators:

Power Button (): Press and hold to power on/off.

Volume Down Button (–): Press to decrease volume. Hold to skip to previous track.

Multi-function Button (): Press to play/pause. Press twice for next track. Press once to answer/end call. Hold to reject call.

Volume Up Button (+): Press to increase volume. Hold to skip to next track.

Bluetooth Button (): Press to enter Bluetooth pairing mode.

LED Indicator: Shows power, charging, and Bluetooth status.

Micro-USB Charging Port: For charging the speaker.

AUX Input Port: For wired audio connection.

Micro-SD Card Slot: For playing music directly from a Micro-SD card.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the Micro-USB port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port.

- The LED indicator will be solid red during charging.
- The LED indicator will turn off when fully charged.
- A full charge typically takes approximately 2-3 hours.

4.2 Powering On/Off

- To power on: Press and hold the Power button for 2 seconds. The LED indicator will flash blue.
- To power off: Press and hold the Power button for 2 seconds. The LED indicator will turn off.

5. OPERATING THE SPEAKER

5.1 Bluetooth Connection

The Soundcore Ace A1 can connect wirelessly to your device via Bluetooth.

1. Power on the speaker. The LED indicator will flash blue, indicating it's in pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "Soundcore Ace A1" in your device's Bluetooth list and select it to connect.
4. Once connected, the LED indicator will turn solid blue.
5. If prompted for a password, enter "0000".

Note: The speaker will automatically attempt to reconnect to the last paired device when powered on. If connection fails, repeat the pairing steps.

5.2 Audio Playback

Once connected via Bluetooth, AUX, or Micro-SD card, you can control audio playback:

- **Play/Pause:** Press the Multi-function button (○).
- **Next Track:** Press and hold the Volume Up button (⏮) for 2 seconds.
- **Previous Track:** Press and hold the Volume Down button (⏭) for 2 seconds.
- **Volume Up:** Press the Volume Up button (⏮).
- **Volume Down:** Press the Volume Down button (⏭).




Image 5.1: The Soundcore Ace A1 is designed for portability, offering up to 6 hours of continuous music playback.

5.3 Using the AUX Input

Connect an audio device directly to the speaker using a 3.5mm AUX cable (not included).

- Plug one end of the AUX cable into the speaker's AUX port.
- Plug the other end into the headphone jack of your audio device.
- The speaker will automatically switch to AUX mode.

5.4 Using a Micro-SD Card

Insert a Micro-SD card (up to 32GB, formatted to FAT32) with audio files into the Micro-SD card slot. The speaker will automatically detect and play music from the card.

- Supported audio formats typically include MP3, WMA, WAV.

5.5 Phone Calls

The built-in microphone allows for hands-free calling when connected via Bluetooth.



Image 5.2: The Soundcore Ace A1 features a built-in microphone for clear hands-free calls.

- **Answer Call:** Press the Multi-function button () once.
- **End Call:** Press the Multi-function button () once during a call.
- **Reject Call:** Press and hold the Multi-function button () for 2 seconds.
- **Switch between speaker and phone:** During a call, press and hold the Multi-function button () for 2 seconds.

6. MAINTENANCE AND CARE

- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or excessive moisture.
- Store the speaker in a cool, dry place when not in use.
- Do not attempt to disassemble or repair the speaker yourself. This will void the warranty.

7. TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source and try again.
Cannot pair with Bluetooth device.	◦ Ensure the speaker is in pairing mode (flashing blue LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device. ◦ Forget "Soundcore Ace A1" from your device's Bluetooth list and try pairing again. ◦ Restart both the speaker and your device.

Problem	Solution
No sound.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is correctly connected via Bluetooth, AUX, or Micro-SD. ◦ If using AUX, check the cable connection. ◦ If using Micro-SD, ensure the card contains supported audio files and is inserted correctly.
Poor sound quality.	◦ Move the speaker closer to your Bluetooth device and away from obstacles. ◦ Try playing a different audio source. ◦ Ensure the speaker is fully charged.
Microphone not working during calls.	◦ Ensure the speaker is connected via Bluetooth. ◦ Check your phone's settings to ensure audio is routed to the Bluetooth speaker.

8. SPECIFICATIONS

Feature	Detail
Model Name	Soundcore Ace A1 (A3151)
Connectivity Technology	Bluetooth, Auxiliary, Micro-SD
Wireless Communication	Bluetooth
Power Source	Battery Powered (Built-in Li-on)
Playtime	Up to 6 hours
Special Features	Built-in Microphone, Micro-SD Card Slot
Control Method	Touch buttons
Waterproof	Yes
Color	Black
Manufacturer	Anker




Image 8.1: Internal components of the Soundcore Ace A1, illustrating its powerful sound architecture.

9. WARRANTY AND CUSTOMER SUPPORT





Soundcore provides an **18-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use. For technical support, warranty claims, or other inquiries, please contact Soundcore customer service through their official website or the retailer where the product was purchased. Please have your proof of purchase and product model number (Ace A1 / A3151) ready.

You can visit the official Soundcore store for more information: [Soundcore Store](#)

© 2025 Soundcore. All rights reserved. Soundcore and the Soundcore logo are trademarks of Anker Innovations Limited.

Related Documents - Ace A1

	Soundcore R50i Bezdrôtové Slúchadlá: Používateľská Príručka a Špecifikácie Komplexná príručka pre bezdrôtové slúchadlá Soundcore R50i, ktorá pokrýva nastavenie, párovanie, ovládanie, nabíjanie, aktualizácie firmvéru a technické špecifikácie. Naučte sa efektívne používať svoje slúchadlá Soundcore.
---	---

	Soundcore Trådlösa Hörsnäckor: Komplette Användarmanual Denna användarmanual ger detaljerade instruktioner för Soundcore trådlösa hörsnäckor (R50i, P20i, P25i), inklusive installation, laddning, parkoppling, kontroller och appfunktioner. Lär dig optimera din ljudupplevelse.
	Soundcore R50i/P20i/P25i Wireless Earbuds User Manual Comprehensive user guide for Soundcore R50i, P20i, and P25i wireless earbuds, covering setup, charging, controls, pairing, firmware updates, and specifications.
	Manuale Utente Auricolari Wireless Soundcore R50i/P20i/P25i Guida completa per gli auricolari wireless Soundcore R50i, P20i e P25i, che copre le funzionalità dell'app, l'uso, la ricarica, l'accoppiamento, i controlli, il ripristino, la guida LED, gli aggiornamenti firmware e le specifiche tecniche.
	Soundcore Trance / Mega User Manual - Portable Bluetooth Speaker Guide Comprehensive user manual for the Soundcore Trance / Mega portable Bluetooth speaker, covering safety instructions, setup, features, specifications, and compliance information. Learn how to connect, charge, and use all functionalities.
	Soundcore Q20i User Manual: Your Guide to Wireless Audio Explore the Soundcore Q20i user manual for detailed instructions on wearing, charging, pairing, and using your wireless headphones. Learn about features like Active Noise Cancellation and Dual Connections.

Documents - soundcore – Ace A1



[\[pdf\]](#) User Manual Instructions

SoundCore Ace A1 Portable Speaker A3151 User Manual Manuals Plus manual internal 2023 09 |||

Model No.: A3151 51005001467 V01 Soundcore **Ace A1** User Manual

Benutzerhandbuch Manuel de l'utilisateur Manuale utente Manual de usuario U

ivatelsk p ru ka Brugervejledning K ytt opas Gebruikershandleiding Brukerh ndbok Anv

ndarhandbok ...

lang:en **score:39** filesize: 20.09 M page_count: 80 document date: 2023-09-27



[\[pdf\]](#) User Manual Quick Start Guide Frequently Asked Questions Warranty

var www.html 2020 11 Anker Soundcore Ace A1 Manual Optimized manual internal |||

- soundcore Soundcore **Ace A1** Quick Start Guide CSaDrd 5 Install OD 1 68 20 OD 3
AUX 4 OD For FAQs and more information, please visit : soundcore.com / support
Model: A3151 51005001465 V01 x1 Soundcore **Ace A1** Soundcore **Ace A1** 0
SoundcoreAudio 0 soundcoreaudio soundcoreaudio 7 ...

lang:it **score:38** filesize: 843.16 K page_count: document date:




[\[pdf\]](#) User Manual Quick Start Guide Frequently Asked Questions

var www.html 2020 11 Anker Soundcore Ace A1 Manual Original manual internal |||

1 Soundcore **Ace A1** Quick Start Guide CSaDrd 5 Install 6 2 7 x2 x3 3 AUX x1
Soundcore **Ace A1** Soundcore **Ace A1** 8 4 For FAQs and more information, please
visit : soundcore.com / support Model: A3151 51005001465 V01 9 SoundcoreAudio
soundcoreaudio soundcoreaudio Input: DC 5V 0.63A Ank...

lang:it **score:37** filesize: 651.04 K page_count: document date:



[\[pdf\]](#) User Manual Instructions

Soundcore Ace A1 Anker Brukerhåndbok | Användarhandbok Руководство пользователя Manual do
Usuário مدختسملا ليلد שמחשכל A3151Manual_1 ankerjapan client_info ANKERJAPAN

view userweb pdf Japan User Benutzerhandbuch Manuel de l'utilisateur Manuale utente usuario

Uživatelská příručka Brugervejledning Käyttöopas Gebruikershandleiding

Model No.: A3151 51005001467 V01 Soundcore **Ace A1** User Manual

Benutzerhandbuch Manuel de l'utilisateur Manuale utente Manual de usuario

Uzivatelsk prucka Brugervejledning Kyttopas Gebruikershandleiding Brukerhndbok

Anvndarhandbok Manual do Usurio 01 English ...

lang:en **score:29** filesize: 7.91 M page_count: 80 document date: 2021-01-20



[\[pdf\]](#) User Manual Quick Start Guide Installation Guide Frequently Asked Questions
Guide

51005001465 Soundcore Speaker A3151011 Online QSG 80x80mm V1 20190321 User Manual Anker
Innovations Limited A3151 Bluetooth 2AOKB 2AOKBA3151 a3151

1 Soundcore **Ace A1** Quick Start Guide CSaDrd 5 Install 6 2 7 x2 x3 3 AUX x1
Soundcore **Ace A1** Soundcore **Ace A1** 8 4 For FAQs and more information, please
visit : soundcore.com / support Model: A3151 51005001465 V01 9 SoundcoreAudio
soundcoreaudio soundcoreaudio Input: DC 5V 0.63A Ank...

lang:en **score:25** filesize: 651.04 K page_count: 1 document date: 2019-03-21




[\[pdf\]](#) User Manual Quick Start Guide

SoundCore Ace A1 Portable Speaker A3151 QSG Manuals Plus manual internal 2023 09 |||

...

lang:en **score:24** filesize: 716.58 K page_count: 1 document date: 2023-09-27



[\[pdf\]](#) User Manual Instructions

Soundcore Ace A1 AWSoundcore

Bluetooth

A3151

ManualA3151 Manualsalesforce knowledge s3 us west 2 amazonaws 000004386 en US

000004386salesforce |||

Model No.: A3151 51005001467 V01 Soundcore **Ace A1** User Manual

Benutzerhandbuch Manuel de l'utilisateur Manuale utente Manual de usuario

Uzivatelsk prucka Brugervejledning Kyttopas Gebruikershandleiding Brukerhndbok

Anvndarhandbok Manual do Usurio 01 English ...

lang:en **score:22** filesize: 20.09 M page_count: 80 document date: 2019-07-22

[\[pdf\]](#) User Manual Quick Start Guide Frequently Asked Questions Guide

51005001465 Soundcore Speaker A3151011 Online QSG 80x80mm V1 20190321 Outline* Page 1
soundcore 2 X AUX bor os 9ca de A2000 43 009 For FAQs and more infor support Title Created Date 4
29 2019 31 49 PM Model A3151 V01 Ace A1 Quick Start Guide 0 @Soundcore Audio @soundcoreaudio
soundo Customer Service al Cliente Serviço Apolo ao Client Ограниченная гарантия на 18
A3151Manual ankerjapan client info ANKERJAPAN view userweb

...

lang:en score:16 filesize: 691.5 K page_count: 1 document date: 2019-04-29



[\[pdf\]](#) Test Report

Measurement Report Kent test report Anker Innovations Limited A3151 Bluetooth Speaker 2AOKB
2AOKBA3151 a3151

Page 1 of 48Report No.: HK1902180257E TEST REPORT FCC Rules and
Regulations Part 15 Subpart C Section 15.247 ANSI C63.10: 2013 RSS-GEN: Issue 5
RSS-247: Issue 2 Test report On Behalf of Anker Innovations Limited For Soundcore
Ace A1 Model No.: A3151 FCC ID: 2AOKB-A3151 IC: 23451-A3151 Prepared for ...

lang:en score:13 filesize: 2.56 M page_count: 48 document date: 2019-04-18

