

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Cecotec](#) /
- › [Cecotec Bamba RitualCare 890 Titanium Hair Straightener User Manual](#)

Cecotec 890

Cecotec Bamba RitualCare 890 Titanium Hair Straightener User Manual

Model: 890

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance. Keep this manual for future reference.

- **Fire Hazard:** Surfaces become extremely hot during use. Avoid contact with skin.
- **Electric Shock Hazard:** Keep away from water. Do not use near bathtubs, basins, or other water sources.
- **Fire Hazard:** Unplug when not in use. Do not leave unattended when plugged in.
- Keep out of reach of children.
- Do not use if the cord or plug is damaged. Contact customer service for repair.
- Do not wrap the power cord around the appliance.
- Ensure your hands are dry when plugging in or unplugging the appliance.

2. PRODUCT OVERVIEW

The Cecotec Bamba RitualCare 890 Titanium Hair Straightener is designed for efficient and versatile hair styling. It features advanced titanium plates for smooth gliding and minimal friction, reducing hair pulling and breakage. The 3D floating plates ensure even pressure and continuous contact with the hair strand.

Key Features:

- **Advanced Titanium Plates:** Ultra-smooth plates designed for maximum control and precision, enhancing glide and minimizing friction.
- **Multi-Style Functionality:** Achieve perfect straightening, flexible waves, and defined curls.
- **3D Floating Plates:** Provide even pressure on hair and maintain constant contact between

plates and hair strands.

- **Adjustable Temperature:** Five preset temperature settings from 140°C to 220°C, suitable for all hair types.
- **Automatic Shut-off:** For safety, the device automatically turns off after 30 minutes of inactivity.
- **3-meter Swivel Cord:** Offers full freedom of movement during styling.
- **Silicone Plate Protector:** Included for safe storage and transport.



Image: The Cecotec Bamba RitualCare 890 Titanium Hair Straightener, showcasing its sleek design and titanium plates.

3. SETUP

1. **Unpack:** Carefully remove the hair straightener and all accessories from the packaging.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Placement:** Place the straightener on a heat-resistant, flat surface.
4. **Connect:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the appliance's requirements.



Image: The hair straightener resting on a countertop, ready for use.

4. OPERATING INSTRUCTIONS

Follow these steps for optimal styling results and safe operation.

4.1. Preparing Your Hair

- Ensure your hair is clean, dry, and free of tangles.
- Apply a heat protectant spray to your hair to minimize heat damage.
- Divide your hair into manageable sections using clips.

4.2. Powering On and Temperature Selection

1. Press and hold the power button () to turn on the straightener.
2. The temperature indicator lights will illuminate.
3. Press the power button repeatedly to cycle through the 5 preset temperature settings: 140°C, 160°C, 180°C, 200°C, 220°C. Select the appropriate temperature for your hair type.
 - **140°C - 160°C:** For fine, damaged, or chemically treated hair.
 - **180°C - 200°C:** For normal hair.
 - **220°C:** For thick, coarse, or very curly hair.

4. Allow the straightener to heat up. The selected temperature light will stop blinking when the desired temperature is reached.



Image: A hand pressing the power button to adjust the temperature settings on the straightener, with indicators for 140°C, 160°C, 180°C, 200°C, and 220°C visible.

4.3. Straightening Hair

1. Take a small section of hair (approximately 2 inches wide).
2. Place the section between the heating plates, close to the roots.
3. Gently clamp the plates together and glide the straightener slowly and smoothly down the hair section, from roots to ends.
4. Repeat on all sections until desired straightness is achieved.



Image: A woman using the Cecotec hair straightener to straighten a section of her long, brown hair, demonstrating the straightening process.

4.4. Curling Hair

1. Take a small section of hair.
2. Clamp the straightener around the hair section, about halfway down the length.
3. Rotate the straightener 180 degrees away from your face.
4. Slowly pull the straightener down the hair shaft, maintaining the rotation.
5. Release the hair and allow the curl to cool before touching.



Image: A woman demonstrating how to create curls using the Cecotec hair straightener, showing a section of hair wrapped around the plates.

4.5. Automatic Shut-off

For enhanced safety, the hair straightener will automatically turn off after 30 minutes of inactivity. To resume use, simply press the power button to turn it back on and select your desired temperature.

5. MAINTENANCE

Proper care ensures the longevity and performance of your hair straightener.

- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning. Wipe the plates and exterior with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** Store the straightener in a dry, safe place, away from moisture and extreme temperatures. Use the included silicone plate protector to prevent damage to the plates.
- **Cord Care:** Do not wrap the power cord tightly around the appliance, as this can damage the cord.



Image: The Cecotec Bamba RitualCare 890 Hair Straightener with its silicone plate protector, illustrating safe storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly, power outlet issue, or internal fault.	Ensure the plug is fully inserted. Test the outlet with another device. If still not working, contact customer support.
Appliance is not heating up.	Temperature setting too low, or internal heating element issue.	Check the temperature setting and increase if necessary. Allow sufficient time to heat. If problem persists, contact customer support.
Hair is snagging or pulling.	Hair is tangled, plates are dirty, or using too large a section.	Ensure hair is thoroughly detangled. Clean the plates. Use smaller sections of hair.
Automatic shut-off activates too soon.	Appliance has been inactive for 30 minutes.	This is a safety feature. Press the power button to turn it back on.

7. SPECIFICATIONS

Brand	Cecotec
Model Name	RitualCare 890 Titanium
Model Number	04213
Power Source	Corded Electric
Heater Surface Material	Titanium
Maximum Temperature Setting	220°C
Adjustable Temperature Range	140°C - 220°C (5 preset settings)
Automatic Shut-off	Yes, after 30 minutes of inactivity
Cord Length	3 meters
Product Dimensions	6 x 13.5 x 33 cm
Weight	400 grams
Color	Black

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Cecotec website. Keep your proof of purchase for any warranty claims.

You can find more information and contact details on the official Cecotec website: www.cecotec.com