Zeppelin 8062-5

Zeppelin LZ129 Hindenburg 8062-5 Automatic Watch User Manual

Model: 8062-5

Introduction

This manual provides comprehensive instructions for the proper use, care, and maintenance of your Zeppelin LZ129 Hindenburg 8062-5 automatic watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.





Image 1: Front view of the Zeppelin LZ129 Hindenburg 8062-5 automatic watch, showcasing its cream dial, Arabic numerals, and brown leather strap.

Setup and Initial Operation

Unpacking and Inspection

Upon receiving your Zeppelin LZ129 Hindenburg watch, carefully remove it from its packaging. Inspect the watch for any visible damage. The package should include:

- Zeppelin 8062 Men's Automatic Watch
- Zeppelin box
- Zeppelin user manual
- Zeppelin service card

Winding the Watch

Your Zeppelin LZ129 Hindenburg 8062-5 is an automatic watch, meaning it is powered by the motion of your wrist. However, for initial setup or if the watch has stopped, it is recommended to manually wind it.

1. Gently pull the crown (knurled knob on the side of the case) to position 1 (if it has multiple positions, otherwise keep

it pushed in).

2. Turn the crown clockwise approximately 20-30 times. This will build up a power reserve.
3. Push the crown back into its original position.

The watch will then continue to wind itself through your daily movements. If worn regularly, manual winding will not be necessary.


MADE IN GERMANY • WR 5ATM • ALL STAINLESS STEEL •
FINE GERMAN WRISTWATCHES
AUTOMATIC 21 JEWELS
LZ 129
8062-5 / 00061 / TP

Image 2: Side view of the watch, highlighting the knurled crown used for winding and setting the time/date.

Operating Instructions

Setting the Time

1. Pull the crown out to position 2 (the outermost position). The second hand will stop.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into position 0 (fully pushed in). The second hand will resume movement.

Setting the Date

The watch features a date display at the 3 o'clock position.

1. Pull the crown out to position 1 (the first click).
2. Turn the crown counter-clockwise to adjust the date.
3. Once the date is set, push the crown back into position 0.

Important: Avoid setting the date between 9 PM and 3 AM, as this can damage the date mechanism. If the current time falls within this window, first adjust the time outside this period, then set the date, and finally reset the time.

Care and Maintenance

General Care

- Handle with care.
- Clean the watch case and crystal regularly with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- The watch is water-resistant up to 5 ATM (50 meters), suitable for splashes, rain, and short immersion in water. It is **not** suitable for swimming, diving, or showering. Ensure the crown is fully pushed in before any contact with water.
- Avoid sudden impacts or drops.

Leather Strap Care

The watch features a handmade crocodile leather strap. To prolong its life:

- Avoid prolonged exposure to water, sweat, and direct sunlight.
- Clean with a soft, damp cloth and allow to air dry naturally.
- Do not use chemical cleaners or solvents.

Service and Inspection

For optimal performance, it is recommended to have your automatic watch serviced by an authorized Zeppelin service center every 3-5 years. This includes cleaning, lubrication, and adjustment of the movement.


MADE IN GERMANY • WR 5ATM • ALL STAINLESS STEEL
FINE GERMAN WRISTWATCHES
AUTOMATIC 21 JEWELS
LZ 129
8062-5 / 00061 / TP

Image 3: Rear view of the watch, showing the transparent case back that reveals the automatic mechanical movement with 21 jewels.

Troubleshooting

Problem	Possible Cause	Solution
Watch stops or runs inaccurately	Insufficient power reserve	Manually wind the watch by turning the crown 20-30 times. Wear the watch regularly to maintain power reserve.
Date does not change	Incorrect date setting or mechanism issue	Ensure the time is set correctly (AM/PM). Avoid setting the date between 9 PM and 3 AM. If the problem persists, seek professional service.
Condensation under crystal	Temperature change or moisture ingress	If condensation is persistent, it indicates a seal issue. Seek immediate professional service to prevent damage to the movement.

Specifications

Feature	Detail
Model Series	LZ129 Hindenburg
Model Number	8062-5
Movement	Mechanical, Self-Winding (Automatic), Calibre 821A, 21 Jewels
Case Material	Polished Stainless Steel
Case Diameter	Approx. 40 mm
Case Height	Approx. 11.7 mm
Crystal	Highly Curved Mineral Glass
Dial Color	Cream (with silver Arabic numerals and indexes)
Strap Material	Handmade Crocodile Leather (Brown)
Lug Width	20 mm
Water Resistance	5 ATM (50 meters) according to DIN standard 8310
Weight	Approx. 59g
Origin	Made in Germany

Warranty Information

Your Zeppelin watch comes with a manufacturer's warranty. Please refer to the included Zeppelin service card for specific terms, conditions, and duration of your warranty. The warranty typically covers manufacturing defects under normal use. Damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear may not be covered. For warranty claims or service, please contact an authorized Zeppelin dealer or service center.

Customer Support

If you have any questions or require further assistance with your Zeppelin LZ129 Hindenburg 8062-5 watch, please contact your authorized Zeppelin dealer or visit the official Zeppelin website for support resources and contact information.

Online Resources: www.zeppelin-watches.com

© 2025 Zeppelin. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question