

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Soehnle](#) /
- › [Soehnle Style Sense Bamboo Magic Digital Bathroom Scale User Manual](#)

## Soehnle 63880

# Soehnle Style Sense Bamboo Magic Digital Bathroom Scale

Model: 63880

## INTRODUCTION

---

Thank you for choosing the Soehnle Style Sense Bamboo Magic Digital Bathroom Scale. This scale combines natural design with advanced technology, featuring a genuine bamboo surface and an innovative invisible LED display. This manual provides essential information for the safe and effective use of your new scale.



*Image: The Soehnle Style Sense Bamboo Magic Digital Bathroom Scale.*

## SAFETY INFORMATION

---

- This scale is intended for personal use to measure body weight. Do not use it for commercial or medical purposes.
- Always place the scale on a firm, flat, and stable surface. Uneven surfaces can lead to inaccurate readings.
- The bamboo surface can become slippery when wet. Ensure the scale and your feet are dry before use to prevent accidents.
- Do not jump on the scale or subject it to sudden impacts.
- Keep the scale away from extreme temperatures, direct sunlight, and high humidity.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.

## PACKAGE CONTENTS

---

The package includes:

- 1 x Soehnle Style Sense Bamboo Magic Digital Bathroom Scale
- 4 x AA 1.5V Batteries

## SETUP

### 1. Battery Installation

1. Turn the scale over to access the battery compartment on the underside.
2. Open the battery compartment cover.
3. Insert the four AA 1.5V batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

### 2. Unit Selection (kg/lb/st)

On the underside of the scale, locate the unit switch. Press this button to toggle between kilograms (kg), pounds (lb), and stones (st) to select your preferred unit of measurement.

### 3. Scale Placement

Place the scale on a hard, flat, and stable surface. Avoid soft surfaces like carpets, as these can affect accuracy.



Image: Internal components and design features of the scale.

## OPERATING INSTRUCTIONS

## 1. Initializing the Scale

Before first use or if the scale has been moved, gently tap the center of the scale with your foot. The display will show "0.0" or a similar indication, then turn off. This calibrates the scale for accurate measurement.

## 2. Weighing Procedure

1. Step onto the scale with bare feet, standing still and centered.
2. The invisible LED display will illuminate and show your weight.
3. Remain on the scale until the weight reading stabilizes.
4. The scale will automatically turn off after a few seconds to conserve battery life.



*Image: Proper foot placement on the scale for weighing.*

## MAINTENANCE AND CARE

- **Cleaning:** Wipe the scale surface with a damp cloth and a mild cleaning agent. Do not use abrasive cleaners or immerse the scale in water.
- **Storage:** Store the scale in a dry place at room temperature. Avoid storing it vertically for extended periods, as this may affect accuracy.

- **Battery Replacement:** When the display shows a low battery indicator (e.g., "Lo"), replace all four AA batteries simultaneously. Do not mix old and new batteries or different battery types.

## TROUBLESHOOTING

If you encounter issues with your scale, please refer to the following common problems and solutions:



Präzision aus Leidenschaft

# So geht Wiegen richtig

## 3 Fehler beim Wiegen, die fast jeder macht und wie es richtig geht.

Die Marke Soehnle steht seit über 150 Jahren für exaktes und präzises Messen. Verschiedene Faktoren können das Wiegeergebnis beeinflussen. Bitte beachten Sie deshalb die folgenden Hinweise!

<p><b>Ist die Waage richtig kalibriert?</b></p> <p>Wird die Waage vor der Messung verschoben oder angehoben, besteht bei der Messung keine korrekte Nullung. Dadurch könnte möglicherweise das Eigengewicht der Waage mit in die Messung einfließen und das Ergebnis um rund 1-2 kg verzerrt werden.</p>	<p><b>Ist der richtige Untergrund gewählt?</b></p> <p>Unebene Untergründe wie z.B. Teppiche verfälschen das Resultat der Messung und führen zu Wiegefehlern.</p>	<p><b>Wurde unter den gleichen Bedingungen gewogen?</b></p> <p>Während des Tages kann das Körpergewicht um 1-2 kg schwanken.</p>
<p><b>Tipp:</b></p> <p>Bewegen Sie Ihre Waage vor dem Wiegen nicht mehr oder warten Sie nach dem Einschalten des Geräts, bis dieses „0“ anzeigt.</p>	<p><b>Tipp:</b></p> <p>Stellen Sie Ihre Waage auf einen möglichst ebenen und rutschfesten Untergrund, zum Beispiel Fliesen oder Parkett, um das Ergebnis nicht zu beeinflussen.</p>	<p><b>Tipp:</b></p> <p>Achten Sie darauf, sich immer unter den gleichen Bedingungen (zur gleichen Zeit, unbedeutet, mit nüchternem Magen) zu wiegen, zum Beispiel am Morgen nach dem Gang zur Toilette.</p>

Mehr Informationen unter: [www.soehnle.de/service/haeufige-fragen-faq](http://www.soehnle.de/service/haeufige-fragen-faq)

*Image: Tips for accurate weighing.*

### 1. Inaccurate or Inconsistent Readings

- **Is the scale correctly calibrated?** If the scale is moved or lifted before use, the zero setting may be incorrect. This can lead to inaccurate readings, potentially distorting the result by 1-2 kg.  
**Tip:** Avoid moving the scale before weighing. Wait until the display shows "0" after switching on.
- **Is the surface suitable?** Uneven surfaces, such as carpets, can distort measurement results and cause weighing errors.  
**Tip:** Place the scale on a firm, even, and non-slip surface, such as tiles or parquet flooring, to ensure accurate results.
- **Are weighing conditions consistent?** Body weight can fluctuate by 1-2 kilograms throughout the day.  
**Tip:** For consistent results, weigh yourself under similar conditions each time (e.g., at the same time, unclothed, on an empty stomach, in the morning after using the restroom).

## 2. Display Not Working or Showing "Lo"

- Check if the batteries are correctly inserted with the correct polarity.
- Replace all four AA batteries with new ones.

## 3. Display Shows "Err"

- This usually indicates an overload. The maximum capacity of the scale is 180 kg. Remove weight from the scale.
- Step off the scale, wait for it to turn off, and then step on again.

## SPECIFICATIONS

<b>Model Number</b>	63880
<b>Brand</b>	Soehnle
<b>Material</b>	Bamboo
<b>Display Type</b>	LED (invisible, lights up when in use)
<b>Maximum Weight Capacity</b>	180 Kilograms
<b>Reading Precision</b>	100 Grams
<b>Units of Measurement</b>	kg, lb, st
<b>Dimensions (L x W x H)</b>	30 x 30 x 3.3 cm
<b>Power Source</b>	4 x AA 1.5V Batteries (included)
<b>Special Features</b>	Automatic shut-off
<b>Country of Origin</b>	China

## Style Sense Bamboo Magic

Invisible Display, lights up when in use

**NEW**



*Image: Scale dimensions and key features.*

### WARRANTY AND SUPPORT

Soehnle products are manufactured to high-quality standards. For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Soehnle website. Keep your proof of purchase for any warranty claims.

**Manufacturer:** Leifheit

**Availability of spare parts:** 1 Year