

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FLEXISPOT](#) /

› [FLEXISPOT EN2 Electric Height Adjustable Standing Desk Instruction Manual](#)

FLEXISPOT EN2

FLEXISPOT EN2 Electric Height Adjustable Standing Desk Instruction Manual

Model: EN2

1. INTRODUCTION

Thank you for choosing the FLEXISPOT EN2 Electric Height Adjustable Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- This desk is designed to support a maximum weight of 176 lbs (79.8 kg). Exceeding this limit may result in damage or injury.
- During assembly, an electric drill may be required, which is not included in the package.
- The product will be delivered in two separate packages and may be shipped separately.
- The 5-year and 2-year warranties cover different components of the desk. Refer to the Warranty section for details.
- The height adjustment motor operates quietly, under 50 dB, at a speed of 0.6 inches (1.5 cm) per second.
- Each desk leg has undergone testing, enduring 20,000 lift cycles.
- To ensure proper assembly and stability, please follow the assembly instructions carefully.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all components are present and undamaged. The package includes:

- Whole-piece desktop (48 x 30 inches)
- Desk frame (legs and crossbar)
- 6-button digital controller with 4 memory presets
- Removable desktop power outlet (3 AC outlets, 2 USB charging ports)
- Cable management device
- Assembly hardware and tools (Allen wrench included, Phillips head screwdriver required but not

included)

- Instruction manual

Note: The desktop and desk frame may arrive in separate packages.

DIMENSIONS & FUNCTIONALITY




Image: All components of the FLEXISPOT EN2 desk laid out for assembly, including the desktop, frame parts, and hardware.

4. SETUP


4.1 Assembly

Follow the detailed instructions provided in the included assembly guide. Ensure all screws are tightened securely. An electric drill may be helpful for certain steps, but is not supplied.

4.2 Initial Placement & Leveling

Place the assembled desk in your desired location. The feet are adjustable to ensure the desk is level on uneven surfaces.


DIMENSIONS



Table

Size: 48"-30"


Can Hold Two 27" Monitor
And One Laptop



Leg


Adjustable Height
28.1"-45.7"

Can Support Your Daily Work



Power Strip

Up To 1.7" Desk Edge



Cable Manager

Size: 15.75"-7.09"-4.72"

Image: Close-up of the adjustable feet on the desk's base, allowing for leveling on various floor types.

4.3 Power Connection

Connect the desk's power cable to a suitable wall outlet. The removable desktop power outlet can be clipped to the back or side of your desk for convenient access.

BUILT-IN SOCKET

3 AC Outlets
[125V/12A]



2 USB Ports
[5V/2A]




Image: The removable desktop power outlet, featuring three AC outlets and two USB ports, shown clamped to the desk edge.

4.4 Cable Management

Utilize the included cable management device to organize and tidy up your workspace. This helps prevent cable clutter and ensures a clean aesthetic.

UP TO 30% STABLER

Durable, Spacious Single-Piece Desktop



Smooth, Single-Piece
Desktop



Uneven Two-Piece
Desktop

Image: A cable management tray installed beneath the desk, designed to hold and organize power cords and other cables.

4.5 Optional Accessories

The desk includes hooks that can be installed on the sides for hanging headphones or other items.



Image: A black hook attached to the side of the desk, suitable for hanging headphones or other accessories.

4.6 Installation Video

For a visual guide on frame installation, please refer to the official FLEXISPOT installation video:

Your browser does not support the video tag.

Video: Official FLEXISPOT Standing Desk Frame Installation Guide. This video demonstrates the step-by-step process of assembling the desk frame.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The desk features a 6-button digital controller for smooth and quiet height adjustments. Use the up (▲) and down (▼) arrow buttons to manually adjust the desk height.

MULTIFUNCTIONAL CONTROLLER




Image: Close-up of the 6-button digital controller, showing the LED display, up/down arrows, and four programmable height setting buttons.

5.2 Memory Presets

The controller includes four programmable memory presets (1, 2, 3, 4). To save a desired height:

1. Adjust the desk to your preferred height using the up/down arrows.
2. Press the 'M' button (often indicated by a person icon or 'M').
3. Immediately press one of the number buttons (1, 2, 3, or 4) to save the current height to that preset.

To recall a saved height, simply press the corresponding number button. The desk will automatically move to the programmed position.

5.3 Desktop Power Outlet

The integrated power outlet provides convenient access to power for your devices. It includes 3 standard AC outlets (125V/12A) and 2 USB charging ports (5V/2A).

BOXES MAY SHIP & ARRIVE SEPARATELY




Image: A detailed view of the desktop power outlet, highlighting the three AC sockets and two USB charging ports.

6. MAINTENANCE

To ensure the longevity and optimal performance of your FLEXISPOT EN2 desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Regularly inspect cables for any signs of wear or damage. Ensure cables are neatly managed to prevent snagging during height adjustments.
- **Weight Limit:** Do not exceed the maximum weight capacity of 176 lbs (79.8 kg).

7. TROUBLESHOOTING

If you encounter any issues with your FLEXISPOT EN2 desk, please refer to the troubleshooting section in the comprehensive manual (if available) or contact customer support. Common issues may include:

- Desk not adjusting height.
- Error codes on the digital display.
- Unusual noises during operation.

Note: A slight 0-1 inch tolerance in desktop size is normal due to manual measurement.

8. SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model Number	EN2
Desktop Dimensions	48"W x 30"D (121.9 cm x 76.2 cm)
Desktop Material	Engineered Wood (FSC-Certified)
Frame Material	Alloy Steel
Color	Black Top + Black Frame
Height Adjustment Range	28.1" to 45.7" (71.4 cm to 116.1 cm)
Lifting Mechanism	Electric
Maximum Weight Capacity	176 lbs (79.8 kg)
Noise Level	Less than 50 dB
Control Type	6-button digital controller with 4 memory presets
Power Outlet	3 AC (125V/12A), 2 USB (5V/2A)
Assembly Required	Yes

9. WARRANTY AND SUPPORT

9.1 Warranty Information

FLEXISPOT provides the following warranty coverage for the EN2 Standing Desk:




- **5-Year Warranty:** Covers frames, motors, and other mechanical devices.
- **2-Year Warranty:** Covers controllers, switches, and electronics.

Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact FLEXISPOT customer support. Refer to your product packaging or the official FLEXISPOT website for the most current contact information.

Related Documents - EN2

	<p><u>FlexiSpot EH1-EU Electric Standing Desk Frame User Manual</u></p> <p>Comprehensive user manual for the FlexiSpot EH1-EU electric standing desk frame, detailing specifications, assembly instructions, wiring, operation, and troubleshooting for optimal use.</p>
	<p><u>FlexiSpot EG8B/EG8W Installation Guide and Limited Warranty</u></p> <p>This document provides a comprehensive installation guide and limited warranty information for the FlexiSpot EG8B/EG8W adjustable standing desk. It details specifications, assembly steps, keypad operation, troubleshooting, safety precautions, and warranty terms.</p>
	<p><u>FlexiSpot EC1 Electric Height Adjustable Standing Desk Assembly Guide</u></p> <p>This assembly guide provides step-by-step instructions for setting up the FlexiSpot EC1 electric height-adjustable standing desk. It includes specifications, parts list, assembly procedures, keypad operation, troubleshooting tips, and warranty information.</p>
	<p><u>FlexiSpot E7QB Standing Desk User Manual</u></p> <p>Comprehensive user manual for the FlexiSpot E7QB standing desk, covering components, installation, usage, troubleshooting, and warranty information.</p>
	<p><u>FlexiSpot Q8B/Q8W Height Adjustable Standing Desk Installation Guide and Warranty</u></p> <p>Comprehensive installation guide and warranty information for the FlexiSpot Q8B/Q8W height adjustable standing desk, including setup instructions, usage tips, troubleshooting, and warranty details.</p>
	<p><u>FlexiSpot E2LB-V2/E2LW-V2 Electric Height-Adjustable Desk User Manual</u></p> <p>User manual for the FlexiSpot E2LB-V2 and E2LW-V2 electric height-adjustable desks, covering assembly, operation, technical specifications, and troubleshooting.</p>