

[Manuals.plus](#) /

› [Kircuit](#) /

› Kircuit AC Adapter Instruction Manual for Clickfree 528WI R528WI-1004-100 External Hard Drive

Kircuit 528WI R528WI-1004-100

Kircuit AC Adapter Instruction Manual

Model: 528WI R528WI-1004-100 for Clickfree External Hard Drives

INTRODUCTION

This instruction manual provides essential information for the safe and proper use of your Kircuit AC Adapter, specifically designed as a replacement power charger for Clickfree 528WI R528WI-1004-100 External Hard Drives. Please read this manual thoroughly before using the product and retain it for future reference.



Image: Two Kircuit AC adapters. The label on the front adapter displays "KIRCUI AC/DC ADAPTOR INPUT: 100-240V AC 50/60Hz 0.3A OUTPUT:  MADE IN CHINA".

Safety Information

Observe the following safety precautions to prevent injury or damage to the product and connected devices:

- Use the adapter only with compatible devices as specified.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open, modify, or repair the adapter. Refer servicing to qualified personnel.
- Ensure the power outlet is easily accessible and unplug the adapter during electrical storms or when unused for long periods.

- Keep out of reach of children.

Built Safety Protections




Image: Diagram showing the Kircuit adapter's built-in safety features, including protection against short circuits, excess voltage, over-temperature, and overcurrent.

SETUP

1. **Verify Compatibility:** Ensure the Kircuit AC Adapter is compatible with your specific Clickfree External Hard Drive model (528WI R528WI-1004-100). Check the voltage and current requirements of your device against the adapter's specifications.
2. **Connect to Device:** Plug the DC output connector of the Kircuit AC Adapter into the power input port of your Clickfree External Hard Drive.
3. **Connect to Power Outlet:** Insert the AC input plug of the adapter into a standard wall power outlet (100-240V AC).
4. **Power On:** Once connected, your external hard drive should receive power.



Image: The Kircuit AC adapter plugged into a power strip, illustrating how to connect it to a power source.

OPERATING INSTRUCTIONS

The Kircuit AC Adapter functions as a direct power supply for your compatible external hard drive. No specific operational steps are required beyond proper connection.

- Ensure the adapter is securely plugged into both the device and the wall outlet.
- The adapter is designed for continuous use within its specified operating parameters.
- If the device is not receiving power, check all connections and the power outlet.

MAINTENANCE

To ensure the longevity and optimal performance of your Kircuit AC Adapter:

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires, cracks, or bent pins. Discontinue use if damage is observed.

Durable design




Image: Details of the adapter's durable cable design, highlighting high-quality materials and thick insulation for protection against wear and high temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not powering on.	• Adapter not fully plugged in. • Power outlet is not active. • Device power input issue. • Damaged adapter.	• Ensure both ends of the adapter are securely connected. • Test the outlet with another device. • Verify the device's power input port is functional. • Inspect the adapter for visible damage. If damaged, discontinue use.
Adapter feels unusually hot.	• Overload or faulty device. • Poor ventilation.	• Disconnect immediately. Ensure the connected device is compatible and not drawing excessive power. • Ensure the adapter is in a well-ventilated area.

SPECIFICATIONS

Brand	Kircuit
Model	528WI R528WI-1004-100 (Compatible)
Input Voltage	100-240V AC, 50/60Hz
Output	DC Output (Specific voltage/current not provided in source data)
Cord Length	Approximately 6.5 ft
Special Features	Portable, Travel, Built-in safety protections (Short Circuit, Over Voltage, Over Temperature, Overcurrent)
Item Weight	8 Ounces



Image: The Kircuit AC adapter with its power cord, clearly indicating a cord length of 6.5 feet.

WARRANTY AND SUPPORT

Kircuit products are designed for reliability and performance. While specific warranty details are not provided in this manual, the product packaging may indicate a **3-year warranty**. For support or warranty claims, please contact your retailer or the manufacturer directly.

For further assistance, refer to the contact information provided with your purchase or visit the official Kircuit website.



Image: A Kircuit AC adapter and its packaging on a desk, with the packaging clearly displaying a "3 YEAR" warranty.

© 2023 Kircuit. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question