Knup KP-8004

Knup KP-8004 Digital Voice Recorder with LCD Display - User Manual

Model: KP-8004

1. Introduction

Thank you for choosing the Knup KP-8004 Digital Voice Recorder. This device is designed for high-quality audio recording and playback, featuring an 8GB internal memory, an LCD display, and MP3 player functionality. It is ideal for lectures, meetings, interviews, and personal notes. Please read this manual carefully to ensure proper use and to maximize the performance of your device.

2. Package Contents

Please check the package contents upon unboxing. If any items are missing or damaged, contact your retailer.

- Knup KP-8004 Digital Voice Recorder
- USB Cable
- Headphones (P2 output compatible)
- Lapel Microphone
- RJ11 Kit (for telephone recording)
- User Manual (this document)



Figure 1: Knup KP-8004 Digital Voice Recorder and included accessories.

3. Product Overview

Familiarize yourself with the various parts of your Knup KP-8004 voice recorder.



Figure 2: Front view of the Knup KP-8004 Digital Voice Recorder, highlighting the LCD display and control buttons.



Figure 3: Top view of the Knup KP-8004, showing the built-in microphone.



Figure 4: Side view of the Knup KP-8004, illustrating the various control buttons and ports.

Key Components:

- **LCD Display:** Shows recording status, time, battery level, and menu options.
- **Built-in Microphone:** For capturing audio.
- **REC Button:** Starts recording.
- **STOP Button:** Stops recording or playback.
- **PLAY/PAUSE Button:** Plays or pauses audio.
- **VOL+ / VOL- Buttons:** Adjusts volume.
- **MODE Button:** Switches between recording, playback, and MP3 modes.
- **UP / DOWN Buttons:** Navigation buttons for menu and track selection.
- **HOLD Switch:** Locks all buttons to prevent accidental operation.
- **USB Port:** For connecting to a computer and charging (if applicable).
- **Headphone Jack (P2):** For connecting headphones.
- **External Microphone Jack:** For connecting the lapel microphone.
- **RJ11 Port:** For connecting the RJ11 kit for telephone recording.

4. Setup

4.1 Battery Installation

The Knup KP-8004 requires two AAA batteries (not included). Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the device.
2. Slide or lift the cover to open the compartment.
3. Insert two AAA batteries, matching the positive (+) and negative (-) terminals as indicated inside the compartment.
4. Close the battery compartment cover securely.

4.2 Powering On/Off

- **To Power On:** Slide the power switch (if present) or press and hold the PLAY/PAUSE button until the LCD screen illuminates.
- **To Power Off:** Press and hold the STOP button until the device shuts down.

5. Operating Instructions

5.1 Recording Audio

1. Ensure the device is powered on and in recording mode (check the LCD display).
2. To start recording, press the **REC** button. The recording indicator light will illuminate, and the display will show recording time.
3. To pause recording, press the **PLAY/PAUSE** button. Press it again to resume.
4. To stop recording, press the **STOP** button. The recording will be saved automatically.

5.2 Voice Operated Recording (VOR)

The VOR function allows the recorder to start recording automatically when sound is detected and pause when silence occurs, saving memory and battery life. Refer to the device's on-screen menu for VOR activation and sensitivity settings.

5.3 Playback

1. In stop mode, use the **UP** and **DOWN** buttons to select the desired audio file.
2. Press the **PLAY/PAUSE** button to start playback.
3. Adjust the volume using the **VOL+** and **VOL-** buttons.
4. To fast forward or rewind, press and hold the **UP** or **DOWN** buttons during playback.
5. To stop playback, press the **STOP** button.

5.4 MP3 Player Function

The device can also function as an MP3 player. Transfer MP3 files to the device's internal memory via USB. Use the **MODE** button to switch to MP3 playback mode and navigate your music files.

5.5 Connecting to a Computer

Connect the voice recorder to your personal computer, notebook, or tablet using the provided USB cable to transfer files.

1. Ensure the device is powered on.
2. Connect one end of the USB cable to the recorder's USB port and the other end to a USB port on your computer.
3. The device will be recognized as a removable disk. You can then drag and drop audio files to and from the recorder.
4. Always safely eject the device from your computer before disconnecting the USB cable.

6. Maintenance

- Keep the device dry. Avoid exposure to moisture or liquids.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping the device or subjecting it to strong impacts.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Remove batteries if the device will not be used for an extended period to prevent leakage.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low or dead batteries; incorrect battery installation.	Replace batteries; ensure correct polarity.
Cannot record.	Memory full; HOLD switch engaged; device in playback mode.	Delete old files; disengage HOLD switch; switch to recording mode.
No sound during playback.	Volume too low; headphones not connected properly or faulty.	Increase volume; check headphone connection; try different headphones.
Computer does not recognize device.	Faulty USB cable; incorrect connection; driver issue.	Try a different USB cable or port; ensure device is powered on; restart computer.

8. Specifications

- **Brand:** Knup
- **Model:** KP-8004
- **Storage Capacity:** 8 GB
- **Interface:** USB, USB 2.0
- **Compatible Devices:** Personal Computer, Notebook, Tablet
- **Microphone:** Built-in, high sensitivity
- **Microphone Range:** Up to 8 meters
- **Media Formats:** WAV, WMA, MP3 Audio
- **Recording Time:** Up to 140 hours (approximate, depends on quality settings)
- **Power Source:** 2 x AAA Batteries (not included)
- **Display:** LCD
- **Features:** MP3 Player function, Voice Operated Recording (VOR)

9. Warranty and Support

For warranty information, please refer to the warranty card included with your purchase or contact your retailer. For technical support or further assistance, please visit the official Knup website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question