

[Manuals.plus](#) /

› [QPLAY](#) /

› QPLAY Prime 3-in-1 Evolutionary Tricycle QP100.00 User Manual

QPLAY QP100.00

QPLAY Prime 3-in-1 Evolutionary Tricycle User Manual

Model: QP100.00 | Brand: QPLAY

INTRODUCTION

The QPLAY Prime 3-in-1 Evolutionary Tricycle is a versatile product designed to adapt to your child's growth from approximately 6 months to 36 months. This manual provides essential information for the safe assembly, operation, and maintenance of your tricycle, ensuring a comfortable and enjoyable experience for both child and parent.

SAFETY INFORMATION

WARNING: Always use this product under the direct supervision of an adult.

- Ensure all parts are securely fastened before each use.
- Do not use the tricycle on public roads or near traffic.
- Keep children away from moving parts during adjustments.
- Regularly inspect the tricycle for any signs of wear or damage.

SETUP AND ASSEMBLY

The QPLAY Prime Tricycle requires assembly. Please follow these general steps. Refer to the included diagrams for specific component identification and placement.

1. Unpack all components and verify against the parts list.
2. Attach the front wheel assembly to the main frame.
3. Install the rear wheels onto the rear axle.
4. Secure the seat unit to the frame, ensuring it clicks into place.
5. Attach the parent handle and canopy.
6. Install the safety bar and footrests.
7. Check all screws, bolts, and quick-release mechanisms to ensure they are tight and secure.



Image: Overview of tricycle components and key features.

OPERATING INSTRUCTIONS

The QPLAY Prime Tricycle offers multiple configurations to support your child's development:

Stage 1: Parent-Facing Mode (Approx. 6-18 Months)

In this mode, the seat faces the parent, allowing for direct interaction. The backrest can be reclined for naps. The child's feet rest on the central foldable footrest.

- **Seat Rotation:** To switch between parent-facing and forward-facing, use the swivel mechanism located under the seat.
- **Reclining Backrest:** Adjust the backrest to one of three levels for optimal comfort.
- **Safety Harness:** Always secure your child with the 5-point safety harness.
- **Safety Bar:** Ensure the safety bar is closed and locked.



Image: Tricycle configured for parent-facing use.

Stage 2: Forward-Facing with Parent Handle (Approx. 18-24 Months)

The seat is turned to face forward, allowing the child to observe their surroundings while the parent maintains control with the telescopic handle.

- **Parent Handle:** The telescopic parent handle allows for steering and pushing.
- **Pedal Lock:** Engage the pedal lock system to prevent the child from pedaling independently.
- **Footrests:** The central foldable footrest can be used, or the child can place their feet on the removable footrests.



Image: Tricycle in forward-facing mode with parent handle.

Stage 3: Tricycle with Parent Handle (Approx. 24-36 Months)

The child can begin to pedal independently while the parent still has the option to steer and assist with the handle. The safety bar can be removed.

- **Pedals:** Unlock the pedal system to allow the child to pedal. The pedals are anti-slip.
- **Removable Safety Bar:** The safety bar can be removed as the child gains confidence.
- **Canopy:** The extendable anti-UV canopy provides sun protection.



Image: Tricycle with extended canopy for sun protection.

Stage 4: Independent Tricycle (Approx. 36+ Months)

The parent handle and canopy can be removed, allowing the child to ride the tricycle independently.

- **Parent Handle Removal:** Detach the telescopic parent handle.
- **Canopy Removal:** Remove the canopy for full open-air riding.
- **Rear Brakes:** Utilize the rear brakes for stopping.
- **Storage Bag:** A storage bag is included for carrying small items.



Image: Rear wheels and integrated storage bag.

MAINTENANCE

- **Cleaning:** Wipe down the tricycle regularly with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Lubrication:** Periodically check and lubricate moving parts such as wheel axles and pedal mechanisms if necessary.
- **Storage:** Store the tricycle in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation.
- **Inspection:** Regularly inspect all fasteners, wheels, and fabric components for wear, damage, or loose connections. Tighten any loose parts immediately.

TROUBLESHOOTING

- **Wobbly Wheels:** Check if the wheel axles are properly secured and tightened.
- **Difficulty Steering:** Ensure the parent handle is correctly engaged and the steering mechanism is free of obstructions.
- **Pedals Not Engaging:** Verify that the pedal lock system is disengaged for independent pedaling.
- **Seat Not Swiveling:** Check for any obstructions or debris in the swivel mechanism. Ensure the seat is properly aligned.

SPECIFICATIONS

Feature	Specification
Brand	QPLAY
Model Number	QP100.00
Material	Plastic
Dimensions (L x W x H)	79 x 53 x 104.5 cm
Minimum Recommended Age	6 Months
Maximum Recommended Age	36 Months
Assembly Required	Yes
Included Components	Tricycle
GTIN/UPC	686268624563



Image: Tricycle dimensions (Length: 108 cm, Width: 53 cm, Height: 104 cm).

WARRANTY INFORMATION

This QPLAY Prime Tricycle comes with a manufacturer's warranty of **2 years** from the date of purchase. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use conditions.

CUSTOMER SUPPORT

For further assistance, spare parts, or to report any issues not covered in this manual, please contact QPLAY customer support through their official website or the retailer where the product was purchased. Have your model number (QP100.00) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question