

[Manuals.plus](#) /

› [YuYue Electronic](#) /

› YuYue Electronic Wireless Bluetooth Media Button Remote User Manual

YuYue Electronic AUB081RLWSTL

YuYue Electronic Wireless Bluetooth Media Button Remote User Manual

Model: AUB081RLWSTL

1. INTRODUCTION

The YuYue Electronic Wireless Bluetooth Media Button Remote provides convenient wireless control over your smartphone's media functions, camera, and voice assistant. Designed for versatility, it can be used in various settings, including cars, motorcycles, and for taking selfies. This manual will guide you through the setup, operation, and maintenance of your device.



Image 1.1: The YuYue Electronic Wireless Bluetooth Media Button Remote, a compact black circular device with media

2. KEY FEATURES

- **Wireless Bluetooth Connectivity:** Compatible with most iOS devices (Bluetooth 3.0 and higher) and Android OS (4.4 or higher).
- **Media Control:** Play, pause, skip tracks, and adjust volume for music and other media.
- **Selfie Control:** Utilize volume buttons as a remote shutter for your smartphone camera.
- **Voice Command Activation:** Activate your phone's voice assistant (e.g., Siri, Google Assistant). Note: Siri activation may not be supported on iOS X and above.
- **Plug and Play:** Simple Bluetooth pairing without additional app installations.
- **Long Battery Life:** Equipped with a CR2025 battery, offering extended usage.
- **Compact Design:** Small and portable, with an included mount for easy attachment to steering wheels or handlebars.



Control your music wirelessly!



Image 2.1: Visual representation of the remote's capabilities, including wireless music control, selfie capture, and voice command activation.

3. PACKAGE CONTENTS

Please verify that all items are present in your package:


- YuYue Electronic Wireless Bluetooth Media Button Remote
- Mount for attachment
- CR2025 Battery (pre-installed or separate)
- 3M Sticker (for alternative mounting)



Smart Remote



CR2016 Battery



3M Sticker



Simply pair the SmartRemote to your phone or tablet via bluetooth, There is no software to install or any apps to download.



The volume button can be a remote shutter



The wireless bluetooth range is 10 meters



If SmartRemote has been left idle for 30 second, it will switch to sleep mode, you can press any key to wake it up, it will automatically re-connected.



The included CR2016 battery has an amazingly long battery life

Image 3.1: The remote, a CR2016 battery (note: product specifications state CR2025), and a 3M sticker, illustrating the package contents.

4. SETUP AND PAIRING

4.1. Initial Pairing

1. Ensure the remote has a working CR2025 battery installed.
2. Long press any button on the remote for approximately 3 seconds to power it on and activate Bluetooth. A blue light will begin flashing on the front of the remote, indicating it is in pairing mode.
3. On your smartphone or tablet, navigate to the Bluetooth settings.
4. Search for available devices and select "Smart Remote" from the list to connect.
5. Once connected, the blue light will stop flashing or change its pattern (refer to device for specific indication).



Long press 3 seconds boot, activate Bluetooth



A blue light will begin flashing on the front of your bluetooth button



Under your bluetooth settings select "Smart Remote" to connect the button

for iOS System Setting Manual




Image 4.1: Visual guide for Bluetooth pairing, showing the remote's indicator light and smartphone Bluetooth settings.

4.2. Installation (Optional)

The remote comes with a mount for easy attachment to a steering wheel or motorcycle handlebars. Use the provided mount to secure the remote in a convenient and safe location. A 3M sticker is also included for alternative mounting options on flat surfaces.

Media Button Remote



**Control
Music**



**Control
Volume**



**Selfie
Remote**



Image 4.2: The remote mounted on a car dashboard, demonstrating a typical installation scenario.

5. OPERATING INSTRUCTIONS

5.1. Media Control

Once paired, the remote allows you to control your device's media playback:

- **Play/Pause:** Press the central button () to play or pause media.
- **Next Track:** Press the right arrow button (>) to skip to the next track.
- **Previous Track:** Press the left arrow button (<) to go to the previous track.
- **Volume Up:** Press the '+' button to increase volume.
- **Volume Down:** Press the '-' button to decrease volume.



Image 5.1: A hand operating the remote to control music playback on a smartphone.

5.2. Selfie Function

The volume buttons on the remote can also function as a remote shutter for your smartphone camera. Open your camera application and press either the '+' or '-' button to capture a photo.

5.3. Voice Command Activation

To activate your phone's voice assistant (e.g., Siri for iOS, Google Assistant for Android), long-press the central Play/Pause button. Note that Siri activation may not be supported on iOS X and above.



Activate your phone's voice commands!



Image 5.2: The remote being used to activate a smartphone's voice command feature.

5.4. Sleep Mode and Reconnection

If the remote is idle for approximately 30 seconds, it will enter sleep mode to conserve battery. To wake it up, simply press any button. The remote will automatically attempt to reconnect to the last paired device.

6. MAINTENANCE

6.1. Battery Replacement

The remote uses one CR2025 Lithium Metal battery. When the remote's performance degrades or it fails to connect, it may be time to replace the battery. To replace the battery:

1. Carefully pry open the back cover of the remote.
2. Remove the old CR2025 battery.
3. Insert a new CR2025 battery with the positive (+) side facing up.
4. Snap the back cover securely into place.

Note: Some product images may incorrectly show a CR2016 battery. Please use a CR2025 battery as specified in the product features.

6.2. Cleaning

Wipe the remote with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the device.

7. TROUBLESHOOTING

- **Remote not connecting:**
 - Ensure Bluetooth is enabled on your smartphone/tablet.
 - Verify the remote is powered on (blue light flashing during pairing).
 - Check if the remote's battery needs replacement.
 - If the remote is in sleep mode, press any button to wake it up.
 - Try unpairing and re-pairing the device from your phone's Bluetooth settings.
- **Buttons not responding:**
 - Ensure the remote is actively connected to your device.
 - Check the battery level.
 - Restart your smartphone/tablet and try again.
- **Siri/Voice Assistant not activating on iOS X and above:**
 - This is a known compatibility limitation for some iOS versions. The remote may not be able to activate Siri on iOS X and newer versions.

8. SPECIFICATIONS

Feature	Detail
Model Number	AUB081RLWSTL
Connectivity Technology	Bluetooth
Power Source	Battery Powered
Battery Type	1 Lithium Metal (CR2025)
Material	Plastic

Item Weight	1.44 ounces (approx. 40.8 grams)
Package Dimensions	3.74 x 2.91 x 2.13 inches
Compatibility	iOS 3.0+ (excluding Siri on iOS X+), Android 4.4+



Image 8.1: The remote shown in hand for size reference, with compatibility details.

9. SAFETY INFORMATION

Please observe the following safety guidelines:

- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.
- Do not expose the device to extreme temperatures, direct sunlight, or moisture.

- Avoid disassembling the device beyond battery replacement.
- Ensure the remote is securely mounted if used in a vehicle to prevent distraction or interference with controls.

10. WARRANTY AND SUPPORT

For any issues encountered during use, please contact YuYue Electronic customer support. Specific warranty details may vary; please refer to your purchase documentation or contact the seller for more information.

© 2025 YuYue Electronic. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B081RLWSTL>

More documents and user manuals: <https://manuals.plus/>