

Ikea TILLREDA

Ikea TILLREDA Portable Induction Hob

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Ikea TILLREDA Portable Induction Hob. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information

To prevent personal injury or damage to the appliance, always observe the following safety precautions:

- Ensure the hob is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the appliance in water or other liquids.
- Keep the appliance away from children and individuals with reduced physical, sensory, or mental capabilities.
- Use only cookware with a magnetic base suitable for induction hobs.
- Do not touch the hot surface immediately after cooking. The hob surface may retain residual heat.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Ensure adequate ventilation around the hob during operation.

Setup

1. **Unpacking:** Carefully remove the hob from its packaging. Retain packaging materials for potential future transport or storage.
2. **Placement:** Place the induction hob on a stable, level, and dry surface. The integrated rubber feet provide stability. Ensure there is sufficient space around the hob for proper air circulation.
3. **Power Connection:** Connect the power cord to a suitable 220V electrical outlet. The hob operates at a connection rating of 2000W and a current of 8.5A.



This image displays the Ikea TILLREDA Portable Induction Hob in use, featuring a black wok filled with colorful stir-fried vegetables. The hob is placed on a light wooden countertop, next to a white plate and a wooden spoon. The hob itself is white with a black glass cooking surface and touch controls.

Operating Instructions

1. **Cookware Selection:** Use only induction-compatible cookware with a magnetic base. The hob will not operate with non-magnetic pots or pans.
2. **Power On:** Place the induction-compatible cookware centrally on the cooking zone. Plug the hob into the power outlet.
3. **Control Panel:** The touch-control panel is located at the front of the hob. Use the touch controls to power on the appliance and adjust settings.
4. **Adjusting Heat:** Select the desired heat level using the '+' and '-' touch buttons. The electronic display will show the current setting.
5. **Fry Function:** Utilize the powerful fry function for instant high heat, suitable for stir-frying.
6. **Child Lock:** The electronic display includes a child lock feature to prevent accidental operation. Refer to the display icons for activation and deactivation.
7. **Power Off:** After cooking, reduce the heat to minimum and then press the power off button on the touch panel. Unplug the hob from the power outlet.

Induction technology transfers energy directly into magnetic cookware, making it highly energy-efficient, fast, and precise for cooking.

Maintenance and Cleaning

- Always unplug the hob and allow it to cool completely before cleaning.
- The smooth tempered glass surface with the integrated touch control panel is easy to clean. Wipe the surface with a damp cloth and a mild detergent.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the glass surface.
- Ensure no liquid enters the internal components of the hob.
- Clean the ventilation openings regularly to prevent dust buildup.

Storage

The TILLREDA Portable Induction Hob is designed for easy storage:

- The hob can be hung using the holes located in the back.
- The handle can also be used as a hook for hanging. The handle facilitates easy carrying and movement of the hob.
- To keep the cord organized, wrap it around the stove knob and secure it with clips when the hob is not in use.

Troubleshooting

If you encounter issues with your hob, refer to the following common troubleshooting steps:

- **Hob not turning on:** Check if the power cord is securely plugged into a working outlet. Ensure the power button on the touch panel has been pressed.
- **No heat/Cookware not detected:** Verify that the cookware is induction-compatible and has a magnetic base. Ensure the pot or pan is centered on the cooking zone.
- **Error codes on display:** Consult the specific error code in the full product manual (if available) or contact customer support.
- **Overheating:** If the hob automatically shuts off, it may be due to overheating. Unplug the unit and allow it to cool down before attempting to use it again. Ensure ventilation openings are clear.

Specifications

Brand	Ikea
Model	TILLREDA
ASIN	B081RN8528
Power / Wattage	2000 watts
Voltage	220V
Current	8.5A
Material	Tempered Glass







Special Features	Induction, Portable, Easy Storage
Heating Elements	1
Type of Controls	Touch
Item Weight	6 g
First Available Date	25 November 2019

Warranty and Support

For information regarding warranty coverage, product support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Ikea website. Keep your proof of purchase for warranty claims.

Related Documents - TILLREDA

<p>TILLREDA</p>  	<p>TILLREDA Portable Induction Hob User Manual</p> <p>Comprehensive user manual for the IKEA TILLREDA portable induction hob, covering safety instructions, product description, daily use, cookware guidance, care and cleaning, and troubleshooting.</p>
<p>TILLREDA</p>  	<p>TILLREDA Portable Induction Hob User Manual</p> <p>Comprehensive user manual for the IKEA TILLREDA portable induction hob, covering safety instructions, product description, daily use, cookware guidance, care and cleaning, and troubleshooting.</p>
	<p>IKEA TILLREDA Portable Induction Hob User Manual</p> <p>User manual for the IKEA TILLREDA portable induction hob, covering safety, installation, operation, care, troubleshooting, and warranty information.</p>

<div>TILLREDA</div> <div></div> <div></div>	<div>TILLREDA Portable Induction Hob User Manual</div> <div>User manual and safety instructions for the IKEA TILLREDA portable induction hob, covering installation, operation, care, and troubleshooting.</div>
<div>TILLREDA</div> <div></div> <div></div>	<div>IKEA TILLREDA Portable Induction Hob User Manual and Safety Guide</div> <div>This user manual provides essential information for the safe installation, operation, and maintenance of the IKEA TILLREDA portable induction hob. It covers safety, operation, care, troubleshooting, and warranty details.</div>
<div>TILLREDA</div> <div></div> <div></div>	<div>IKEA TILLREDA Induction Hob User Manual</div> <div>Comprehensive user manual for the IKEA TILLREDA induction hob, covering safety, operation, maintenance, troubleshooting, and technical specifications for domestic use.</div>