

[Manuals.plus](#) /

› [Keurig](#) /

› Keurig K-Elite Coffee Maker Instruction Manual

Keurig K-Elite

Keurig K-Elite Coffee Maker Instruction Manual

Model: K-Elite | Brand: Keurig

INTRODUCTION

The Keurig K-Elite Single Serve K-Cup Pod Brewer offers a versatile and convenient way to enjoy your favorite beverages. Designed for ease of use, this brewer features multiple cup size options, a strong brew setting, and an innovative iced coffee capability. Its large water reservoir minimizes refills, making your daily routine smoother. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your Keurig K-Elite coffee maker.



Image: Keurig K-Elite Coffee Maker in Brushed Silver, shown with a blue mug, water filter, and reusable coffee filter.

SETUP

1. **Unpacking:** Carefully remove all packaging materials from the brewer. Place the brewer on a stable, level surface.
2. **Water Reservoir:** Remove the water reservoir from the side of the brewer. Lift the reservoir lid and fill it with fresh, filtered water up to the 'MAX' fill line. The 75oz capacity allows for multiple brews before refilling.
3. **Water Filter:** If included, insert the water filter cartridge into the filter holder and place it inside the water reservoir. This helps ensure clean-tasting beverages.
4. **Initial Rinse Brew:** Place a large mug on the drip tray. Power on the brewer. Do not insert a K-Cup pod. Select the largest brew size (12oz) and press the brew button. Discard the hot water. This cleans the brewer and prepares it for use.

K•Elite™

SINGLE SERVE COFFEE MAKER



75oz
Removable
water reservoir



Image: The large 75oz removable water reservoir of the Keurig K-Elite, demonstrating how water is poured into it.

OPERATING INSTRUCTIONS

1. **Brewing Coffee:** Lift the handle and place a K-Cup pod into the K-Cup pod holder. Lower the handle completely. Place a mug on the drip tray. Select your desired brew size (4, 6, 8, 10, or 12oz) and press the corresponding button. The brewer will begin brewing.
2. **Strong Brew:** For a bolder, more intense coffee, press the **STRONG** button before selecting your brew size.
3. **Iced Setting:** To brew over ice, fill a large tumbler (do not use glass) with ice. Place it on the drip tray. Insert a K-Cup pod. Press the **ICED** button, then select your desired brew size. The brewer will optimize the brew for iced coffee.
4. **Hot Water on Demand:** For instant soups, oatmeal, or other hot beverages, lift and lower the handle without inserting a K-Cup pod. Place a mug on the drip tray. Press the **HOT WATER** button.

K-Elite™

SINGLE SERVE COFFEE MAKER



STRONG BREW

Brew a stronger, more intense cup



ICED COFFEE

Brew hot, enjoy cold — full-flavored and delicious



5 CUP SIZES

4, 6, 8, 10, 12oz



<1 MINUTE BREW TIME

for fresh brewed coffee



ENERGY SAVER

Programmable auto on/off



Image: Overview of Keurig K-Elite features, highlighting Strong Brew, Iced Coffee, and various cup size options.

K-Elite™

SINGLE SERVE COFFEE MAKER



EASY ICED COFFEE

full-flavored and delicious

Brew delicious iced beverages easier than ever with the **ICED button**

Fill your cup to the top with ice

Press the **ICED button** - the K-Elite™ Coffee Maker selects the optimal size and strength for a perfectly brewed iced beverage



FILL
WITH ICE
do not use glass



BREW
HOT



ENJOY
COLD



Image: The Keurig K-Elite brewing an iced coffee beverage into a tall glass filled with ice.

K•Elite™

SINGLE SERVE COFFEE MAKER



HOT WATER ON DEMAND

Press the HOT
WATER button
for instant soups
and oatmeal



Image: The Keurig K-Elite dispensing hot water into a bowl of oatmeal, demonstrating the hot water on demand feature.

Drip Tray

The drip tray is removable to accommodate larger travel mugs. Simply lift the drip tray assembly off the base to place a taller mug. Remember to replace the drip tray after use.

K•Elite™

SINGLE SERVE COFFEE MAKER



REMOVABLE DRIP TRAY

Fits a 7.2"
travel mug



Image: The removable drip tray of the Keurig K-Elite, shown detached to fit a taller travel mug.

PROGRAMMABLE SETTINGS

The Keurig K-Elite offers several programmable settings for a customized brewing experience:

- **Clock:** Set the current time on the digital display.
- **Auto On/Off:** Program the brewer to automatically turn on or off at specific times to conserve energy.
- **Temperature Control:** Adjust the brew temperature from 187°F to 192°F to suit your preference.
- **High Altitude Setting:** For optimal performance at higher altitudes, enable this setting.

K•Elite™

SINGLE SERVE COFFEE MAKER



PROGRAMMABLE SETTINGS

- ✓ Temperature Control
- ✓ Auto On/Off
- ✓ High Altitude Setting



Image: Close-up of the Keurig K-Elite control panel, showing options for programmable settings including temperature control and auto on/off.

MAINTENANCE

- **Descaling:** The **DESCALE** light will illuminate when it's time to descale your brewer. Follow the descaling instructions in the full user manual to remove mineral buildup.
- **Cleaning Drip Tray:** The drip tray should be emptied and cleaned regularly. It is top-rack dishwasher safe.
- **Cleaning Water Reservoir:** The water reservoir can be removed and cleaned with mild soap and water. Rinse thoroughly.

TROUBLESHOOTING

- **"ADD WATER" Light:** If this light is on, the water reservoir needs to be refilled.
- **No Brew:** Ensure the handle is fully lowered and the K-Cup pod is properly seated. Check if the water reservoir is filled.

- **Coffee Grounds in Cup:** This may indicate the exit needle is clogged. Refer to the full user manual for cleaning instructions.

For more detailed troubleshooting, please refer to the complete user manual or contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Keurig
Model Name	K-Elite Coffee Maker
Color	Brushed Silver
Product Dimensions	9.9"D x 12.7"W x 13.1"H
Item Weight	7.92 pounds
Water Reservoir Capacity	75oz
Filter Type	Reusable
Operation Mode	Fully Automatic
Human Interface Input	Buttons
Special Feature	Programmable

K•Elite®

SINGLE SERVE COFFEE MAKER



PRODUCT DIMENSIONS

13.1" High
(16.5" High when open)

9.9" Wide

12.7" Deep

Weighs 8.0 lbs



Image: Diagram showing the dimensions of the Keurig K-Elite Coffee Maker.

WARRANTY & SUPPORT

Your Keurig K-Elite Coffee Maker comes with a limited one-year warranty. For detailed warranty information, product registration, or technical support, please visit the official Keurig website or contact their customer service line. Keep your purchase receipt for warranty claims.

© 2025 Keurig. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question