Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SupplySource B081TVKVMZ

SupplySource AC Adapter Charger User Manual

For Lepy LP7498E+ 200W Class D HiFi Amplifier Audio Power

1. Introduction

This manual provides essential information for the safe and effective use of your SupplySource AC Adapter Charger. This adapter is designed to provide power to compatible devices, specifically the Lepy LP7498E+ 200W Class D HiFi Amplifier Audio Power unit.

Before using the product, please read this manual thoroughly and retain it for future reference. Ensure the DC output and tip size of this AC adapter are compatible with your device before connecting.

2. Safety Information

To ensure safe operation and prevent damage, observe the following safety guidelines:

- **Voltage Compatibility:** Verify that the input voltage range of the adapter (100-240V) is suitable for your electrical outlet.
- **Device Compatibility:** Always confirm that the DC output voltage and connector tip size of the adapter match the requirements of your device (e.g., Lepy LP7498E+ amplifier). Incorrect voltage or tip size can damage your equipment.
- **Protection Features:** This adapter includes safeguards against incorrect voltage (IV), short circuits (SC), and internal overheating (IO). It is certified with CE and FCC standards for safety.
- **Ventilation:** When using the adapter for extended periods, ensure it is placed in a well-ventilated area. Avoid covering the adapter or placing it on heat-sensitive surfaces.
- **Environmental Conditions:** Do not expose the adapter to excessive humidity, moisture, or extreme temperatures. Keep it away from direct sunlight and heat sources.
- **Physical Handling:** Avoid dropping or subjecting the adapter to strong impacts. Do not attempt to open or modify the adapter.
- **Cord Integrity:** Regularly inspect the power cord for any signs of damage. Do not use the adapter if the cord is frayed or damaged.

3. Setup Instructions

1. **Unpack the Adapter:** Carefully remove the AC adapter and its power cord from the packaging.
2. **Verify Compatibility:** Double-check that the adapter's output specifications (voltage, amperage, and connector type) match your device's power input requirements.
3. **Connect Power Cord:** Insert the AC power cord into the adapter's input port. Ensure a firm connection.
4. **Connect to Device:** Plug the adapter's DC output connector into the power input port of your Lepy LP7498E+ amplifier.
5. **Connect to Wall Outlet:** Finally, plug the AC power cord into a standard electrical wall outlet.
6. **Power On:** Once all connections are secure, power on your device according to its own instructions.

4. Operating Instructions

The SupplySource AC Adapter Charger operates automatically once connected correctly. It provides a stable power supply to your compatible device.

- Ensure all connections are secure before powering on your device.
- The adapter is designed for continuous operation within its specified limits.
- If the adapter feels excessively hot, disconnect it immediately and allow it to cool down in a well-ventilated area.

5. Maintenance

Proper maintenance ensures the longevity and reliable performance of your AC adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the power cord to prevent damage.
- **Ventilation:** Always ensure adequate airflow around the adapter during operation to prevent overheating.

6. Troubleshooting

If you encounter issues with your AC adapter, consider the following steps:

- **No Power to Device:**
  - Check if the adapter is securely plugged into both the wall outlet and your device.
  - Ensure the wall outlet is functional by testing it with another device.
  - Verify that the adapter's specifications (voltage, current, tip size) are correct for your device.
  - Inspect the power cord and adapter for any visible damage.
- **Adapter Overheating:**
  - Disconnect the adapter and allow it to cool.
  - Ensure it is in a well-ventilated area and not covered.
  - If overheating persists, discontinue use and contact support.

7. Product Features and Components

The SupplySource AC Adapter Charger is engineered with quality materials and design for reliable performance. Below

are key features and a visual representation of the product:



Image: SupplySource AC Adapter Charger with its detachable power cord.

- **Stable Output Voltage:** Designed to provide a consistent and stable power output to protect your connected devices.
- **Advanced Protection:** Features automatic overload cut-off, over-voltage cut-off, automatic thermal cut-off, and short circuit protection for enhanced safety.
- **High-Quality Power Cord:** The power cord is constructed with a high-quality 3x0.5 mm copper core, offering excellent antioxidant properties and corrosion resistance for durability.
- **Durable Casing:** The power supply's shell is made from flame-retardant and high-temperature resistant ABS and PC synthetic materials, ensuring a strong and wear-resistant build.

8. Specifications

Brand	SupplySource

Manufacturer	SupplySource
Compatible Devices	Lepy LP7498E+ 200W Class D HiFi Amplifier (adapter for general use)
Input Voltage	100-240 Volts
Wattage	200 watts
Frequency Range	60 hertz
Connector Type	Barrel Connector
Main Power Connector Type	2 Pin
Material	Metal, Plastic (ABS and PC synthetic materials)
Power Source	Corded Electric
Certifications	CE, FCC
ASIN	B081TVKVMZ
Date First Available	November 22, 2019

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2024 SupplySource. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081TVKVMZ

More documents and user manuals: **https://manuals.plus/**