

## Hermitshell HU-XI-201

# Hermitshell Hard EVA Travel Case Instruction Manual

Model: HU-XI-201

## 1. INTRODUCTION

---

This manual provides instructions for the Hermitshell Hard EVA Travel Case, Model HU-XI-201. This protective case is designed to safely store and transport your portable charger or power bank, such as the Ekrist/Xooparc 25800mAh models, along with small accessories. Its durable construction helps shield your device from physical damage and environmental elements.

## 2. PRODUCT OVERVIEW

---

The Hermitshell Travel Case features a hard Ethylene Vinyl Acetate (EVA) shell, providing robust protection. The interior is designed to securely hold your device and small cables.

- **Material:** Durable EVA (Ethylene Vinyl Acetate)
- **Color:** Black
- **Internal Dimensions:** Approximately 6.5 x 3.4 x 1.5 inches (16.5 x 8.6 x 3.8 cm)
- **Protection:** Hard shell design protects against bumps, dents, and scratches.
- **Interior Features:** Includes an elastic strap to secure the main device and a mesh pocket for small accessories like charging cables.
- **Portability:** Compact and lightweight, ideal for travel.

### Visual Features



Image 1: The Hermitshell case opened, showing a portable charger secured inside with an elastic strap and a mesh pocket in the lid.



**For sale is case only  
Device is not included**

Image 2: The interior of the case, highlighting the mesh pocket for accessories and the elastic band for securing the main device.



Image 3: A front view of the closed Hermitshell case, showcasing its compact and durable exterior.

### 3. SETUP

---

1. **Open the Case:** Unzip the dual zippers completely to open the case.
2. **Place Your Device:** Carefully place your portable charger or power bank into the main compartment. Ensure it fits snugly within the internal dimensions (approx. 6.5 x 3.4 x 1.5 inches).
3. **Secure the Device:** Use the elastic strap to hold your device firmly in place, preventing movement during transit.
4. **Store Accessories:** Utilize the mesh pocket in the lid for smaller items such as charging cables, earbuds, or memory cards.
5. **Close the Case:** Zip the case closed securely.
6. **Attach Carabiner (Optional):** If your case includes a carabiner, attach it to the designated loop on the case for easy carrying on bags or belts.

#### Setup Demonstration Video

Your browser does not support the video tag.

Video 1: This video demonstrates how to open the case, place a power bank and cable inside, and close it securely. It also shows the water-resistant feature.

### 4. OPERATING

---

The Hermitshell Travel Case is designed for convenient and secure transport of your electronic devices.

- **Carrying:** The compact size allows the case to be easily stored in backpacks, handbags, or luggage.
- **External Attachment:** Use the integrated loop and an optional carabiner to attach the case to the exterior of a backpack or belt for quick access.
- **Protection:** The hard EVA material provides a protective barrier against accidental drops, impacts, and minor splashes, making it suitable for various environments including travel, work, and outdoor activities.

## Portability and Attachment



Image 4: The case conveniently attached to a backpack strap using a carabiner, illustrating its portability.

Your browser does not support the video tag.

Video 2: This video shows the case being opened, a device placed inside, and the case being attached to a backpack with a carabiner.

## 5. MAINTENANCE

---

To ensure the longevity and appearance of your Hermitshell Travel Case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Allow to air dry completely.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the EVA material.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.

## 6. TROUBLESHOOTING

---

Most issues with a protective case are minor. Here are some common concerns and their solutions:

- **Zipper Stuck:** Gently apply a small amount of lubricant (like graphite from a pencil) to the zipper teeth and carefully work the zipper back and forth. Avoid forcing it.

- **Case Not Closing Properly:** Ensure that your device and any accessories are correctly positioned within the case and not overfilling it. The elastic strap should secure the main device without causing bulging.
- **Minor Scratches/Scuffs:** Due to the durable nature of EVA, minor surface marks are normal with use. These typically do not affect the protective integrity of the case.
- **Odor:** New EVA products may have a slight odor. This will dissipate over time with aeration. Leave the case open in a well-ventilated area for a few hours.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	Hermitshell
Model Number	HU-XI-201
Material	Ethylene Vinyl Acetate (EVA)
Color	Black
Internal Size	6.5 x 3.4 x 1.5 inches (16.76 x 10.92 x 5.59 cm)
Weight	113 g
Shell Type	Hard
Compatible Devices	Portable Phone Chargers (e.g., Ekrist/Xooparc 25800mAh)
Features	Shockproof, Water-resistant, Mesh Pocket, Elastic Strap, Dual Zippers

## 8. WARRANTY AND SUPPORT

---

For warranty information or product support, please refer to the seller's policy on the original purchase platform or contact Hermitshell customer service directly. Keep your proof of purchase for any warranty claims.