MINISO 4512485203525

MINISO Wireless Keyboard User Manual

Model: 4512485203525

Introduction

Thank you for choosing the MINISO Wireless Keyboard. This manual provides essential information for setting up, operating, and maintaining your new wireless keyboard. Please read it thoroughly before use to ensure optimal performance and longevity of the product.
This wireless keyboard is designed for broad compatibility, connecting seamlessly with various devices. Its compact and sleek design makes it ideal for both home and office environments.

Package Contents

- MINISO Wireless Keyboard
- User Manual (this document)
- *(Note: Batteries may not be included. Please check product packaging.)*



Image: The MINISO Wireless Keyboard shown alongside its white retail packaging box, illustrating the typical contents of the product package.

Setup Guide

1. Battery Installation

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert the required batteries (typically AAA, check compartment for specific type and quantity) ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Connecting the Keyboard (Wireless Pairing)

The MINISO Wireless Keyboard uses Bluetooth technology for connection. Follow these steps to pair it with your device:

1. Ensure the keyboard has fresh batteries installed and is powered on (if it has an on/off switch).
2. On your device (computer, tablet, smartphone), navigate to the Bluetooth settings.
3. Enable Bluetooth if it is not already enabled.
4. Your device will begin searching for nearby Bluetooth devices.
5. Look for "MINISO Keyboard" or a similar name in the list of available devices and select it.
6. If prompted, enter the pairing code displayed on your screen using the MINISO keyboard, then press Enter.
7. Once paired, the keyboard will be ready for use.




Image: A clear, top-down view of the MINISO Wireless Keyboard, showcasing its full layout including function keys and numeric pad, essential for understanding key placement during setup and operation.

Operating Instructions

Basic Usage

Once successfully paired, the MINISO Wireless Keyboard functions like a standard keyboard. You can use it for typing, navigating, and executing commands on your connected device.

Function Keys (F1-F12)

The keyboard features a row of function keys (F1-F12) that may have secondary multimedia or system control functions. These functions are typically accessed by pressing the **Fn** key simultaneously with the desired function key.

- **Fn + F1-F3:** Media playback controls (e.g., previous track, play/pause, next track).
- **Fn + F4-F6:** Volume controls (e.g., mute, volume down, volume up).
- **Fn + F7-F9:** System controls (e.g., search, share, settings).
- **Fn + F10-F12:** Brightness or other system-specific functions.

Note: Specific functions of the F-keys may vary depending on the operating system and device.



Image: An angled perspective of the MINISO Wireless Keyboard, highlighting its sleek profile and keycap design, useful for visual reference during operation.

Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your MINISO Wireless Keyboard.

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the surface of the keyboard. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place. Remove batteries if storing for a very long time to prevent leakage.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, immediately disconnect the keyboard, remove batteries, and allow it to dry completely before attempting to use it again.
- **Avoid Extreme Temperatures:** Do not expose the keyboard to extreme heat or cold.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard not connecting/pairing.	Low or dead batteries. Bluetooth not enabled on device. Keyboard not in pairing mode. Interference.	Replace batteries. Ensure Bluetooth is on and discoverable. Refer to setup guide for pairing steps. Move closer to the device; avoid other wireless devices.

Problem	Possible Cause	Solution
Keys not responding.	Connection lost. Software issue on device. Physical damage/debris.	Reconnect/re-pair the keyboard. Restart your device. Clean the keyboard (refer to Maintenance).
Lag or delayed input.	Low battery. Wireless interference. Distance from device.	Replace batteries. Reduce interference from other wireless devices. Move the keyboard closer to your device.

Specifications

Brand	MINISO
Model Number	4512485203525
Connectivity	Wireless (Bluetooth)
Compatible with	All (Universal compatibility)
Color	Silver
Keyboard Language	English
Package Dimensions	28.8 x 13.2 x 2.2 cm
Item Weight	276 g
Operating System Compatibility	Windows 10 (and generally compatible with other major OS)
Number of Keys	99
Button Quantity	104



Image: A side profile view of the MINISO Wireless Keyboard, illustrating its slim and ergonomic design, which contributes to its compact dimensions.

Warranty and Support

Specific warranty information for the MINISO Wireless Keyboard is not provided in this manual. Please refer to the product

packaging or contact MINISO customer support for details regarding warranty coverage and technical assistance. For further support or inquiries, please visit the official MINISO website or contact their customer service channels.

© 2023 MINISO. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question