

[Manuals.plus](#) /

> [MEDION](#) /

> MEDION P85289 Internet Radio User Manual

MEDION P85289

MEDION P85289 Internet Radio User Manual

Model: P85289 | Brand: MEDION

1. INTRODUCTION

The MEDION P85289 Internet Radio is a versatile audio device designed to provide access to a vast array of audio content. It features reception of over 25,000 Internet radio stations and numerous podcasts from around the world, alongside traditional DAB+ and FM radio. With integrated Wi-Fi and LAN connectivity, it offers seamless streaming from various music services including Spotify Connect, Amazon Music, Napster, Tidal, and Deezer. The device also supports local media playback via USB and AUX input, and can be controlled conveniently via a remote control or a dedicated smartphone application.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the device. Keep this manual for future reference.

- Do not expose the device to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation. Do not block ventilation openings.
- Use only the power adapter supplied with the device.
- Do not open the device casing. Refer all servicing to qualified personnel.
- Keep the device away from direct sunlight, heat sources, and strong magnetic fields.
- Avoid placing the device on unstable surfaces.
- Dispose of batteries responsibly according to local regulations.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- MEDION P85289 Internet Radio
- Remote Control (with 2 AAA batteries included)
- Power Adapter
- User Manual (this document)
- Warranty Card

4. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your MEDION P85289 Internet Radio.



Figure 4.1: Front view of the MEDION P85289 Internet Radio with its remote control.



Figure 4.2: Labeled diagram showing the front panel controls (ON/OFF & Volume knob, USB port, Navigation knob, Mode/Alarm, Info, Menu, Favorites, Play/Pause, Skip, Back buttons) and rear panel ports (LAN, AUX In, Line Out R/L, Headphone Jack, DC 9V 2A Power Supply, ON/OFF switch).

4.1 Front Panel Controls

- **ON/OFF & Volume Knob:** Press to power on/off, rotate to adjust volume.
- **USB Port:** For connecting USB storage devices.
- **Navigation Knob:** Rotate to scroll through menus, press to confirm selections.
- **Display:** 2.8" TFT color display for menu navigation and information display.
- **Function Buttons:** MODE/ALARM, INFO, MENU, FAV/★ (Favorites), Play/Pause, Skip Forward, Skip Backward, Back.

4.2 Rear Panel Connections

- **LAN Port (RJ45):** For wired network connection.
- **AUX IN:** 3.5mm stereo input for external audio devices.
- **Line Out R/L:** RCA stereo output for connecting to external amplifiers or speakers.

- **Headphone Jack:** 3.5mm stereo output for headphones.
- **DC 9V 2A:** Power input for the supplied adapter.
- **ON/OFF Switch:** Main power switch.
- **Telescopic Antenna:** For DAB+ and FM radio reception.

5. SETUP

5.1 Power Connection

1. Connect the supplied power adapter to the DC 9V 2A port on the rear of the radio.
2. Plug the power adapter into a wall outlet.
3. Flip the main ON/OFF switch on the rear panel to the 'ON' position.
4. Press the ON/OFF & Volume knob on the front panel to turn on the radio.

5.2 Antenna Setup

For optimal DAB+ and FM radio reception, fully extend the telescopic antenna located on the rear of the unit.

5.3 Network Connection

The MEDION P85289 can connect to your network via Wi-Fi or a wired LAN connection.

5.3.1 Wi-Fi Connection

1. Upon first power-on, the radio will guide you through the initial setup wizard.
2. Select "Network Wizard" or "Wi-Fi Setup" from the menu.
3. The radio will scan for available Wi-Fi networks. Select your network from the list.
4. Enter your Wi-Fi password using the navigation knob and the on-screen keyboard. Press the navigation knob to confirm each character.
5. Once connected, the radio will display a confirmation message.

5.3.2 LAN (Wired) Connection

1. Connect an Ethernet cable from your router or network switch to the LAN port on the rear of the radio.
2. The radio will automatically attempt to obtain an IP address via DHCP.
3. Verify the network status in the system settings menu to ensure a successful connection.

6. OPERATING INSTRUCTIONS

6.1 Basic Navigation

- **Navigation Knob:** Rotate to scroll through menu options or lists. Press to select an item or confirm an action.
- **MENU Button:** Access the main menu.
- **BACK Button:** Go back to the previous screen or menu.
- **INFO Button:** Display information about the current station or track.

Alles im Blick

Übersichtliche Steuerung via 2,8" TFT-Farbdisplay



Figure 6.1: The 2.8" TFT color display provides clear visual feedback for navigation and settings.

6.2 Mode Selection

Press the **MODE/ALARM** button repeatedly to cycle through available modes:

- **Internet Radio:** Access thousands of online radio stations and podcasts.
- **DAB+:** Digital Audio Broadcasting Plus radio.
- **FM:** Frequency Modulation analog radio.
- **USB:** Play audio files from a connected USB storage device.
- **AUX In:** Play audio from an external device connected via the AUX input.
- **Spotify Connect / Music Services:** Stream music directly from supported services.

6.3 Internet Radio

Access a vast library of global radio stations and podcasts.

Unendlich viel Auswahl

Über 25.000 Internet-Radiosender und digitales DAB+ Radio



Figure 6.2: The Internet Radio mode offers access to over 25,000 stations worldwide.

1. Select "Internet Radio" mode.
2. Navigate through categories (e.g., Location, Genre, Popular Stations) or use the search function to find specific stations.
3. To save a station as a favorite, tune into the station and press the **FAV/★** button. You may need to register an account with the Nuvola Smart Radio (now airtel) portal for full favorite management, as indicated by user reviews.
4. To access saved favorites, press the **FAV/★** button and select from your list.

6.4 DAB+ and FM Radio

Tune into local digital (DAB+) or analog (FM) radio broadcasts.

1. Select "DAB+" or "FM" mode using the **MODE/ALARM** button.
2. For DAB+, the radio will automatically scan for available stations upon first use or when entering the mode.
3. For FM, use the navigation knob to manually tune or perform an auto-scan for stations.
4. Press the **FAV/★** button to save current stations to your favorites list.

6.5 USB Playback

Play audio files directly from a USB storage device.



Figure 6.3: The USB port allows for direct playback of audio files from a USB drive.

1. Insert a USB flash drive into the USB port on the front panel.
2. Select "USB" mode.
3. Navigate through folders and select the desired audio file to play.
4. Use the Play/Pause, Skip Forward, and Skip Backward buttons for playback control.

6.6 AUX Input

Connect external audio sources like MP3 players or CD players.

1. Connect your external audio device to the AUX IN port on the rear of the radio using a 3.5mm audio cable (not included).
2. Select "AUX In" mode.
3. Control playback from your external device. The radio's volume control will still function.

6.7 Music Streaming Services (Spotify Connect, Amazon Music, etc.)

The radio supports direct streaming from popular music services.



Figure 6.4: The radio supports a variety of music streaming services for diverse listening options.

- **Spotify Connect:** Ensure your radio and smartphone/tablet are on the same Wi-Fi network. Open the Spotify app, play a song, and select the MEDION P85289 as the playback device from the "Devices Available" menu. A Spotify Premium subscription is required for full functionality.
- **Other Services (Amazon Music, Napster, Tidal, Deezer):** Access these services through the radio's menu. You may need an active subscription to these services. Follow the on-screen prompts for login and navigation.

6.8 MEDION Lifestream II App Control

Control your radio conveniently from your smartphone or tablet using the free MEDION Lifestream II app.




Figure 6.5: The MEDION Lifestream II app provides comprehensive control over the radio's functions.

1. Download the "MEDION Lifestream II" app from the App Store (iOS) or Google Play Store (Android).
2. Ensure your smartphone/tablet is connected to the same Wi-Fi network as your MEDION P85289 radio.
3. Open the app. It should automatically detect your radio.
4. Use the app to select modes, browse stations, control playback, and manage settings.

6.9 Alarm and Sleep Timer

Set alarms to wake up to your favorite station or use the sleep timer to fall asleep to music.

Integrierte Weckfunktion & Sleeptimer

Einschlafen und aufwachen mit dem Lieblingssender



Figure 6.6: The integrated alarm and sleep timer functions allow for personalized audio experiences for waking up or falling asleep.

- **Setting an Alarm:** Press the **MODE/ALARM** button until "Alarm" appears, or navigate to "Alarm" in the main menu. Follow the on-screen prompts to set alarm time, source (buzzer, Internet radio, DAB+, FM), volume, and recurrence.
- **Setting Sleep Timer:** Navigate to "Sleep Timer" in the main menu. Select the desired duration (e.g., 15, 30, 60, 90, 120 minutes). The radio will automatically turn off after the set time.

7. MAINTENANCE

Proper care ensures the longevity of your device.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the radio. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** If storing the radio for an extended period, disconnect it from the power outlet and store it in a cool, dry place.
- **Antenna:** Handle the telescopic antenna carefully to avoid bending or breaking.

8. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No power	Power adapter not connected; Main switch off; Power outlet issue.	Ensure power adapter is securely connected. Check main ON/OFF switch on rear. Try a different power outlet.
No sound	Volume too low; Mute activated; Incorrect source selected; Headphones connected.	Increase volume. Check if mute is active. Ensure correct input mode is selected. Disconnect headphones if not in use.
Cannot connect to Wi-Fi	Incorrect password; Router too far; Network interference; DHCP issue.	Re-enter Wi-Fi password carefully. Move radio closer to router. Check for other devices causing interference. Restart router. Ensure DHCP is enabled on your router.
Internet radio buffering/cuts out	Weak Wi-Fi signal; Slow internet connection; Network congestion.	Improve Wi-Fi signal strength (move radio, use LAN). Check internet speed. Reduce network activity from other devices.
Poor DAB+/FM reception	Antenna not extended; Location interference.	Fully extend the telescopic antenna. Try repositioning the radio for better signal.
Remote control not working	Dead batteries; Obstruction; Not pointing at sensor.	Replace AAA batteries. Remove any obstructions between remote and radio. Point remote directly at the radio's front panel sensor.

9. SPECIFICATIONS

Technical specifications for the MEDION P85289 Internet Radio.



Figure 9.1: Dimensions of the MEDION P85289 Internet Radio.

- **Model Number:** P85289
- **Connectivity:** Wi-Fi (802.11 b/g/n), LAN (RJ45), USB, AUX In, Headphone Jack, Line Out R/L
- **Radio Tuner:** Internet Radio, DAB+, FM
- **Output Power:** 2 x 6 W RMS
- **Display:** 2.8" TFT Color Display
- **Supported Streaming Services:** Spotify Connect, Amazon Music, Napster, Tidal, Deezer
- **Power Source:** AC Power Adapter (DC 9V 2A)
- **Weight:** 1.2 Kilograms
- **Dimensions (W x H x D):** Approximately 29 cm x 11.3 cm x 14.1 cm
- **Included Accessories:** Remote Control (with 2 AAA batteries)

10. WARRANTY AND SUPPORT

Your MEDION P85289 Internet Radio comes with a warranty. Please refer to the included warranty card for specific terms and conditions, including the warranty period and coverage details. For technical support, product inquiries, or service requests, please visit the official MEDION website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: MEDION

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B081VL3WVG>

More documents and user manuals: <https://manuals.plus/>