

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bontempi](#) /

› [Bontempi iGirl Showtime Stage Microphone with 2 Microphones Instruction Manual](#)

**Bontempi 40 1472**

# Bontempi iGirl Showtime Stage Microphone with 2 Microphones

Model: 40 1472

## INTRODUCTION

---

Thank you for choosing the Bontempi iGirl Showtime Stage Microphone with 2 Microphones. This manual provides essential information for the safe and correct use of your product. Please read it thoroughly before use and retain it for future reference.



Figure 1: Bontempi iGirl Showtime Stage Microphone with 2 Microphones. This image shows the complete microphone stand assembly with two microphones and the main control unit.

## SAFETY INFORMATION

---

- **Age Recommendation:** This product is suitable for ages 3 and up.
- **Battery Safety:** Use only recommended battery types. Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly.
- **Choking Hazard:** Keep small parts away from young children.
- **Electrical Safety:** Do not expose the unit to water or moisture. Do not attempt to disassemble or repair the unit yourself.
- **Cleaning:** Clean only with a dry, soft cloth.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1 x Main Microphone Stand Unit
- 2 x Dynamic Microphones

- 1 x MP3 Connection Cable (Auxiliary cable)
- Instruction Manual



Figure 2: Product packaging showing included components. This image displays the product in its retail packaging, highlighting features like sound effects, 10 songs, drum rhythms, and the adjustable microphone stand.

## SETUP

### 1. Assembling the Microphone Stand

1. Carefully remove all components from the packaging.

2. Attach the base of the stand to the main pole. Ensure it clicks securely into place.
3. Connect the main control unit to the top of the pole.
4. Insert the two microphones into their designated holders on the control unit.
5. Adjust the height of the microphone stand by loosening the adjustable knob on the pole, extending or retracting the pole, and then tightening the knob.

## **2. Installing Batteries**

The unit requires batteries for operation. Locate the battery compartment on the underside of the main control unit.

1. Using a screwdriver, open the battery compartment cover.
2. Insert the required number of 1.5V "AA" batteries (not included), ensuring correct polarity (+/-).
3. Replace the battery compartment cover and secure it with the screw.



Figure 3: Close-up view of the control panel and microphone connections. This image provides a detailed look at the main unit, showing the various buttons for sound effects, songs, drum rhythms, and the MP3 connection port.

## OPERATING INSTRUCTIONS

### 1. Power On/Off

Locate the power button on the main control unit. Press it once to turn the unit on. Press it again to turn it off.

### 2. Using the Microphones

The unit comes with two dynamic microphones. Simply speak or sing into the microphone to amplify your voice. Ensure the microphones are securely plugged into their respective ports.

### 3. Sound Effects and Songs

The main control unit features buttons for various sound effects and pre-recorded songs. Press the corresponding buttons to activate them. Refer to the labels on the unit for specific functions.

- **Sound Effects:** Press the 'Sound Effects' button to cycle through available effects.
- **Songs:** Press the 'Songs' button to play pre-loaded melodies.
- **Drum Rhythms:** Press the 'Drum Rhythms' button to add a beat to your performance.

### 4. MP3 Connection

Connect an external audio device (e.g., smartphone, MP3 player) to the unit using the provided auxiliary cable to play your favorite music through the speaker.

1. Plug one end of the auxiliary cable into the MP3 input jack on the main control unit.
2. Plug the other end into the headphone jack of your external audio device.
3. Start playing music on your external device. The music will now play through the microphone stand's speaker.
4. Adjust the volume on your external device for optimal sound.

### 5. Magic Light Show

The microphone stand features a built-in magic light show. This will activate automatically when the unit is powered on and music or sound effects are playing, adding a visual element to your performance.

### 6. Volume Control

Adjust the overall volume using the dedicated volume controls on the main control unit. There may be separate controls for microphone volume and music volume.

## MAINTENANCE

---

- **Cleaning:** Wipe the unit and microphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the unit in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when sound quality diminishes or the unit stops functioning. Always replace all batteries at the same time.

## TROUBLESHOOTING

---

- **No Sound:**
  - Ensure the unit is powered on.
  - Check battery installation and replace if necessary.
  - Verify microphone connections.
  - Increase the volume.
- **Distorted Sound:**
  - Lower the volume.

- Check the MP3 connection cable for damage.
- **MP3 Music Not Playing:**
  - Ensure the auxiliary cable is fully inserted into both the unit and the external device.
  - Check the volume on your external device.
  - Verify that music is playing on your external device.

## SPECIFICATIONS

---

- **Model Number:** 40 1472
- **Brand:** Bontempi
- **Material:** Plastic
- **Number of Microphones:** 2
- **Connectivity:** Auxiliary (MP3 connection)
- **Power Source:** Battery Powered (Batteries not included)
- **Product Dimensions:** Approximately 14.17 x 35.04 x 14.17 inches (36 x 89 x 36 cm)
- **Item Weight:** Approximately 2.07 pounds (0.94 kg)
- **Recommended Age:** 3+ years

## WARRANTY AND SUPPORT

---

Bontempi products are designed for quality and durability. For any issues or support, please refer to the contact information provided on the product packaging or visit the official Bontempi website. Please retain your proof of purchase for warranty claims.