Vidal Sassoon VSI-1030/PJ

Vidal Sassoon Cordless 2-Way Hair Iron VSI-1030/PJ User Manual

Model: VSI-1030/PJ

Introduction

Thank you for purchasing the Vidal Sassoon Cordless 2-Way Hair Iron. This device is designed for both straightening and curling, offering convenience and portability. Please read this manual carefully before use to ensure safe and optimal performance.





Image: The Vidal Sassoon Cordless 2-Way Hair Iron in pink, featuring a Paul & Joe collaboration design.

Setup

1. Unboxing and Components

Carefully remove all components from the packaging. Ensure the following items are present:

- Vidal Sassoon Cordless 2-Way Hair Iron
- Protective Cover
- USB Cable (Type B)



Image: The compact hair iron shown next to a small handbag, demonstrating its portability.

2. Charging the Device

Before first use, fully charge the hair iron. Connect the included USB cable to the micro USB port on the device and to a USB-AC adapter (not included) or a computer. The charging time is approximately 3 hours.

Note: The device uses a removable lithium-ion battery and is compatible with world voltage for international travel. Please check with your airline regarding in-flight carry-on regulations for devices with removable batteries.



Image: A close-up of the hair iron showing the micro USB charging port and a connected USB cable.

Video: Demonstrates the USB charging process and the 2-way functionality of the hair iron.

Operating Instructions

1. Power On/Off and Mode Selection

The main switch has three positions: OFF, STRAIGHT, and CURL. Slide the switch to the desired mode (STRAIGHT or CURL) to turn on the device. Slide to OFF to power off.

2. Temperature Settings

The maximum plate temperature is approximately 180°C. The device features speed heating, reaching approximately 95°C in about 30 seconds. Please note that the actual temperature rise time may vary depending on the ambient temperature.

Video: Illustrates the temperature adjustment feature and battery indicator of a similar cordless hair iron.

3. 2-Way Styling (Straight & Curl)

This hair iron offers versatile 2-way styling. Simply select the STRAIGHT or CURL mode using the main switch. For straight styling, the inner plates heat up. For curling, the outer plates heat up.



Image: A user demonstrating how to achieve both straight and curled hairstyles using the 2-way hair iron.

4. Usage Tips

- For best results, ensure hair is dry before styling.
- Take small sections of hair for more effective styling.
- For bangs or delicate areas, use gentle, quick passes.

Video: Shows quick touch-ups and styling on the go, highlighting the portability and convenience of the hair iron.

Maintenance

1. Cleaning

Ensure the device is turned off and completely cooled before cleaning. Wipe the ceramic plates and exterior with a soft, damp

cloth. Do not use abrasive cleaners or harsh chemicals.

2. Storage

After use and cooling, place the hair iron in its protective cover for storage. The cover is designed for convenient portability. Store in a cool, dry place away from direct sunlight.



Image: The hair iron shown with its protective cover, emphasizing its design for safe and convenient storage.

Troubleshooting

- **Slow Temperature Rise:** In cold ambient temperatures, it may take longer for the plates to reach the desired temperature. This is normal operation.
- **Stiff Plate Lock:** The plate lock mechanism is designed to be slightly stiffer than usual to prevent accidental operation during transport. Apply firm pressure to slide it.
- **Device Not Turning On:** Ensure the device is fully charged. If the battery is low, the indicator lights may not illuminate.

Specifications

Feature	Specification
Model Number	VSI-1030/PJ
Dimensions (W x D x H)	Approx. 217 x 31 x 36 mm
Weight	Approx. 205 g
Plate Size	Width 19 x Length 60 mm
Curl Diameter	Approx. 19 mm x 24 mm (oval)
Plate Material	Ceramic Coating
Max Plate Temperature	Approx. 180°C
Speed Heating	Approx. 30 seconds to 95°C
Power Source	Battery-powered (Lithium-ion)
Charging Time	Approx. 3 hours
Continuous Use Time	Approx. 20 minutes (curl) / Approx. 30 minutes (straight)
Power Consumption	5W (during charging)
Main Switch	OFF-STRAIGHT-CURL
Accessories	Protective Cover, USB Cable

Warranty Information

This product comes with a **1-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Customer Support

For any questions, concerns, or technical assistance regarding your Vidal Sassoon Cordless 2-Way Hair Iron, please refer to the contact information provided with your product packaging or visit the official Vidal Sassoon website for support resources.

© 2024 Vidal Sassoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question