

[Manuals.plus](#) /

› [EXIT Toys](#) /

› EXIT Toys Stone Pool ø360x122cm with Sand Filter Pump - Grey Instruction Manual

EXIT Toys 30.27.12.00

EXIT Toys Stone Pool ø360x122cm with Sand Filter Pump - Grey

Model: 30.27.12.00

Brand: EXIT Toys

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of the EXIT Toys Stone Pool ø360x122cm with Sand Filter Pump. This round, grey-colored frame pool features a robust 3-layer PVC and polyester wall, a powder-coated steel frame, and a depth of 122 cm. It includes a sand filter pump for water purification and a pool ladder for safe entry and exit. The modern stone pattern exterior and blue interior enhance its aesthetic appeal. Please read this manual carefully before assembly and use to ensure safe operation and prolong the life of your pool.



Image 1.1: The EXIT Toys Stone Pool in use, showing its grey stone pattern exterior and children enjoying the water.

2. SAFETY INFORMATION

Your safety is paramount. Failure to follow these instructions can result in serious injury or death. Always exercise caution when using the pool.

- **Adult Supervision:** Always supervise children and non-swimmers in and around the pool.
- **No Diving:** The pool depth of 122 cm is not suitable for diving. Diving into shallow water can cause serious injury.
- **Ladder Safety:** Use the provided pool ladder for safe entry and exit. Ensure the ladder is stable before use. Remove the ladder when the pool is not in use to prevent unsupervised access by children.
- **Electrical Safety:** Ensure all electrical components, especially the sand filter pump, are connected to a grounded outlet and protected by a Residual Current Device (RCD). Do not operate electrical devices while in the pool.
- **Chemicals:** Handle pool chemicals according to manufacturer instructions. Store them out of reach of children.

- **Clear Area:** Keep the area around the pool clear of obstacles and ensure adequate drainage.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact EXIT Toys customer service.

- EXIT Stone Pool Liner (ø360x122cm)
- Powder-coated Steel Frame Set
- Sand Filter Pump
- Pool Ladder
- Hoses and Clamps for Pump Connection
- Instruction Manual



- ✓ **With sand filter pump**
- ✓ **Unique design**
- ✓ **Extra deep pool**

Image 3.1: Overview of the EXIT Toys Stone Pool, including the sand filter pump and ladder.

4. SETUP

4.1 Site Preparation

1. Choose a level, stable surface for your pool. The area must be free of sharp objects, rocks, or debris.
2. Ensure the chosen location has good drainage and is away from overhead power lines or structures.
3. A concrete slab or compacted sand base is recommended for optimal stability.

4.2 Frame Assembly

1. Unpack all frame components and lay them out according to the included assembly diagram.
2. Connect the horizontal and vertical frame pieces, ensuring all locking pins snap securely into place.
3. Do not force connections; if parts do not fit, recheck the diagram.

4.3 Liner Installation

1. Carefully spread the pool liner inside the assembled frame.
2. Ensure the drain plug is accessible and closed.
3. Smooth out any wrinkles on the bottom of the liner as you begin to fill the pool with a few centimeters of water.

4.4 Sand Filter Pump Connection

1. Position the sand filter pump on a stable, level surface near the pool, ensuring it is below the water level.
2. Connect the pump's inlet and outlet ports to the corresponding fittings on the pool liner using the provided hoses and clamps. Ensure all connections are tight to prevent leaks.
3. Fill the sand filter tank with the recommended amount and type of filter sand (not included). Refer to the pump's specific manual for details.



**GO PLAY
OUTSIDE!**



Image 4.1: The sand filter pump, showing its connections for the pool hoses.

4.5 Ladder Assembly

1. Assemble the pool ladder according to the separate instructions provided with the ladder.
2. Place the assembled ladder securely over the edge of the pool, ensuring both sides are firmly on the ground.



**GO PLAY
OUTSIDE!**



Image 4.2: The pool ladder, illustrating its design for safe pool access.

5. OPERATING THE POOL AND SAND FILTER PUMP

5.1 Filling the Pool

Once the frame and liner are in place, begin filling the pool with water. As the water level rises, continue to smooth out any wrinkles in the liner. Fill the pool to the recommended water line, typically just below the top frame rail.

5.2 Sand Filter Pump Operation

The sand filter pump is crucial for maintaining clean water. Refer to the separate sand filter pump manual for detailed operating instructions, including:

- **Filter Cycle:** Run the pump for several hours each day to ensure proper water circulation and filtration. The duration depends on pool size and usage.
- **Multi-port Valve Settings:** Understand the different settings (Filter, Backwash, Rinse, Waste, Recirculate, Closed) and when to use them.

- **Priming:** Ensure the pump is properly primed before starting to avoid damage.



Image 5.1: Close-up view of the sand filter pump, highlighting its control valve and connections.

5.3 General Pool Use

Enjoy your pool responsibly. Encourage safe play and ensure all users are aware of the safety guidelines.

Your browser does not support the video tag.

Video 5.1: An official video demonstrating the EXIT Toys Stone Pool in use, including the optional pool dome, showing families enjoying the pool.

6. MAINTENANCE

Regular maintenance is essential for clean water and the longevity of your pool.

6.1 Water Quality

- **Testing:** Regularly test your pool water for pH, chlorine, and alkalinity levels using a pool test kit.
- **Balancing:** Adjust chemical levels as needed to maintain optimal water balance. Ideal pH is 7.4-7.6, and free chlorine should be 1-3 ppm.
- **Sanitization:** Use appropriate pool sanitizers (e.g., chlorine tablets or liquid) to keep the water free from bacteria and algae.

6.2 Filter Cleaning (Backwashing)

The sand filter needs regular cleaning to remove trapped debris. This process is called backwashing.

1. Turn off the sand filter pump.
2. Set the multi-port valve to 'Backwash'.
3. Turn on the pump and backwash until the water in the sight glass runs clear (usually 2-3 minutes).
4. Turn off the pump, set the valve to 'Rinse', and run the pump for 30-60 seconds.
5. Turn off the pump, set the valve back to 'Filter', and restart the pump for normal operation.

6.3 Pool Cleaning

- **Skimming:** Use a leaf skimmer net to remove leaves, insects, and other floating debris daily.
- **Vacuumping:** Periodically vacuum the pool bottom to remove settled dirt and debris.
- **Wall Brushing:** Brush the pool walls and floor regularly to prevent algae growth.

6.4 Winterization

Before freezing temperatures arrive, properly winterize your pool to prevent damage.

1. Clean the pool thoroughly and balance the water chemistry.
2. Drain the pool to below the skimmer and return jets.
3. Disconnect and drain the sand filter pump, hoses, and heater (if applicable). Store them in a dry, frost-free location.
4. Cover the pool with a winter cover to protect it from debris.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your pool.

- **Cloudy Water:** Check filter operation, backwash if needed, test water chemistry and adjust. Consider shocking the

pool if algae is suspected.

- **Pump Not Working:** Check power connection, RCD, ensure pump is primed, check for blockages in hoses or skimmer basket.
- **Leaks:** Inspect all hose connections for tightness. Check the liner for visible tears or punctures. Small punctures can often be repaired with a vinyl patch kit.
- **Poor Water Circulation:** Ensure skimmer and return jets are clear. Check pump for proper operation and filter for cleanliness.

For persistent issues, contact EXIT Toys customer support.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions (L x W x H)	3.6 x 3.6 x 1.22 meters (ø360 x 122 cm)
Weight	58 kg
Capacity	10126 Liters
Shape	Round
Color	Grey
Material	Alloy Steel (Frame), 3-layer PVC and Polyester (Liner)
Included Components	Sand filter pump, Pool ladder
Assembly Required	Yes
Model Number	30.27.12.00






Image 8.1: Technical diagram illustrating the pool's dimensions and water capacity.

9. WARRANTY AND SUPPORT

EXIT Toys products are manufactured to high-quality standards. For information regarding warranty coverage, spare parts, or technical support, please refer to the warranty card included with your product or visit the official EXIT Toys website. Ensure you have your model number (30.27.12.00) and proof of purchase available when contacting support.



Customer service

**Over 25 years of
experience with outdoor toys**



- ✓ **Spare parts available**
- ✓ **Advice and support**
- ✓ **Excellent service**
- ✓ **Great warranty**



Image 9.1: Information regarding EXIT Toys customer service and support.

© 2023 EXIT Toys. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question