

- [Manuals.plus](#) /
- › [Little Live Pets](#) /
  - › Little Live Pets Bird - Tweeterina Instruction Manual

Little Live Pets 26029

# Little Live Pets Bird - Tweeterina Instruction Manual

Model: 26029 | Brand: Little Live Pets

## INTRODUCTION

The Little Live Pets Bird - Tweeterina is an interactive toy designed to mimic speech and respond to touch. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Tweeterina bird to ensure optimal enjoyment and longevity.



Figure 1: Little Live Pets Bird - Tweeterina

The Tweeterina bird is a charming interactive toy that repeats phrases and sings when petted. Its vibrant design and engaging features make it a delightful companion.

## SETUP

---

Follow these steps to prepare your Little Live Pets Bird - Tweeterina for play:

1. **Unboxing:** Carefully remove the Tweeterina bird from its packaging. Ensure all components, including the bird and this instruction manual, are present.
2. **Battery Installation:** The Tweeterina bird requires batteries (not included). Locate the battery compartment, usually on the

underside of the bird. Use a small screwdriver to open the compartment. Insert the required batteries, ensuring correct polarity (+/-). Close the compartment securely.

3. **Power On:** Locate the ON/OFF switch, typically on the bird's body. Slide the switch to the 'ON' position. The bird may emit a sound or move its head to indicate it is active.



Figure 2: Tweeterina in its packaging

Always use fresh batteries for best performance. Refer to the battery compartment for the specific battery type and quantity required.

## OPERATING INSTRUCTIONS

Your Little Live Pets Bird - Tweeterina offers several interactive features:

- **Talking and Repeating:** To make Tweeterina repeat what you say, press and hold the recording button (if present, typically a

small button on its chest or side) and speak clearly. Release the button, and Tweeterina will play back your message in its unique voice.

- **Petting and Singing:** Gently pet the bird's back or head. The more you pet it, the more it will tweet and sing different melodies.
- **Head Movement:** Tweeterina's head turns as it interacts, adding to its lifelike movements.





Figure 3: Close-up of Tweeterina's features

Experiment with different phrases and petting patterns to discover all of Tweeterina's responses.

## MAINTENANCE

Proper care will help extend the life of your Tweeterina bird:

- **Cleaning:** Wipe the bird with a soft, dry cloth to remove dust and dirt. Do not use harsh chemicals or immerse the toy in water.
- **Battery Replacement:** When the bird's sounds become distorted or its movements slow down, it's time to replace the batteries. Follow the battery installation steps in the Setup section.
- **Storage:** When not in use for extended periods, turn the bird off and remove the batteries to prevent leakage and damage. Store in a cool, dry place away from direct sunlight.

## TROUBLESHOOTING

If your Tweeterina bird is not functioning as expected, try these solutions:

- **No Sound/Movement:**
  - Ensure the ON/OFF switch is in the 'ON' position.
  - Check the batteries. Replace them with fresh ones if they are low or incorrectly inserted.
- **Recording Issues:**
  - Speak clearly and close to the bird's microphone (if visible).
  - Ensure you are pressing and holding the recording button correctly.
- **Intermittent Functionality:**
  - This may indicate low batteries. Replace them.
  - Ensure the bird is on a stable, flat surface.

If problems persist after trying these steps, please refer to the Support section.

## SPECIFICATIONS

|                 |                           |
|-----------------|---------------------------|
| Brand Name      | Little Live Pets          |
| Model Number    | 26029                     |
| Toy Figure Type | Interactive Gaming Figure |
| Character       | Bird                      |

|                     |                                                                                                                                           |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Age Range           | From 5 years (Manufacturer Minimum Age: 60 months)                                                                                        |
| Power Source        | Battery Powered (Batteries Required: Yes)                                                                                                 |
| Material Type       | Acrylonitrile Butadiene Styrene, Chlorinated polyvinyl chloride, Electronics, Paper, Poly(Acrylonitrile Butadiene Styrene), Polypropylene |
| Outer Material      | Plastic                                                                                                                                   |
| Item Weight         | 0.12 Kilograms                                                                                                                            |
| Item Dimensions     | 2.3 x 4 x 3.5 inches                                                                                                                      |
| Included Components | 1x Bird, 1x Instruction Manual                                                                                                            |

## Safety Information

**WARNING: CHOKING HAZARD** — Small parts. Not for children under 3 years. Adult supervision is recommended during play.

## Warranty and Support

The manufacturer's warranty description states "No Warranty" for this product. For any product-related inquiries, technical assistance, or concerns, please contact the manufacturer, Moose Toys, directly through their official customer support channels. Keep your purchase receipt as proof of purchase.

### Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B081ZWF38K>

More documents and user manuals: <https://manuals.plus/>